

AAM1-1700 NMO Connector Mounting Instructions: For 3/4" (19mm) Hole



Step 1:

Drill 3/4" (19mm) Dia. hole in panel.

Note, max. panel thickness = 5/32" (4 mm)

Insert cable with NMO connector as shown.

Note, connector installs from top of panel.



Step 2:

Insert connector so that mounting flanges are underneath panel. (See next photo)



Step 3:

Move protective cover into place as shown.

(Photo shown from underneath panel)



Step 4:

Attach the top of the connector as shown.

Note: O-Ring should be facing panel for proper seal.



Before securing fully, inspect underneath panel to ensure connector is properly seated in mounting hole.

X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for [Mounting Fixings](#) category:

Click to view products by [L-Com](#) manufacturer:

Other Similar products are found below :

[5912235-1 REV -](#) [71-344699-4S](#) [7717-8DAP](#) [HD7-1](#) [14320](#) [NT20SATT01](#) [89078GBESR](#) [9150700000](#) [BACC47CN2S](#) [ELXA051G1](#)
[1453315-11](#) [71-148608-2S](#) [H373247-15](#) [85054GBESR](#) [860099-1](#) [DM 330](#) [197-007](#) [BRKT-ND](#) [197-003](#) [1960004544](#) [CF81GHZMHDW](#)
[61104-01](#) [20011292N025050000](#) [DVA.4-40-20-M8-23-70](#) [GN 2277-ALN-20-K-30-A](#) [GN 2279-ALS-14-K-30-A](#) [GN 2280-ALN-20-K-30](#)
[GN 237-ZD-60-60-C-SR](#) [KALM-16](#) [189888-2](#) [G4-PEM-NUTS](#) [89309-00](#) [KJE-POGES 100K1](#) [M050NAHF](#) [POBW 150/20K](#) [451928](#)
[452413](#) [451521](#) [TPE-POB 100S](#) [3.ST27-1.001](#) [3.STZH3.001](#) [BPPB 0801 2100H](#) [GN 1362-NI-80-80-A-BL](#) [GN 1364-NI-105-50-B-BL](#) [GN](#)
[1364-NI-140-50-B-BL](#) [GN 136-NI-120-60-B](#) [GN 136-NI-50-50-A](#) [GN 136-NI-50-50-B](#) [GN 136-NI-50-50-C](#) [GN 136-NI-50-75-B](#)