




STRAIGHT PLUG CLAMP TYPE CABLE 1/2" SPIRAL SUPERFLEXIBLE





## **Technical Data Sheet**

Radiali			STRAIGI	HT PLUG CLAMP T	YPE CAB	LE 1/2" SP	IRAL SUF	PERFLEXI	BLE
PAGE <b>2/3</b>	ISSUE 1320A	SERIES Q	LI	PA	RT NUN	MBER <b>R</b>	R184037	007	
		Standard <b>50</b>	PAC	KAGING Unit Contact us		Other <b>Contact</b>			
Impedance Frequency VSWR Insertion loss RF leakage Voltage rating Dielectric withstar Insulation resistar		50 Ω 0-6 GHz + 0.02 x F(GH 0.05 √F(GH	ini	Operating temp Hermetic seal Panel leakage	erature	<u>SPECIFIC</u>	-4	55~+120 NA NA	°C Atm.cm3/s
MECHANICAL CHARACTERISTICS				CABLE ASSEMBLY					
Center contact ref Axial force – M. Axial force – Op Torque  Recommended to Mating Panel nut Clamp nut A/F clamp nut  Mating life	ating End pposite end orque	30 NA	N mini N mini N.cm mini N.cm N.cm N.cm N.cm	Stripping a mm 7  Assembly instru  Recommended  FSJ4RN-50B  HCF1/2"CuH-5  Characteristics indica	cable(s)	C 20	d 0	e 1.5	f 0
Weight		<b>86.42</b> g		performance cable. In assembly  Cable retention  - pull off  - torque					
Pari	t Number			<b>DLING</b>			F	lexagon	
		<u>.</u>		RACTERISTICS ed condition					






STRAIGHT PLUG CLAMP TYPE CABLE 1/2" SPIRAL SUPERFLEXIBLE


PAGE 3/3 ISSUE 1320A SERIES QLI PART NUMBER R184037007

## **COMPONENTS**




1

- Strip the cable.
- Do not damage the outer conductor.
- The end surface of inner conductor should be chamfered.
- Remove impurities such as copper scraps and burrs on the end surface of the cable.



3

- Screw the body onto the cable assembly.
- Recommended coupling torque: 950N.cm



2

- Put the O-ring onto the clamp nut.
- Screw the clamp nut along the outer conductor of the cable, make sure dimension **e** is ok after tightening.



## **X-ON Electronics**

Largest Supplier of Electrical and Electronic Components

Click to view similar products for RF Connectors / Coaxial Connectors category:

Click to view products by Radiall manufacturer:

Other Similar products are found below:

8915-1511-000 89674-0827 6001-7071-019 6002-7051-003 6002-7551-202 6059674-1 619550-1 630059-000 M39030/3-01N 6500-7071-046 6769 CX050L2AQ 7002-1541-010 7002-1542-011 7004-1512-000 7009-1511-004 7010-1511-000 7029-1511-060 7101-1541-010 7101-1571-002 7145-1521-002 7203-1571-003 7209-1511-011 7210-1511-015 7210-1511-019 73137-5015 73216-2241 73404-2300 7405-1521-005 7405-1521-802 8527 8547 FS11V 877931 8808-1511-001 9074-9513-000 9101-9573-002 910A205F 9130-9573-002 PL11SC-026 PL375-33 PL40-5 PL74C-221 PL75MC-217 PL803-7 1200690078 1-201144-1 R107003010W R110A172100 R112186000