# Panasonic ideas for life

**ELECTRONIC COUNTER** (with pre-scaling function)

## LC4H-S Counters



4-digit type



6-digit type





11 pin type

Screw terminal type

RoHS Directive compatibility information http://www.nais-e.com/ UL File No.: E122222 C-UL File No.: E122222

## **c \$11**° us ( **6**

### **Features**

### 1. Bright and Easy-to-Read Display

A brand new bright 2-color backlight LCD display. The easy-to-read screen in any location makes checking and setting procedures a cinch.

## 2. Easy to use, simple operation, simple settings

- Operation modes (input/output modes) can be set easily, using DIP switches on the side panel.
- Values can be set easily, using key switches on the front panel.
- **3. Pre-scaling function provided**A pre-scaling function enables conversion of lengths and volumes to any desired values, and displays the results.

### 4. Built-in power supply for highcapacitance sensor

An internal power supply drives a 12 VDC, 100 mA high-capacitance sensor. (AC power supply types only) Photoelectric switches, proximity switches and encoders can be directly connected.

## 5. Dual-path AC sensor can be connected.

# 6. Basic insulation between the power supply and the input terminal (only for the sensor type model with power supply)

There is no need for caution when connecting between terminals.

## 7. Conforms to IP66's Weather Resistant Standards

The water-proof panel keeps out water and dirt for reliable operation even in poor environments.

### 8. 4-digit or 6-digit display

Two sizes of displays are offered for you to choose the one that suits your needs.

## 9. Screw terminal and Pin Type are Both Standard Options

The two terminal types are standard options to support either front panel installation or embedded installation.

### 10. Compliant with UL, c-UL and CE.

#### 11. Low Price

All this at an affordable price to provide you with unmatched cost performance.

## **Product types**


Digit	Count speed	Operation mode	Output	Operation voltage	Power for sensor	Terminal	Part No.
		Maintain output/hold count     Maintain output/over count I	Relay -	100 to 240 V AC	12 V DC 100mA	11 pins	LC4H-PS-R4-AC240V
				100 to 240 V AC	12 V DC TOOMA	Screw terminal	LC4H-PS-R4-AC240VS
4				12 to 24 V DC	None	11 pins	LC4H-S-R4-24V
4				/24 V AC	none	Screw terminal	LC4H-S-R4-24VS
			<b>T</b>	12 to 24 V DC	Nama	11 pins	LC4H-S-T4-24V
	30 Hz/5 KHz	Maintain output/over count II     One shot/over count	Transistor	/24 V AC	None	Screw terminal	LC4H-S-T4-24VS
	switchable	One shot/recount I One shot/recount II One shot/hold count (7 modes)	Relay	100+- 041/40	12 V DC 100mA	11 pins	LC4H-PS-R6-AC240V
				100 to 24 V AC	12 V DC 100MA	Screw terminal	LC4H-PS-R6-AC240VS
6				12 to 24 V DC	Nama	11 pins	LC4H-S-R6-24V
0				/24 V AC	None	Screw terminal	LC4H-S-R6-24VS
				12 to 24 V DC	Niere	11 pins	LC4H-S-T6-24V
			Transistor	/24 V AC	None	Screw terminal	LC4H-S-T6-24VS

Notes) 1. Rubber packing (ATC18002) and an mounting frame (AT8-DA4) are included.

2. 100 to 240 VAC Tr outputs (11-pin terminal, screw-tightening terminal) types are also supported.

### Part names

### • 4-digit display type



(Same for screw terminal type)

### **Specifications**

			Ralay ou	itput type	Transistor output type			
	Item		AC type	DC/AC type	DC/AC type			
	Rated operating voltage		100 to 240 V	12 to 24 V DC/24 V AC	12 to 24 V DC/24 V AC			
	Rated frequency			50/60 Hz common				
	Rated power consumption		Max. 10 V A	Max	a. 3 W			
	Rated control capacity		5 A 250 V AC	(resistive load)	100 mA, 30 V DC			
	Input mode		Addition (UP)/Subtraction (DOWN)/Direction (DIR)/Individuality (IND)/Phase (PHASE) 5 modes selectable by DIP switches					
	Max. counting speed		30 Hz, 5 kHz (selectable by DIP switches)					
	Counting input	t (input 1, input 2)	16.7 ms at 30 Hz/0.1 ms at 5 kHz ON time: OFF time = 1:1					
	Reset input	· · · · · ·	Min. input	signal width: 1 ms, 20 ms (selected by DI	P switches)			
	Lock input		·	Min. input signal width: 20 ms	,			
Rating	Input signal			re system sensor Input impedance: 1 k $\Omega$ cance: 100 k $\Omega$ or less, Max. energized volt	or less, Input residual voltage: 2 V or less, tage: 40 V DC			
	Output mode	е	HOLD-A, HOLD-B, HOLD-C, SI	HOT-A, SHOT-B, SHOT-C, SHOT-D, 7 m	odes selectable by DIP switches			
	One shot ou	tput time		1 s, 0.5s, 0.2s, 0.1s, 0.05, 0.01s				
	Indication			er value (backlight red LED), Setting valu				
	Digit		4-digit display type –999 to 9999 (0 to 9999 for setting) 6-digit display type –99999 to 999999 (0 to 999999 for setting)					
	Decimal point		Can be set to three digits					
	Pre-scaling		0.001 to 9.999 (4-digit type), 0.001 to 99.999 (6-digit type)					
	Memory		EE	P-ROM (Overwriting times: 10 <sup>5</sup> ope. or m	ore)			
	Power for senser		12 V DC (±10%) 100 mA Max.					
	Contact arra	ingement	1 Fo	rm C	1 Form A (Open collector)			
Contact	Initial contact	t resistance	100 mΩ (at	_				
	Contact material		Ag alloy	_				
Life	Mechanical	(contact)	2 × 10 <sup>7</sup> ope. (Except for	r switch operation parts)	_			
LIIC	Electrical (co	ontact)	10⁵ ope. (At rate	d control voltage)	10 <sup>7</sup> ope. (At rated control voltage)			
	Operating vo	oltage range	85 to 264 V AC 10.8 to 26.4 V DC, 20.4 to 26.4 V AC					
Electrical	Initial withstand voltage		Between live and dead metal parts: 2,000 Vrms for 1 min (pin type)  Between input and output: 2,000 Vrms for 1 min					
Liectrical	Initial insulation resistance (At 500 V DC)		Between live and dead metal parts: Min. 100 M $\Omega$ (pin type) Between input and output: Min. 100 M $\Omega$					
	Temperature	e rise	Max. 65° C (under the flow of nominal operating current at nominal voltage)					
	Vibration	Functional	10 to 55 Hz (1	cycle/min), single amplitude: 0.35 mm (10	cle/min), single amplitude: 0.35 mm (10 min on 3 axes)			
Mechanical	resistance	Destructive	10 to 55 Hz (1 cycle/min), single amplitude: 0.75 mm (1 h on 3 axes)					
Mechanical	Shock	Functional		Min. 98 m/s <sup>2</sup> (4 times on 3 axes)				
	resistance	Destructive	Min. 294 m/s <sup>2</sup> (5 times on 3 axes)					
Oneration	Ambient tem	nperature	−10° C to 55° C +14° F to +131° F					
Operating conditions	Ambient hur	midity		Max. 85 % RH (non-condensing)				
Conditions	Air pressure			860 to 1,060 h Pa				
Connection				11-pin/screw terminal				
Protective co	onstruction			IP66 (front panel with a rubber gasket)				

### **Applicable standard**


Safety standard	EN61812-1	Pollution Degree 2/Overvoltage Category II
	(EMI)EN61000-6-4	
	Radiation interference electric field strength	EN55011 Group1 ClassA
	Noise terminal voltage	EN55011 Group1 ClassA
	(EMS)EN61000-6-2	
	Static discharge immunity	EN61000-4-2 4 kV contact
		8 kV air
	RF electromagnetic field immunity	EN61000-4-3 10 V/m AM modulation (80 MHz to 1 GHz)
	,	10 V/m pulse modulation (895 MHz to 905 MHz)
EMC	EFT/B immunity	EN61000-4-4 2 kV (power supply line)
		1 kV (signal line)
	Surge immunity	EN61000-4-5 1 kV (power line)
	Conductivity noise immunity	EN61000-4-6 10 V/m AM modulation (0.15 MHz to 80 MHz)
	Power frequency magnetic field immunity	EN61000-4-8 30 A/m (50 Hz)
	Voltage dip/Instantaneous stop/Voltage fluctuation immunity	EN61000-4-11 10 ms, 30% (rated voltage)
		100 ms, 60% (rated voltage)
		1,000 ms, 60% (rated voltage)
		5,000 ms, 95% (rated voltage)


### **Dimensions**

mm inch General tolerance: ±1.0 ±.039

### Pin type (Flush mount/Surface mount)








\* With power supply for sensor

\* With power supply for sensor

(\* 6-digit display type has the same dimensions.)

### • Dimensions for flush mounting (with adapter installed)

Screw terminal type Rubber gasket




### Pin type Mounting frame for flush mount AT8-DA4 (supplied) Rubber gasket ATC18002 (supplied) 11 pin type COUNTER 11 pins cap: ATA4861 (sold separately) 88888 88888 **48** 22 RESET 0 0 0 **48** 104.5

### • Dimensions for front panel installations


### DIN rail terminal block 11-pin type: AT8-DF11K (sold separately) Ę Г Device installation rail ATA48011 (sold separately) 95.5 (112.9) 3.760 (4.445) \* With power supply for sensor

### • Installation panel cut-out dimensions

The standard panel cut-out dimensions are shown below. Use the mounting frame (AT8-DA4) and rubber gasket (ATC18002).



### · For connected installations



When n units are attached in a continuous series the dimension of (A) is:


 $A = (48 \times n - 2.5)^{-0.6}$ 

Note 1: The installation panel thickness should be between 1 and 5 mm .039 and .197 inch.

Note 2: For connected installations, the waterproofing ability between the unit and installation panel is lost.

## **Terminal layouts and Wiring diagrams**

• Pin type



Note) For connecting the output leads of the transistor output type, refer to 5) Transistor output on page 141.

### Setting the operation mode and counter

### Setting procedure 1) Setting the operation mode (input mode and output mode)

Set the input and output modes with the DIP switches on the side of the counter.

#### **DIP** switches

	ltem	DIP switch			
	item	OFF ON			
1		Refer to table 1			
2	Output mode				
3					
4	Minimum reset input signal width	20 ms	1 ms		
5	Maximum counter setting	30 Hz	5 kHz		
6					
7	Input mode	Refer to	table 2		
8					

Table 1: Setting the output mode

	DII	P switch N	lo.	Output mode				
	1	2	3	Output mode				
	ON	ON	ON	SHOT-A				
_	OFF	OFF	OFF	SHOT-B				
	ON	OFF	OFF	SHOT-C				
	OFF	ON	OFF	SHOT-D				
	ON	ON	OFF	HOLD-A				
	OFF	OFF	ON	HOLD-B				
	ON	OFF	ON	HOLD-C				
	OFF	ON	ON	— (See note 1)				

Table 2: Setting the input mode

DI	P switch N	No.	Input mode
6	7	8	input mode
ON	ON	ON	Addition input
OFF	OFF	OFF	Subtraction input
ON	OFF	OFF	Directive input
OFF	ON	OFF	Independent input
ON	ON	OFF	Phase input
OFF	OFF	ON	— (See note 1)
ON	OFF	ON	— (See note 1)
OFF	ON	ON	— (See note 1)

Notes:1) The counter and set value displays will display DIP Err.

- 2) Set the DIP switches before installing the counter on the panel.
  3) When the DIP SW setting is changed, turn off the power once.
  4) The DIP switches are set as ON before shipping.

## (Same for 6-digit, screw-down terminal type)

DIP switches (See note 2)

### Setting procedure 2) Setting the set value


Set the set value with the UP and DOWN keys on the front of the counter.

### Front display section

### • 4-digit display type

- 1 Counter display
- 2 Set value display
- 3 Controlled output indicator
- (4) Reset indicator
- (5) Lock indicator
- 6 UP kevs

Changes the corresponding digit of the set value in the addition direction (upwards)



### (7) DOWN keys

Changes the corresponding digit of the set value in the subtraction direction (downwards)

8 RESET switch


Resets the counting value and the output

9 SET/LOCK switch

This is used to handle pre-scaling values, one-shot times, decimal point position settings, and key lock operations (to disable Up key, Down key, and Reset key operations).

### • 6-digit display type

- (1) Counter display
- (2) Set value display
- 3 Controlled output indicator
- (4) Reset indicator
- (5) Lock indicator



### 6 UP keys

Changes the corresponding digit of the set value in the addition direction (upwards)

(7) RESET switch

Resets the counting value and the output

8 SET/LOCK switch

This is used to handle pre-scaling values, one-shot times, decimal point position settings, and key lock operations (to disable Up key, Down key, and Reset key operations).

### Setting procedure 3) Setting the input mode

The input mode is set using the key switch in the [Display] section on the front of the counter.

### Decimal point position setting mode


① Holding down the [SET/LOCK] key, press the key for the second digit to access the decimal point position setting mode.



Example) 6-digit type Decimal point position setting mode display (Example shows default value displayed)

2 When the setting mode has been accessed, release the [SET/LOCK] key.

The decimal point is set using the [UP] and [DOWN] keys to specify the 2nd, 3rd, and 4th digits (this applies only to 4-digit models). (The 1st digit is set using the [UP] key or [DOWN] key in settings where there is no decimal point (this applies only to 4-digit models).)



Example) 6-digit type Example shows 2nd digit displayed using [UP] key

(4) Press the [RESET] key to set the displayed decimal point position and return to normal operation.

### Setting the pre-scaling value

① Holding down the [SET/LOCK] key, press the key for the first digit to access the pre-scaling value setting mode.

Example) 4-digit type



Example) 6-digit type



Pre-scaling value setting mode displayed (Example shows default values displayed)

- (2) When the setting mode has been accessed, release the [SET/LOCK] key.
- ③ Use the [UP] or [DOWN] key to set the pre-scaling value (this applies only to 4-digit models).

Select either: 0.001 to 9.999 (4-digit) or 0.001 to 99.999 (6-digit)

- (4) Press the [RESET] key to set the displayed pre-scaling value and return to normal operation.
- Setting the one-shot output time
- ① Holding down the [SET/LOCK] key, press the key for the third digit to access the one-shot output time setting mode.



Example) 6-digit type One-shot output time setting mode displayed (Example shows default value displayed)

- ② When the setting mode has been accessed, release the [SET/LOCK] key.
- ③ Each time the 1st-digit [UP] key is pressed, the one-shot output time changes in the following sequence, moving to the right:

$$\rightarrow \text{1 s} \rightarrow \text{0.5 s} \rightarrow \text{0.2 s} \rightarrow \text{0.1 s} \rightarrow \text{0.05 s} \rightarrow \text{0.01 s} -$$

(With a 4-digit type, the [DOWN] key can also be used to move to the left.)

(4) Press the [RESET] key to set the displayed one-shot output time and return to normal operation.

### Changing the set value

- 1. It is possible to change the set value with the up and down keys (4-digit type only) even during counting. However, be aware of the following points.
- 1) If the set value is changed to less than the count value with counting set to the addition direction, counting will continue until it reaches full scale (9999 with the 4-digit type and 999999 with the 6-digit type), returns to zero, and then reaches the new set value. If the set value is changed to a value above the count value, counting will continue until the count value reaches the new set value.
- 2) Suppose that thew counter is preset to count down. Whether a preset count-down value is smaller or larger than the count value, the counter counts down to "0 (zero)".
- 2. If the set value is changed to "0," the unit will not complete count-up. It starts counting up when the counting value comes to "0 (zero)" again.
- 1) Up-count (addition) input When counting is set to the addition direction, counting will continue until full scale is reached (9999 with the 4-digit type and 999999 with the 6-digit type), return to zero, and then complete count-
- 2) Down-count (subtraction) input When counting is set to the subtraction direction, counting will continue until full scale is reached (-999 with the 4-digit type and -99999 with the 6-digit type), and then the display will change to
- • • with the 4-digit type and • • with the 6-digit type.

The counting value does not become "0 (zero)" and so the counter does not count up.

3) Directive, independent, and phase inputs

The counting value is counted up or down to any number other than "0" once. When it comes to "0 (zero)" again, the counter starts counting up.

### **CAUTIONS FOR USE**

For more information regarding the cautions for use of LC4H series counter, refer to page 140 "PRECAUTIONS IN USING THE LC4H SERIES".

## Operation mode 1. Input mode

• Phase

For the input mode, you can choose one of the following five modes

 Addition UP • Subtraction DOWN • Directive DIR • Independent IND

PHASE

Input mode	Operation	*Minimum input signal width 30 Hz: 16.7 ms; 5 kHz: 0.1 ms
Addition UP	IN1 or IN2 works as an input block (gate) for the other input.	• Example where IN1 is the counting input and IN2 is the input block (gate).  IN1  H  Counting (addition)  IN2  Reset  A A A A A A A A A A A A A A A A A A A
Subtraction DOWN		• Example where IN2 is the counting input and IN1 is the input block (gate).  IN1  H Blocked  O 1 2 3 4  Counting (addition)  Counting (subtraction)  Reset  * "A" must be more than the minimum input signal width.
Directive DIR	IN1 is the counting input and IN2 is the addition or subtraction directive input. IN2 adds at L level and subtracts at H level.	IN1  H Addition AAA Subtraction AAA Addition  IN2 Counting  Addition  A A A Subtraction A A A A Addition  A A A A A Subtraction  A A A A A Addition  A A A A A Subtraction  A A A A A Addition  A A A A A Subtraction  A A A A A A Subtraction  A A A A A Subtraction  A A A A A A Addition  A A A A Subtraction  A A A A B Subtraction  A A A A Subtraction  A A A B Subtraction  A B B Subtraction
Independent IND	IN1 is addition input and IN2 is subtraction input.	* IN1 and IN2 are completely independent, so there is no restriction on signal timing.
Phase PHASE	Addition when the IN1 phase advances beyond IN2, and subtraction when the IN2 phase advances beyond IN1.	* "B" must be more than the minimum input signal width.

### LC4H-S

### 2. Output mode

• One shot/recount II

• One shot/hold count

For the output mode, you can choose one of the following seven modes

SHOT-C

SHOT-D


Maintain output/hold count
 Maintain output/over count I
 Maintain output/over count II
 One shot/over count
 One shot/recount I
 SHOT-B

• One shot/hold									
Output mode	Operation	(Example when input mode is either addition or subtraction)							
	Output control is maintained after count-up completion and until resetting.	Counting (addition)		n-3	n-2	n-1		n	
Maintain output  Hold count	During that time, the count display does not change from that at count-up com-	Counting (subtraction)		3	2	1		0	
HOLD-A	pletion.	Counting able/unable	4	Able		-	Unable		
[		Output control	OFF				ON		
		* n: Set value	011						
	Output control is maintained after count-up completion and until resetting.	Counting (addition)		n-2	n-1	n	n+1	n+2	
Maintain output	However, counting is possible despite	Counting (subtraction)		2	1	0	-1	-2	
Over count I	completion of count-up.	Counting able/unable				I Able	1	<u> </u>	ı
HOLD-B		-	•			ION			•
		Output control	OFF						
		* n: Set value							
	Output control is maintained after count-up completion and until the next	Counting (addition)		n-2	n-1	n	n+1	n+2	
Maintain output	signal enters. However, counting is	Counting (subtraction)		2	1	0	-1	-2	
Over count II	possible despite completion of count- up.	Counting able/unable				Able			
HOLD-C	<b>и</b> р.					ON	<del> </del>		•
		Output control	OFF				OFF		
		* n: Set value							
	Output control is maintained after count-up completion for one shot output time. Counting is possible despite completion of count-up.	Counting (addition)		n-2	n-1	n	n+1	n+2	
One shot Over count		Counting (subtraction)		2	1	0	-1	-2	
SHOT-A		Counting able/unable							
		Output control OFF OFF							
		* n: Set value				Appr	ox. 1s	]	
	Output control is maintained after count-up completion for one shot output time. Counting is possible despite completion of count-up. However, reset occurs simultaneous with completion of count-up. While output is being main-	Counting (addition)		n-2	n-1	0	1	2	
0		Counting (subtraction)		2	,	I _		I - 0	
One shot Recount I			1 n n-1 n-2 A Reset (automatic)						
SHOT-B		Counting able/unable Able							
	tained, restarting of the count is not	Output control	OFF OFF						
	possible	* n: Set value				Appr	ox. 1s		
	Output control is maintained after	Counting (addition)		n-1	n	n+1	0	1	
One shot	count-up completion for one shot output time. Counting is possible despite com-	Counting (subtraction)		1	0	-1	n	n-1	
Recount II	pletion of count-up. However, reset	3.		· ·		l	Reset (a		<u> </u>
SHOT-C	occurs simultaneous with output OFF.	Counting able/unable							
		Output control	OFF	OFF OFF					
		* n: Set value			Appr	ox. 1s			
				n-1		n	0	1	
	Output control is maintained after	Counting (addition)		11-1				1	
One shet	count-up completion for one shot output					n	n	n-1	
One shot Hold count	•	Counting (addition)  Counting (subtraction)		1		0	n Reset (a	n-1 automatic)	
	count-up completion for one shot output time. During that time, the count display does not change from that at count-up completion. Reset occurs simultaneous			1	(	0 Zable	<u> </u>	l	
Hold count	count-up completion for one shot output time. During that time, the count display does not change from that at count-up	Counting (subtraction)		1	(		<u> </u>	automatic)	


### Input connections

### Signal input type

### 1) Open collector



### 3) Contact input




Input 1, input 2, and reset input specifications


- Impedance during short-circuit: 1 k $\Omega$  max. (At 0  $\Omega$ , the outflow current is approximately 12 mA.)
- Residual voltage during short-circuit: 2 V max.
- Impedance when released: 100 k $\Omega$  min.
- Max. applied voltage: 40 VDC max.

### \* There is no 12 V DC with 12 - 24 V DC/24 V AC types.

### 2) For voltage output




### 4) For a rotary encoder



Lock input specifications

- Impedance during short-circuit: 1 k $\Omega$  max. (At 0  $\Omega$ , the outflow current is approximately 1.5 mA.)
- Residual voltage during short-circuit: 2 V max.
- Impedance when released: 100 k $\Omega$  min.
- Max. applied voltage: 40 DVC max.
- The contact relay should be one which can open/close 5 V, 1.5 mA.

### 5) For a dual-line sensor



**Dual-line sensor specifications** 

- Leakage current: 1.5 mA max.
- Breaker capacitance: 5 mA min.
- Residual voltage: 3.0 V max.
- Usable voltage: Runs on 10 VDC
- \* If a dual-line sensor is connected to a 12 24 VDC/24 VAC type, 24 VDC (21.6 to 26.4 VDC) and 24 VAC (21.6 to 26.4 VAC) should be applied to the power supply voltage of the counter.

### What is the prescale function?

The prescale function converts the count into an actual value (amount) and displays it.

Example

For a device that outputs 500 pulses when 1 m has been fed:

- 1. Set decimal position to the last 3rd place.
- 2. Set the prescale value to 0.002 (1/500).

