

# QSG150: C8051Fxxx Development Kit Quick-Start Guide

This guide is an excellent starting point to get familiar with the C8051Fxxx Development Kits and application development in general.

For more specific information on the features available on the kit, see the Development Kit User's Guide available on the Silicon Labs website or in Simplicity Studio. To find this document on the website, go to www.silabs.com, then navigate to [Community & Support]>[Document Library].

### KIT CONTENTS

- 1 x Development Board
- 1 x USB Debug Adapter
- 1 x AC to DC Power Adapter
- Additional USB or other cables
- · Getting Started card



Figure .1. Example C8051Fxxx Development Board

## 1. Download the Software

Silicon Labs offers two free software suites to develop your application: Simplicity Studio and the 8-bit Microcontroller Studio.

Before downloading and installing Simplicity Studio or 8-bit Microcontroller Studio, consult the 8-bit Microcontroller Studio web page for a list of supported legacy 8-bit MCU products.

The Simplicity Studio software supports both new 8-bit and all 32-bit MCU products and is available here: http://www.silabs.com/ simplicity-studio.

The 8-bit Microcontroller Studio software supports legacy 8-bit MCU products and is available here: http://www.silabs.com/8051-software.



**Note:** The images in this document display the C8051F996 Development Kit for the purposes of demonstration. The software will display appropriate content for the actual Development Kit in use.

## 2. Setting Up Your Hardware

To set up your hardware:

1. Connect a USB cable from your PC to the USB Debug Adaptor and then connect the USB Debug Adaptor ribbon cable to the 10pin connector on the board.



2. Provide power to the board by using the AC to DC power adapter included in the kit.



3. If your device has a switch, ensure that the switch is in the ON or powered position.



If using Simplicity Studio, proceed to 3. Using Simplicity Studio. If using the 8-bit Microcontroller studio, proceed to 4. Using the 8-bit Microcontroller Studio.

## 3. Using Simplicity Studio

## 3.1 Using the Software

## **Detect the Device**

Open Simplicity Studio and click [**Refresh**] <sup>3</sup>/<sub>2</sub>. The board may take some time to appear due to driver installations for the debug adapter. Select your device from the list of detected hardware.



### Open and Run [Blinky]

1. Go to the [Demos] list under [Getting Started] and select the Blinky demo from the list.

Launcher-Simplicity Studio ** Jie John y Geynaer Saych Project Bun Windo Sprin + Q Argenta (Service Bun Windo Detrice	Search C8051F996	Development Kit	(C8051F996D	×	
solutions D 🕀 🖤 🗖	Getting Started	nt Projects → Documentation - + 🗹 ☴ Software Examples	Compatible Tools	Resources tation -+⊠≡	
Contempoduct name Custom Solution	Timer2 to .	IREF	* 8051 SDK • Demos		
© 2017 Silicon Labs : "All Not Logged In	F99x Capacitive mse fo This example us the cap			basic example that uses to blink P1.3 LED DS4 at	
				pacitive Sense for overla	25

2. Click [Start] to run [Blinky] on your board.

#### **Need More Information?**

Is Simplicity Studio your first Eclipse-based IDE? Find more information on all of the features and how to use Simplicity Studio in the Help menus or in *AN0822: Simplicity Studio™ User Guide*. AN0822 can be found using the [**Application Notes**] tile in Simplicity Studio or online at http://www.silabs.com/8bit-appnotes.

#### 3.2 Additional Resources

#### Demos

For Simplicity Studio supported devices, demos are a quick and easy way to evaluate a device without compiling or debugging code. Demos can be accessed using the [**Demos**] list under [**Getting Started**].

				<b>D V</b>	
Launcher - Simplicity Studio <sup>74</sup> Eile         Edit         Navigate         Search         Project         Run         Windo	w Help			- 🗆 ×	
Sign In V 🔆 🐣 🗡	Search			😰 🏫 Launcher	
Device     Occurrent     Occurrent	C8051F996 Devel		51F996DK)		
	New Project Recent Project - Getting Started Docum	mentation Compat	ible Tools Resourc	es	
Solutions	Demos -+ 🗹 🚍	Software Examples 🛛 🗕 🕇	Documentation	-+⊠≡	
New Solution	▼ 8051 SDK v4.0.6	▼ 8051 SDK v4.0.6	The preferred SDK does not c for the select	ontain documents	
Enter product name	Demos	ADC     Blinky	for the same		
Custom Solution	Blinky This is a bar of the set Time2 to 054 at F99x Capacitive me for overt This cample un he capacitive sensing firmware stary to	CRC     CapacitiveSense	8051 SDK v4.0.6 ▼ Demos		
	F99x Capacitive nse for overk () This example us he capacitive	DS P	Blinky	0	Ð
© 2017 Silicon Labs 🗐 📲 Not Logged In		_		example that uses	
			Timer2 to blink	P1.3 LED DS4 at	2
			F99x Capacitive	e Sense for overl	25
			This example u	ses the capacitive	Γ

## Software Examples

Software examples can be imported, compiled, and downloaded using the [Software Examples] list under [Getting Started] in Simplicity Studio.

Eile Edit Navigate Search Sign In 👻 🔅 🤌	Ficher Way Tangon		arch			
Device		36				; B)
S S C8051F996 Developr	¥ ‰ ✿ ◄ 🗔 🔯			ppment Kit	(C8051F	996DK)
	_	New Project Getting Started	Recent Projects 👻	entation	Compatible To	ols Resources
		Demos	-+⊠≡	Software Examples	-+ ⊠ ≡	Documentation -
Solutions     New Solution	88.0	▼ 8051 SDK v4.0.6		<ul> <li>■ 8051 SDK v4.0.6</li> </ul>		The preferred SDK does not contain do
Enter product name		Demos		+ ADC	eternalln 📴	for the selected device. Showing appli notes.
Custom Solution				12-bit mos	DC in	<ul> <li>Application Notes</li> </ul>
				F99x-98x ADC0 Bu This example code Mode with Auto-Av	uses the Burst	
				F99x-98x ADC0 Ext	ternalinput 🙀	
				This example code		
© 2017 Silicon Labs 🛛 🚚 Not L	Logged In					
´ <b>→</b> A	I SDK v DC F99x-98x	4.0.6 ADC0 12b	it Extern	allnj 💽		
		ple code u de to take				
				168		
				んぴ		

## Documentation

Kit documentation like the schematic and detailed board description can be found using the [**Documentation**] tab in Simplicity Studio. Part documentation can also be found using the related lists.

🕶 Launcher - Simplicity Studio ™				-		×
<u>File Edit Navigate Search Project Run Window</u>						
Sign In 👻 🔅 🤌	Search				🟫 Laun	cher
Device     Cost Cost Cost Cost Cost Cost Cost C	Preferred SDK: 8051 SDK v4.0.6	Click <u>here</u> to change the preferred SD	t (C8051F996Dł		*	
	New Project Recent	Projects -	Compatible Tools	Resources		
• Solutions	My Favorite Documents	-+ 🗹	All Documents		-+	
New Solution     Enter product name     Custom Solution	No documents have been favorited. document here.	Click the 'Favorite' icon to add a	8051 SDK v4.0.6 C80515996 Development Kit (C8051F996D) • Application Notes • Data Sh • Errata • Uncategoin rd Documents • User's Guic s	0		^
	<ul> <li>Application N</li> </ul>	otoc				
		Ules				
	<ul> <li>Data Sheets</li> </ul>					
	<ul> <li>Errata</li> </ul>					
© 2017 Silicon Labs Not Logged In	<ul> <li>Uncategorize</li> </ul>	d Documents				*
	▶ User's Guide	5	· · ·			

All documentation can also be found online at [www.silabs.com]>[Community & Support]>[Document Library].

## **Application Notes**

Application Notes on peripherals and other various topics can be accessed using the [Application Notes] list under [Getting Started] in Simplicity Studio or online at http://www.silabs.com/8bit-appnotes.

Eile Edit Navigate Search Project Run Sign In 👻 👶 🎤	Search		B
Device     Constraints     Constraints	I96DK)	opment Kit (C8051F	996DK)
	New Project Recent Projects -	mentation Compatible To	ols Resources
Solutions	Demos -+ ⊠ ≡	Software Examples 🛛 🗕 🕂 🗹 🚍	Documentation
New Solution	▼ 8051 SDK v4.0.6	• 8051 SDK v4.0.6	The preferred SDK does not contain o for the selected device. Showing app
Enter product name	Demos	ADC     Blinky	notes.
Custom Solution		+ CRC	<ul> <li>Application Notes</li> </ul>
		CapacitiveSense     Current Consumption	AN0821 Sim
		DataSheetSpecExamples	This docume step-by-step v. that
		Examples	
		IREF     Interrupts	AN0828 Capacitive ensing Lib
		scillators	detailed overview of the
Application N	lotes		
AN0821 Simpli	city Studio™ C805 📑	~	
7 HOOL I Shinpi		2.4	
This document	provides a		
in a document	· · · · · · · · · · · · · · · · · · ·		
at any loss at any set	aikthrough that	K S	
step-by-step w			
step-by-step w		LN.	
step-by-step w			
step-by-step w			
step-by-step w		2	

## **Community and Support**

Have a question? Visit the community by clicking the [Silicon Labs Community] tile under [Resources] in Simplicity Studio.



The Community can also be accessed online at https://www.silabs.com/community.

## 4. Using the 8-bit Micrcontroller Studio

## 4.1 Using the Software

## **Detect the Device**

🕈 Silicon Laboratories IDE				
<u>File Edit View Project Debug Too</u>				
🗅 🚅 🖶 🕹 🛍 🖓 🗳 🗳	<u>a i Sor</u>			
	Mult figuration		1	
F80x_F83x_Blinky_AS     F80x_Blinky_asm     F80x_Blinky_asm	Toolbar C figuration			
A conformation	Toolbar E Inded Styles			
	Editor For election Editor Tat onfiguration			
	Select Lar age			
	Debug Woow Font Selection	on		
	Disassem <u>V</u> iew	•		
	Eile Backu etting			
	Suspend V0 on Halt			
	Connect Dore Opening Proje	yect		
	<ul> <li>Flash Pers on Download</li> <li>Enable Sn Download</li> </ul>			
	Show Asc Memory Window	0.05		
			Mindon -	
			<u>Connection Optic</u>	inc L
			<u>c</u> onnection optic	
File C Symbo				
×				10
-				- P 1
Build (List ) Tool ) F	ind in Files /			
Connection parameter configuration.		777777777777 Target: C8051xxxx	PC: ???? Watchpoints ???????? Not Conn 🥢	

1. Open the 8-bit Integrated Development Environment (IDE) using the Windows Start menu. From the menu bar in the IDE, click **[Options]** and then click **[Connection Options...**].

2. Select [USB Debug Adaptor] and the appropriate debug interface for the device. Devices with numbers below C8051F300 will use the [JTAG] interface, and C8051F300 devices and above will use the [C2] interface. Click [OK] to apply the settings.



3. Click the [Connect] button at the top of the screen to connect your device.

🚰 <u>F</u> ile <u>E</u> dit <u>V</u> iew <u>P</u> roject Deb <u>u</u>	<u>ug T</u> ools <u>O</u> ptions W <u>i</u> ndow <u>H</u> elp	
] D 🚅 🖬   X 🖻 🖻   🎒		,†
F80x_F83x_Blinky_AS	\$NOMOD51 F80x_Blinky.asm	
	Copyright 2009, Silicon La o http://www.silabs.com Program Description:	rator 📕
	; This program illustrates how ; configure the Crossbar, conf : I/O pin.	

## Open and Run [Blinky]

1. Select [Project] from the IDE menu at the top of the screen then click on [Open Project...].

Silicon Laboratories IDE	
Eile Edit View Project Debug Iools Options Window Help	
Add Elles to Project Add Groups to Project	気 P 1) さ 2 時間   11 回回   11 回回回回 2 1 2 4 2 5   1
Here Project. Size Project Size Project Read Project To Read Project To Load Read Project or whip To CI Chain Reagation Tenget Build Configure L	-ew Project
	Open Project
]X] 	
Open an existing workspace	1177777777777 Target: C8051xxxx PC: 7777 Watchpoints 77777777 Not Conn

2. Find the [Blinky] project for your device located in C:\Silabs\MCU\Examples\<device\_family>\Blinky. Click [Open].

🥶 Open Workspace		x
Look in: 🚺 Blinky 💌	⇐ 🗈 📸 🖬 •	
Name	Date modified	Ту
F80x_F83x_Blinky_ASM	7/22/2014 11:23 AM	Si
f∰/F80x_F83x_Blinky_C	7/22/2014 11:23 AM	Si
•		١.
File name: F80x_F83x_Blinky_ASM	Open	
Files of type: Workspaces (*.wsp)	▼ Cancel	

3. Click the [Build] button and then click the [Download] button.

Eile Edit View Project De	b <u>ug T</u> ools <u>O</u> ptions W <u>i</u> ndow <u>H</u> el	p
0 🚅 🖬   % 🖻 🖻 🎒		
F80x_F83x_Blinky_AS	SNOMOD51 F80x_Blinky.asm vyright 2009, Si n://www.silabs ogram Descriptic	🛥 ( "L 🗐 )

4. Press the [Go] button to run the program on your board.



#### 4.2 Additional Resources

#### **Software Examples**

Software examples can be imported, compiled, and downloaded using the 8-bit IDE. Examples can be found in C:\Silabs\MCU\Examp les after installing the software.

#### Documentation

Kit documentation like the schematic can be found in the User Guide related to the kit. Part documentation like the data sheet is also available.

All documentation can also be found online at [www.silabs.com]>[Community & Support]>[Document Library].

#### **Application Notes**

Application Notes on peripherals and other various topics can be accessed online at http://www.silabs.com/8bit-appnotes.

#### **Community and Support**

Have a question? Visit the community online at http://community.silabs.com.







## **Simplicity Studio**

One-click access to MCU and wireless tools, documentation, software, source code libraries & more. Available for Windows, Mac and Linux!







slifty

Support and Community community\_silabs.com

#### Disclaimer

Silicon Labs intends to provide customers with the latest, accurate, and in-depth documentation of all peripherals and modules available for system and software implementers using or intending to use the Silicon Labs products. Characterization data, available modules and peripherals, memory sizes and memory addresses refer to each specific device, and "Typical" parameters provided can and do vary in different applications. Application examples described herein are for illustrative purposes only. Silicon Labs reserves the right to make changes without further notice and limitation to product information, specifications, and descriptions herein, and does not give warranties as to the accuracy or completeness of the included information. Silicon Labs shall have no liability for the consequences of use of the information supplied herein. This document does not imply or express copyright licenses granted hereunder to design or fabricate any integrated circuits. The products are not designed or authorized to be used within any Life Support System" is any product or system intended to support or sustain life and/or health, which, if it fails, can be reasonably expected to result in significant personal injury or death. Silicon Labs products are not designed or authorized for military applications. Silicon Labs products be used in weapons of mass destruction including (but not limited to) nuclear, biological or chemical weapons, or missiles capable of delivering such weapons.

#### **Trademark Information**

Silicon Laboratories Inc.®, Silicon Laboratories®, Silicon Labs®, SiLabs® and the Silicon Labs logo®, Bluegiga®, Bluegiga Logo®, Clockbuilder®, CMEMS®, DSPLL®, EFM®, EFM32®, EFR, Ember®, Energy Micro, Energy Micro logo and combinations thereof, "the world's most energy friendly microcontrollers", Ember®, EZLink®, EZRadio®, EZRadioPRO®, Gecko®, ISOmodem®, Micrium, Precision32®, ProSLIC®, Simplicity Studio®, SiPHY®, Telegesis, the Telegesis Logo®, USBXpress®, Zentri, Z-Wave, and others are trademarks or registered trademarks of Silicon Labs. ARM, CORTEX, Cortex-M3 and THUMB are trademarks or registered trademarks of ARM Holdings. Keil is a registered trademark of ARM Limited. All other products or brand names mentioned herein are trademarks of their respective holders.



Silicon Laboratories Inc. 400 West Cesar Chavez Austin, TX 78701 USA

## http://www.silabs.com

## **X-ON Electronics**

Largest Supplier of Electrical and Electronic Components

Click to view similar products for Development Boards & Kits - 8051 category:

Click to view products by Silicon Labs manufacturer:

Other Similar products are found below :

C8051F350-TB CY3684 C8051F360-TB-K C8051F310DK C8051F390-A-DK C8051F540-TB C8051F930-TB-K C8051F850-B-DK EVAL-ADUC814QSZ EVAL-ADUC831QSZ EVAL-ADUC832QSZ EVAL-ADUC834QSZ EVAL-ADUC841QSZ EVAL-ADUC845QSPZ FT51A-EVM MIKROE-2018 MIKROE-2019 MIKROE-257 MIKROE-598 MIKROE-703 PIM447 C8051F060DK C8051F064EK C8051F226DK C8051F330DK C8051F350DK C8051F380DK C8051F380-TB-K C8051F410DK C8051F500DK C8051F540DK C8051F580DK C8051F912DK C8051F930DK C8051F970-A-DK C8051F996DK C8051F996-TB EFM8BB1LCK F990SLIDEREK MCUNIVERSITYKIT SLBLDC-MTR-RD SLSTK2000A SLSTK2011A SLSTK2020A SLSTK2022A iMCU7100EVB EVAL-ADUC842QS SLRDK1000A C8051F912-TB C8051F380-TB