


MIKROELEKTRONIKA D.O.O, Batajnički drum 23, 11000 Belgrade, Serbia VAT: SR105917343 Registration No. 20490918
Phone: + 381 11 78 57 600 Fax: + 381 11 63 09 644 E-mail: office@mikroe.com

www.mikroe.com

3D Hall 8 Click





PID: MIKROE-4498

3D Hall 8 Click is a compact add-on board containing an ultra-small 3D-magnetic sensor for industrial and consumer applications. This board features the TLI493D-W2BW, a low-power 3D Hall sensor from Infineon. This magnetic sensor combines high-accuracy magnetic field measurements with exceptionally low power consumption (minimum 7nA). It features an I2C interface, enabling it to be easily configured by MCU whit the measurement data provided in digital format. It also provides the functionality to Wake-Up a sleeping system. This Click board ™ is suitable for a wide range of magnetic sensing, including robotics position sensing, angle measurement at the end of the shaft and out of shaft configurations, and many more.

3D Hall 8 Click is supported by a $\underline{\mathsf{mikroSDK}}$ compliant library, which includes functions that simplify software development. This $\underline{\mathsf{Click}}\ \mathsf{board}^{\mathsf{TM}}$ comes as a fully tested product, ready to be used on a system equipped with the $\underline{\mathsf{mikroBUS}^{\mathsf{TM}}}$ socket.


How does it work?

3D Hall 8 Click as its foundation uses the TLI493D-W2BW, a low-power 3D Hall sensor with an I2C interface and Wake-Up feature from Infineon. It consists of three central functional units; containing the power mode control system, a low-power oscillator, basic biasing, undervoltage detection, and a fast oscillator. Besides, it has also implemented the sensing unit, which contains the HALL biasing, HALL probes with multiplexers and successive tracking ADC, and a temperature sensor. This sensor offers several use cases, including innovative human-machine interfaces in the form of industrial and consumer joysticks and precise position control in robotics.

Mikroe produces entire development toolchains for all major microcontroller architectures.

Committed to excellency, we are dedicated to helping engineers bring the project development up to speed and achieve outstanding results.










MIKROELEKTRONIKA D.O.O, Batajnički drum 23, 11000 Belgrade, Serbia VAT: SR105917343 Registration No. 20490918

Phone: + 381 11 78 57 600 Fax: + 381 11 63 09 644 E-mail: office@mikroe.com



The power mode control provides the power distribution, which manages the Start-Up behavior in the TLI493D-W2BW, a power-on reset function, and a specialized low-power oscillator, the clock source. The sensing unit measures the magnetic field in the X, Y, and Z direction. Each X-, Y- and Z-Hall probe is connected sequentially to a multiplexer, connected to an analog to digital converter. Optional, the temperature measurement feature, activated in the default state, can be determined after the three Hall channels.

3D Hall 8 Click communicates with MCU using the standard I2C 2-Wire interface to read data and configure settings, supporting Fast Mode operation with a clock frequency up to 1MHz. For each of the three magnetic channels (X/Y/Z), the Wake-Up function has an upper and lower comparison threshold. Each component of the applied field is compared to the lower and upper threshold. If one of the results is above or below these thresholds, an interrupt is generated called a Wake-Up function. The Wake-Up mode allows the sensor to continue making magnetic field measurements while the MCU is in the power-down state, which means the microcontroller will only consume power and access the sensor if relevant measurement data is available.

An interrupt pin signals a finished measurement cycle but also can be used for I2C clock stretching. In this case, the INT pin must be connected to the SCL pin, which can be done by populating the jumper labeled JP1.

This Click board[™] can be operated only with a 3.3V logic voltage level. The board must perform appropriate logic voltage level conversion before use with MCUs with different logic levels. However, the Click board[™] comes equipped with a library containing functions and an example code that can be used, as a reference, for further development.


Specifications

| Туре | Magnetic |
|------|--|
| | Can be used for a wide range of magnetic sensing, including robotics position sensing, angle measurement at the end of the shaft and out of shaft configurations, and many more. |
| | TLI493D-W2BW - low-power 3D Hall sensor with an I2C interface and Wake-Up feature |

PTIKTOE PRODUCES ENTIRE DEVELOPMENT POOICNAINS FOR All MAJOR MICROCONTROLLER ARCHITECTURES.

Committed to excellency, we are dedicated to helping engineers bring the project development up to speed and achieve outstanding results.









MIKROELEKTRONIKA D.O.O, Batajnički drum 23, 11000 Belgrade, Serbia VAT: SR105917343 Registration No. 20490918 Phone: + 381 11 78 57 600 Fax: + 381 11 63 09 644 E-mail: office@mikroe.com www.mikroe.com

| | from Infineon | | | |
|------------------|---|--|--|--|
| Key Features | Low power 3D Hall sensor, Wake-Up function, power down mode with 7nA (typ.) power consumption, 12-bit resolution for each measurement direction plus 10-bit temperature sensor, and more. | | | |
| Interface | I2C | | | |
| Feature | No ClickID | | | |
| Compatibility | mikroBUS™ | | | |
| Click board size | S (28.6 x 25.4 mm) | | | |
| Input Voltage | 3.3V | | | |

Pinout diagram

This table shows how the pinout on 3D Hall 8 Click corresponds to the pinout on the mikroBUS™ socket (the latter shown in the two middle columns).

| Notes | Pin | mikro™ BUS | | | | Pin | Notes |
|--------------|------|---------------|------|-----|----|-----|-----------|
| | NC | 1 | AN | PWM | 16 | NC | |
| | NC | 2 | RST | INT | 15 | INT | Interrupt |
| | NC | 3 | CS | RX | 14 | NC | |
| | NC | 4 | SCK | TX | 13 | NC | |
| | NC | 5 | MISO | SCL | 12 | SCL | I2C Clock |
| | NC | 6 | MOSI | SDA | 11 | SDA | I2C Data |
| Power Supply | 3.3V | 7 | 3.3V | 5V | 10 | NC | |
| Ground | GND | 8 | GND | GND | 9 | GND | Ground |

Onboard settings and indicators

| Label | Name | Default | Description |
|-------|------|---------|-----------------------------|
| LD1 | PWR | - | Power LED Indicator |
| JP1 | - | · · | I2C clock stretching jumper |

3D Hall 8 Click electrical specifications

| Description | Min | Тур | Max | Unit |
|-----------------------------|-----|------|------|------|
| Supply Voltage | - | 3.3 | - | V |
| Sensing Range | - | ±160 | - | mT |
| Resolution | - | 12 | - | bit |
| Operating Temperature Range | -40 | +25 | +125 | °C |


Software Support

We provide a library for the 3D Hall 8 Click as well as a demo application (example), developed using MikroElektronika compilers. The demo can run on all the main MikroElektronika development boards.

Mikroe produces entire development toolchains for all major microcontroller architectures.

Committed to excellency, we are dedicated to helping engineers bring the project development up to speed and achieve outstanding results.









MIKROELEKTRONIKA D.O.O, Batajnički drum 23, 11000 Belgrade, Serbia VAT: SR105917343 Registration No. 20490918 Phone: + 381 11 78 57 600 Fax: + 381 11 63 09 644 E-mail: office@mikroe.com

Package can be downloaded/installed directly from NECTO Studio Package Manager(recommended way), downloaded from our $\underline{\mathsf{LibStock}^{\mathsf{TM}}}$ or found on $\underline{\mathsf{mikroE}}$ github account.

Library Description

This library contains API for 3D Hall 8 Click driver.

Key functions:

- c3dhall8 cfg setup Config Object Initialization function.
- c3dhall8 init Initialization function.
- c3dhall8_default_cfg Click Default Configuration function.

Examples description

This application shows capability of 3D Hall 8 Click board[™]. It configures device and reads sensor data. Sensor is capeable of reading magnetic flux density from 3 axes and temperature.

The application is composed of three sections:

The full application code, and ready to use projects can be installed directly from NECTO Studio Package Manager(recommended way), downloaded from our <u>LibStock™</u> or found on <u>mikroE</u> <u>github account</u>.

Other mikroE Libraries used in the example:

- MikroSDK.Board
- MikroSDK.Log
- Click.3DHall8

Additional notes and informations

Depending on the development board you are using, you may need <u>USB UART click</u>, <u>USB UART 2 click</u> or <u>RS232 click</u> to connect to your PC, for development systems with no UART to USB interface available on the board. The terminal available in all MikroElektronika <u>compilers</u>, or any other terminal application of your choice, can be used to read the message.

mikroSDK

This Click board[™] is supported with <u>mikroSDK</u> - MikroElektronika Software Development Kit. To ensure proper operation of mikroSDK compliant Click board[™] demo applications, mikroSDK should be downloaded from the <u>LibStock</u> and installed for the compiler you are using.

For more information about mikroSDK, visit the official page.

Resources

<u>mikroBUS™</u>

mikroSDK

Click board™ Catalog

Mikroe produces entire development toolchains for all major microcontroller architectures.

Committed to excellency, we are dedicated to helping engineers bring the project development up to speed and achieve outstanding results.





health and safety management system.



MIKROELEKTRONIKA D.O.O, Batajnički drum 23, 11000 Belgrade, Serbia VAT: SR105917343 Registration No. 20490918
Phone: + 381 11 78 57 600 Fax: + 381 11 63 09 644 E-mail: office@mikroe.com

Click boards™

Downloads

TLI493D-W2BW datasheet

3D Hall 8 click 2D and 3D files

3D Hall 8 click schematic

3D Hall 8 click example on Libstock

Mikroe produces entire development toolchains for all major microcontroller architectures.

Committed to excellency, we are dedicated to helping engineers bring the project development up to speed and achieve outstanding results.





health and safety management system.

X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for Magnetic Sensor Development Tools category:

Click to view products by MikroElektronika manufacturer:

Other Similar products are found below:

AS5134 AB 5579 MIKROE-5190 EVB90395_QFN MIKROE-5125 EVB90394_BK_001 MIKROE-5387 MIKROE-1647 MK21P-KIT

AS5047P-TS_EK_AB AS5048B-TS_EK_MB AS5510-WL_EK_AB AS5510-WL_EK_DB AS5X47P-TS_EK_MB AS5X47-TS_EK_SB

AS5X6X-EK-ST AS5115-SS_EK_DB AS5145A-SS_EK_AB MMC34160PJ-B AS5170A-SO_EK_AB AS5147-EK-AB HAL APB V5.1

DPP401G000 4022 4366 AS5013-QF_EK_AB AS5045 AB AS5047D-TS_EK_AB AS5048A-TS_EK_AB AS5048B-TS_EK_AB AS5048
TS_EK_DB AS5050A-QF_EK_AB AS5132 AB AS5132 DB AS5132-PB AS5145B-EK-AB-STM1.0 AS5147P-TS_EK_AB AS5147U
TS_EK_MB AS5162-EK-AB AS5247U-TQ_EK_AB AS5600-SO_EK_SB AS5262-MF_EK_AB AS5306-TS_EK_AB AS5311
TS_EK_AB AS5510-SOIC8-AB AS5600-SO_EK_AB AS5600-SO_EK_ST AS5600-SO_RD_RB AS5601-SO_EK_AB AS5601-SO_EK_ST