


MIKROELEKTRONIKA D.O.O, Batajnički drum 23, 11000 Belgrade, Serbia VAT: SR105917343 Registration No. 20490918

Phone: + 381 11 78 57 600 Fax: + 381 11 63 09 644 E-mail: office@mikroe.com www.mikroe.com

AMR Angle Click





PID: MIKROE-4561

AMR Angle Click is a compact add-on board containing an anisotropic magnetoresistive measurement solution ideal for either angle or linear position measurements. This board features the ADA4571, an AMR sensor with clean and amplified cosine and sine output signals related to a rotating magnetic field angle from Analog Devices. It can provide better than 0.2° angular accuracy over 180°, and linear accuracy of 2mil (0.002 inches) over a 0.5-inch range, depending on the size of the used magnet. This Click board™ is suitable for absolute position measurement (linear and angle), contactless angular measurement and detection, magnetic angular position sensing, actuator control and positioning, and more.


AMR Angle Click supports the mikroSDK compliant library, which includes functions that simplify software development. This Click board™ comes as a thoroughly tested product, ready to be used on a system equipped with the mikroBUS™ socket.

How does it work?

AMR Angle Click, as its foundation, uses the ADA4571, an anisotropic magnetoresistive (AMR) sensor with integrated signal conditioning amplifiers and ADC drivers, as well as a temperature sensor for temperature compensation from Analog Devices. It produces two analog outputs that indicate the surrounding magnetic field's angular position and consists of two die within one package, an AMR sensor, and a fixed gain instrumentation amplifier, with G=40 nominally. It provides better than 0.2° angular accuracy over 180°, and linear accuracy of 2mil (0.002 inches) over a 0.5-inch range, depending on the used magnet's size.

Mikroe produces entire development toolchains for all major microcontroller architectures. Committed to excellency, we are dedicated to helping engineers bring the project development up to speed and achieve outstanding results.










MIKROELEKTRONIKA D.O.O, Batajnički drum 23, 11000 Belgrade, Serbia VAT: SR105917343 Registration No. 20490918

Phone: + 381 11 78 57 600 Fax: + 381 11 63 09 644 E-mail: office@mikroe.com



The ADA4571 contains two Wheatstone bridges, at a relative angle of 45° to one another. A rotating magnetic field in the x-y sensor plane delivers two sinusoidal output signals with the double frequency of the angle between sensor and magnetic field direction. Within a homogeneous field in the x-y plane, the output signals are independent of the physical placement in the z-direction (air gap).

The AMR Angle Click communicates with MCU through the 3-Wire SPI serial interface using the LTC1407, 12-bit 3MSPS ADC with two 1.5MSPS simultaneously sampled differential inputs from Analog Devices. The LTC1407 samples both channels of the sensor simultaneously using an SPI interface, allowing access to both channels on one data line. Besides, it possesses additional functionality routed on some GPIO pins such as Power-Down mode, Gain control, and temperature monitoring.

The power-down feature labeled as PD and routed on the PWM pin of the mikroBUS™ socket shuts down the device. It sets its outputs to a high impedance to avoid current consumption, while the VTEMP routed on the AN pin can be used for temperature monitoring or calibration purposes. Gain control, labeled as GC and routed on the RST pin of the mikroBUS™ socket, activates by switching this pin to a high level. In this mode, the AMR sensor amplitude outputs are compensated to reduce temperature variation, which results in higher and controlled output voltage levels. It can also be used as a sensor self-diagnostic feature by comparing the sine and cosine amplitude outputs when enabled and disabled, such as radius check.

This Click board[™] can be operated only with a 3.3V logic voltage level. The board must perform appropriate logic voltage level conversion before use with MCUs with different logic levels. However, the Click board[™] comes equipped with a library containing functions and an example code that can be used, as a reference, for further development.

Specifications

Туре	Magnetic
Applications	Can be used for absolute position measurement (linear and angle), contactless angular measurement and detection, magnetic angular position sensing, actuator control and positioning, and more.
On-board modules	ADA4571 - AMR sensor with clean and

Mikroe produces entire development rooicnains for all major microcontroller architectures.

Committed to excellency, we are dedicated to helping engineers bring the project development up to speed and achieve outstanding results.







MIKROELEKTRONIKA D.O.O, Batajnički drum 23, 11000 Belgrade, Serbia VAT: SR105917343 Registration No. 20490918

Phone: + 381 11 78 57 600 Fax: + 381 11 63 09 644 E-mail: office@mikroe.com

	amplified cosine and sine output signals related to a rotating magnetic field angle from Analog Devices LTC1407 - 12-bit 3MSPS ADC with two 1.5MSPS simultaneously sampled differential inputs from Analog Devices
Key Features	High precision 180° angle sensor, maximum angular error of 0.5°, magnetoresistive (MR) bridge temperature compensation mode, fault diagnostic, and more.
Interface	SPI
Feature	No ClickID
Compatibility	mikroBUS™
Click board size	M (42.9 x 25.4 mm)
Input Voltage	3.3V

Pinout diagram

This table shows how the pinout on AMR Angle Click corresponds to the pinout on the mikroBUS™ socket (the latter shown in the two middle columns).

Notes	Pin	mikro™ BUS				Pin	Notes
Temperature Monitoring	VTP	1	AN	PWM	16	PD	Power-Down Mode
Gain Control	GC	2	RST	INT	15	NC	
SPI Chip Select	CS	3	CS	RX	14	NC	
SPI Clock	SCK	4 SCK		TX	13	NC	
SPI Data OUT	SDO	5 MISO		SCL	12	NC	
	NC	6	MOSI	SDA	11	NC	
Power Supply	3.3V	7	3.3V	5V	10	NC	
Ground	GND	8	GND	GND	9	GND	Ground

Onboard settings and indicators

Label	Name	Default	Description		
LD1	PWR	-	Power LED Indicator		

AMR Angle Click electrical specifications

Description	Min	Тур	Max	Unit
Supply Voltage	-	3.3	-	V
Rotation Angle	0	-	180	degrees
Angular Error	-	-	0.5	degrees
Resolution	12	-	-	bits
Operating Temperature Range	0	+25	+70	°C

Software Support

We provide a library for the AMR Angle Click as well as a demo application (example), developed using MIKROE compilers. The demo can run on all the main MIKROE development

Mikroe produces entire development toolchains for all major microcontroller architectures.

Committed to excellency, we are dedicated to helping engineers bring the project development up to speed and achieve outstanding results.





MIKROELEKTRONIKA D.O.O, Batajnički drum 23, 11000 Belgrade, Serbia VAT: SR105917343 Registration No. 20490918
Phone: + 381 11 78 57 600 Fax: + 381 11 63 09 644 E-mail: office@mikroe.com

boards.

Package can be downloaded/installed directly from NECTO Studio Package Manager (recommended), downloaded from our <u>LibStock™</u> or found on <u>MIKROE github account</u>.

Library Description

This library contains API for AMR Angle Click driver.

Key functions

- amrangle angle read This function reads an angle in degrees.
- amrangle_read_vtp_temp This function returns calculated temperature using vtp pin voltage.

www.mikroe.com

• amrangle_gain_control_mode This function sets the gain control mode pin which is used to compensate the sensor amplitude output for reduction of temperature variation.

Example Description

This demo application shows the performance of AMR Angle Click by reading and presenting the temperature and angle results on the UART log.

The full application code, and ready to use projects can be installed directly from NECTO Studio Package Manager (recommended), downloaded from our $\underline{\mathsf{LibStock}}^\mathsf{TM}$ or found on $\underline{\mathsf{MIKROE\ github\ account}}$.

Other MIKROE Libraries used in the example:

- MikroSDK.Board
- MikroSDK.Log
- Click.AMRAngle

Additional notes and informations

Depending on the development board you are using, you may need <u>USB UART click</u>, <u>USB UART 2 Click</u> or <u>RS232 Click</u> to connect to your PC, for development systems with no UART to USB interface available on the board. UART terminal is available in all MIKROE compilers.


mikroSDK

This Click board[™] is supported with $\underline{\mathsf{mikroSDK}}$ - MIKROE Software Development Kit. To ensure proper operation of mikroSDK compliant Click board[™] demo applications, mikroSDK should be downloaded from the $\underline{\mathsf{LibStock}}$ and installed for the compiler you are using.

For more information about mikroSDK, visit the official page.

Resources

mikroBUS™



Mikroe produces entire development toolchains for all major microcontroller architectures.





health and safety management system.



MIKROELEKTRONIKA D.O.O, Batajnički drum 23, 11000 Belgrade, Serbia VAT: SR105917343 Registration No. 20490918

Phone: + 381 1178 57 600 Fax: + 381 11 63 09 644 E-mail: office@mikroe.com www.mikroe.com

mikroSDK

Click board™ Catalog

Click Boards™

Downloads

AMR Angle click 2D and 3D files

AMR Angle click schematic

ADA4571 datasheet

LTC1407 datasheet

AMR Angle click example on Libstock

Mikroe produces entire development toolchains for all major microcontroller architectures.

Committed to excellency, we are dedicated to helping engineers bring the project development up to speed and achieve outstanding results.







health and safety management system.

X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for Magnetic Sensor Development Tools category:

Click to view products by MikroElektronika manufacturer:

Other Similar products are found below:

AS5134 AB 5579 MIKROE-5190 EVB90395_QFN MIKROE-5125 EVB90394_BK_001 MIKROE-5387 MIKROE-1647 MK21P-KIT

AS5047P-TS_EK_AB AS5048B-TS_EK_MB AS5510-WL_EK_AB AS5510-WL_EK_DB AS5X47P-TS_EK_MB AS5X47-TS_EK_SB

AS5X6X-EK-ST AS5115-SS_EK_DB AS5145A-SS_EK_AB MMC34160PJ-B AS5170A-SO_EK_AB AS5147-EK-AB HAL APB V5.1

DPP401G000 4022 4366 AS5013-QF_EK_AB AS5045 AB AS5047D-TS_EK_AB AS5048A-TS_EK_AB AS5048B-TS_EK_AB AS5048
TS_EK_DB AS5050A-QF_EK_AB AS5132 AB AS5132 DB AS5132-PB AS5145B-EK-AB-STM1.0 AS5147P-TS_EK_AB AS5147U
TS_EK_MB AS5162-EK-AB AS5247U-TQ_EK_AB AS5600-SO_EK_SB AS5262-MF_EK_AB AS5306-TS_EK_AB AS5311
TS_EK_AB AS5510-SOIC8-AB AS5600-SO_EK_AB AS5600-SO_EK_ST AS5600-SO_RD_RB AS5601-SO_EK_AB AS5601-SO_EK_ST