

MIKROELEKTRONIKA D.O.O, Batajnički drum 23, 11000 Belgrade, Serbia VAT: SR105917343 Registration No. 20490918 Phone: + 381 11 78 57 600 Fax: + 381 11 63 09 644 E-mail: office@mikroe.com

Heart Rate 13 Click





PID: MIKROE-6490

Heart Rate 13 Click is a compact add-on board for precise and reliable vital sign monitoring. This board features the <u>SFH 7074</u>, a biomonitoring sensor from <u>ams OSRAM</u>, with signal processing handled by the <u>ADPD1080</u> photometric front-end from Analog Devices. The SFH 7074 is optimized for photoplethysmography (PPG) applications, featuring a strong optical signal, an integrated light barrier to prevent crosstalk and high ESD protection. The ADPD1080 ensures accurate signal conversion with a 14-bit ADC and built-in interference rejection, enabling stable measurements even under ambient light conditions. Communication with the host MCU is established via an I2C interface, with additional I/O pins for interrupts and clocking options. Heart Rate 13 Click is ideal for wearable health devices, fitness trackers, and medical diagnostic applications, where real-time biometric data is essential for monitoring heart rate, oxygen saturation, and other vital signs.

For more information about **Heart Rate 13 Click** visit the official product page.

How does it work?

Heart Rate 13 Click is based on the SFH 7074, a high-performance biomonitoring sensor from ams OSRAM, designed for precise and reliable vital sign monitoring. This sensor is optimized for photoplethysmography (PPG) applications, providing a strong and accurate optical signal while minimizing the effects of optical crosstalk through an integrated light barrier. Additionally, the SFH 7074 meets stringent ESD protection standards (1.5 kV acc. to ANSI/ESDA/JEDEC JS-001 HBM), ensuring robustness in various operating environments. Due to its advanced design, this sensor is widely used in digital diagnostic applications like wearable devices, fitness trackers, and medical diagnostic equipment, enabling accurate heart rate, oxygen saturation, and other biometric measurements.

Mikroe produces entire development toolchains for all major microcontroller architectures.

Committed to excellency, we are dedicated to helping engineers bring the project development up to speed and achieve outstanding results.








MIKROELEKTRONIKA D.O.O, Batajnički drum 23, 11000 Belgrade, Serbia VAT: SR105917343 Registration No. 20490918

Phone: + 381 1178 57 600 Fax: + 381 11 63 09 644 E-mail: office@mikroe.com



Heart Rate 13 Click incorporates the ADPD1080, a photometric front-end from Analog Devices, to ensure optimal signal processing and high measurement accuracy. This front end is essential for handling the optical signals received from the SFH 7074, as it includes a 14-bit analog-to-digital converter (ADC) and a 20-bit burst accumulator, allowing precise digital conversion of the detected biometric data. The ADPD1080 controls the sensor's light-emitting diodes (LEDs), stimulating and capturing the reflected optical signals to generate accurate readings. A key advantage of this front-end is its built-in signal processing capabilities, which eliminate the need for external optical filters or DC cancellation circuits. It suppresses signal offset and reduces corruption caused by modulated interference, commonly introduced by ambient light sources, ensuring stable and reliable biometric measurements.

This Click board™ establishes communication with the host MCU through a standard I2C interface of the ADPD1080 operating at 1.8V. Additionally, it features two general-purpose I/O pins (IOO and IO1), which are connected to the default mikroBUS™ socket's PWM and INT positions. These pins serve as interrupt sources and offer various clocking options, allowing for greater flexibility in application design and integration with different processing platforms.

The SFH 7074 operates at a 3.3V supply and requires no specific power-up sequence. However, the ADPD1080 photometric front-end requires a 1.8V supply for its analog and digital core to function correctly. To accommodate this requirement, Heart Rate 13 Click integrates a small low-dropout (LDO) voltage regulator, the BH18PB1WHFV, which converts the 3.3V mikroBUS™ power rail into a stable 1.8V supply, ensuring proper operation of the ADPD1080.

This Click board™ can be operated only with a 3.3V logic voltage level. The board must perform appropriate logic voltage level conversion before using MCUs with different logic levels. It also comes equipped with a library containing functions and example code that can be used as a reference for further development.

Specifications

Туре	Biometrics,Heart Rate
1 ' '	ldeal for wearable health devices, fitness trackers, and medical diagnostic applications
	SFH 7074 - biomonitoring sensor from ams OSRAM ADPD1080 - photometric front-end from Analog Devices

Mikroe produces entire development toolchains for all major microcontrolfer architectures.

Committed to excellency, we are dedicated to helping engineers bring the project development up to speed and achieve outstanding results.









MIKROELEKTRONIKA D.O.O, Batajnički drum 23, 11000 Belgrade, Serbia VAT: SR105917343 Registration No. 20490918
Phone: + 381 11 78 57 600 Fax: + 381 11 63 09 644 E-mail: office@mikroe.com

Key Features	Biomonitoring sensor optimized for photoplethysmography (PPG) applications, photometric front-end, strong PPG signal with an integrated light barrier to prevent optical crosstalk, ESD protection, advanced signal processing, and more
Interface	12C
Feature	ClickID
Compatibility	mikroBUS™
Click board size	M (42.9 x 25.4 mm)
Input Voltage	3.3V

www.mikroe.com

Pinout diagram

This table shows how the pinout on Heart Rate 13 Click corresponds to the pinout on the mikroBUS™ socket (the latter shown in the two middle columns).

Notes	Pin	, mikro~ , b BUS				Pin	Notes
	NC	1	AN	PWM	16	100	General-Purpose I/O 0
	NC	2	RST	INT	15	101	General-Purpose I/O 1
ID COMM	CS	3	CS	RX	14	NC	
	NC	4	SCK	TX	13	NC	
	NC	5	MISO	SCL	12	SCL	I2C Clock
	NC	6	MOSI	SDA	11	SDA	I2C Data
Power Supply	3.3V	7	3.3V	5V	10	NC	
Ground	GND	8	GND	GND	9	GND	Ground

Onboard settings and indicators

Label	Name	Default	Description
LD1	PWR	-	Power LED Indicator

Heart Rate 13 Click electrical specifications

Description	Min	Тур	Max	Unit
Supply Voltage	-	3.3	-	V
Green Emitter Peak Wavelength	-	526	-	nm
Red Emitter Peak Wavelength	-	660	1	nm
Infrared Emitter Peak Wavelength	-	950	-	nm
Broadband Photodiode Peak Wavelength		940	-	nm
IR-Cut Photodiode Peak Wavelength	-	635	-	nm

Software Support

Heart Rate 13 Click demo application is developed using the NECTO Studio, ensuring compatibility with mikroSDK's open-source libraries and tools. Designed for plug-and-play implementation and testing, the demo is fully compatible with all development, starter, and mikromedia boards featuring a mikroBUS™ socket.

Mikroe produces entire development toolchains for all major microcontroller architectures.

Committed to excellency, we are dedicated to helping engineers bring the project development up to speed and achieve outstanding results.









MIKROELEKTRONIKA D.O.O, Batajnički drum 23, 11000 Belgrade, Serbia VAT: SR105917343 Registration No. 20490918

Phone: + 381 11 78 57 600 Fax: + 381 11 63 09 644 E-mail: office@mikroe.com

www.mikroe.com

Example Description

This example demonstrates the use of Heart Rate 13 Click board by reading and displaying the PPG measurements which can be visualized on the SerialPlot application.

Key Functions

- heartrate13 cfg setup Config Object Initialization function.
- heartrate13 init Initialization function.
- heartrate13 default cfg Click Default Configuration function.
- heartrate13 get pd data This function waits for the data ready interrupt and then reads data from photodiodes PD1, PD2, and PD3.
- heartrate13 set mode This function sets the device operating mode.
- heartrate13 sw reset This function executes software reset of the device.

Application Init

Initializes the driver and performs the Click default configuration for heart rate measurement.

Application Task

Waits for the data ready interrupt, then reads the PPG measurements and displays it on the USB UART (SerialPlot).

Application Output

This Click board can be interfaced and monitored in two ways:

- Application Output Use the "Application Output" window in Debug mode for real-time data monitoring. Set it up properly by following this tutorial.
- UART Terminal Monitor data via the UART Terminal using a USB to UART converter. For detailed instructions, check out this tutorial.

Additional Notes and Information

The complete application code and a ready-to-use project are available through the NECTO Studio Package Manager for direct installation in the <u>NECTO Studio</u>. The application code can also be found on the MIKROE GitHub account.

Resources

mikroBUS™

mikroSDK

Click board™ Catalog

Click boards™

ClickID

Downloads

Heart Rate 13 click example package

Mikroe produces entire development toolchains for all major microcontroller architectures.

Committed to excellency, we are dedicated to helping engineers bring the project development up to speed and achieve outstanding results.





health and safety management system.



MIKROELEKTRONIKA D.O.O, Batajnički drum 23, 11000 Belgrade, Serbia VAT: SR105917343 Registration No. 20490918

Phone: + 381 1178 57 600 Fax: + 381 11 63 09 644 E-mail: office@mikroe.com www.mikroe.com

Heart Rate 13 click 2D and 3D files v100

SFH 7074 datasheet

ADPD1080 datasheet

Heart Rate 13 click schematic v100

Mikroe produces entire development toolchains for all major microcontroller architectures.

Committed to excellency, we are dedicated to helping engineers bring the project development up to speed and achieve outstanding results.







X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for Multiple Function Sensor Development Tools category:

Click to view products by MikroElektronika manufacturer:

Other Similar products are found below:

SLG-0150 EV_ICM-42670-P MIKROE-5448 GX-F12A GX-F12A-P GX-F15A GX-F6A GX-F6A-P GX-F8B GX-H12A GX-H12A-P

1093 MIKROE-2455 MIKROE-2458 MIKROE-2507 MIKROE-2508 176 189 1893 ATQT4-XPRO GP30-DEMO MODULE 910-28015A

GX-F15A-P GX-F8A GX-F8A-P GX-H15A-P GX-H8A GX-H8A-P 28092 SDAWIR01 AAS-AQS-UNO SDAWIR02 SDAF01

IQS620AEV04-S SMOD701KITV1 DFR0131 DFR0165 DFR0280 SEN0213 SEN0217 SEN0219 SEN0220 SEN0231 SEK002

SSCCOMMBOARDV4P1C MIKROE-2786 MIKROE-2731 SPEEDTOGOKITTOBO1 2JCIE-BL01-P1 SEN0160