

	<b>Price groups</b> PG 14O, 41B, 41E, 41F, 41G, 41H, 41J, 42F, 42J
7/2	Introduction
	Motor starter protectors/ circuit breakers SIRIUS 3RV2 motor starter protectors/ circuit breakers
7/7	General data
7/26	For motor protection NEW
7/30	For motor protection with overload relay function <b>NEW</b>
7/32	For starter combinations <b>NEW</b>
7/34	For transformer protection
7/35	For system protection according to UL 489/CSA C22.2 No.5 <b>NEW</b>
7/36	For transformer protection according to UL 489/CSA C22.2 No.5
7/07	Accessories
7/37 7/40	- Mountable accessories - Busbar accessories NEW
7/40	- Rotary operating mechanisms
7/45	- Mounting accessories NEW
7/52	- Enclosures and front plates
7/55	3RV29 infeed system
	SIRIUS 3RV1 motor starter protectors/circuit breakers
7/60	For fuse monitoring
7/61	For distance protection
	SIRIUS 3RV1 molded case motor starter protectors up to 800 A
7/62	General data
7/67	For motor protection
7/68	For starter combinations
	Accessories
7/69	- Mountable accessories
7/70	- Rotary operating mechanisms, mounting accessories

	Overload relays
7/71	General data
	SIRIUS 3RU2 thermal overload relays
7/78	3RU2 for standard applications NEW
7/88	Accessories <b>NEW</b>
	SIRIUS 3RB3 electronic overload relays
7/90	3RB30, 3RB31
	for standard applications NEW
7/100	Accessories <b>NEW</b>
	SIRIUS 3RB2 electronic overload relays
7/102	3RB20, 3RB21
	for standard applications
7/112	Accessories for 3RB20, 3RB21
7/114	3RB22, 3RB23
	for high-feature applications
7/122	3RB24 for IO-Link
	for high-feature applications
7/129	Current measuring modules for 3RB22, 3RB23, 3RB24
7/133	Accessories for 3RB22, 3RB23, 3RB24

## Note:

The 3RV1, 3RU1 and 3RB2 devices (sizes S00/S0 to S12) can be found

- in the Catalog Add-On IC 10 AO · 2016 at the Information and Download Center
- in the interactive Catalog CA 01
- in the Industry Mall

Conversion tool, e.g. from

- 3RV1 to 3RV2
- 3RU11 to 3RU21
- 3RB20/3RB21 to 3RB30/3RB31

see

www.siemens.com/sirius/conversion-tool

## Introduction

#### Overview













		•	6			6	4			4		9	7		9 9		P				
Туре		3RV	20			3RV	21			3RV	23			3RV2	4		3RV2	27		3RV2	28
SIRIUS 3RV2 motor starte	r pro	otect	ors/c	ircui	t brea	kers															
Applications																					
System protection		<b>√</b> 1)				<b>√</b> 1)											1			1	
Motor protection		1																			
<ul> <li>Motor protection with overload relay function</li> </ul>						1															
<ul> <li>Starter combinations</li> </ul>										1											
<ul> <li>Transformer protection</li> </ul>														1			1			/	
Size		S00	, S0, S	S2, S3		S00	S0, S	82, S3		S00	, S0,	S2, S	33	S00, \$	S0, S2		S00,	S0, S	3	S00,	S0
Rated current In																					
<ul><li>Size S00</li><li>Size S0</li><li>Size S2</li><li>Size S3</li></ul>	A A A	Up t	to 16 to 40 to 80 to 100	)		Up t Up t	o 16 o 32 o 80 o 100			Up :		1		Up to Up to Up to 	25		Up to Up to  Up to	22		Up to Up to 	
Rated operational voltage $U_{\rm e}$ acc. to IEC	V	690	AC <sup>2)</sup>			690	AC <sup>2)</sup>				AC <sup>2</sup>	)		690 A	.C <sup>2)</sup>		690 /	AC		690 /	AC
Rated frequency	Hz	50/6	60			50/6	0			50/6	60			50/60			50/60	)		50/60	)
Trip class				) (S00 ) (S2,	S3), S3)	CLA	.SS 10	)						CLAS	S 10						
Thermal overload releases	A A		0. 100				0. <sup>.</sup> 100	16 to		Non	ю <sup>3)</sup>			0.11 . 54	0.16 65	to	0.16 Non-	70 adjust	able	0.16 Non-	22 adjustable
<b>Electronic releases</b> A multiple of the rated current		13 t	imes			13 ti	mes			13 t	imes			20 tim	nes		13 tir	nes		20 tir	nes
Short-circuit breaking capacity I <sub>cu</sub> at 400 V AC	kΑ	20/5	55/65/	100		55/6	5/100			20/5	55/65	/100		55/65	/100		4)			4)	
Pages		7/26	3 7/	28		7/30	)			7/32	2, 7/3	33		7/34			7/35			7/36	
Accessories																					
For sizes		S00	S0	S2	S3	S00	S0	S2	S3	S00	S0	S2	S3	S00	S0	S2	S00	S0	S3	S00	S0
Auxiliary switches		1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
Signaling switches		1	1	1	1	1	1	1	1	1	1	/	1	1	1	1					
Undervoltage releases		1	1	1	1					1	1	1	1	1	1	1	1	1	1	1	1
Shunt releases		/	1	1	1					1	1	/	1	1	/	1	/	/	1	1	1
Isolator modules		1	1	1		1	1	/		1	1	1		1	1	1					
Insulated three-phase busbar system		1	1	1						1	1	1		1	1	1					
Busbar adapters		1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1		
Door-coupling rotary operating mechanisms		1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
Link modules		1	1	1	✓	1	1	1	1	1	1	1	1	1	1	1					
Enclosures for surface mounting	g	1	1	1		/	1	1		1	1	1		1	1	1					
Enclosures for flush mounting		1	1			1	1			1	1			1	1						
Front plates		/	1	1	1	1	1	1	1	1	1	1	1	1	1	1					
Infeed system		1	1							1	1			1	1						
Sealable scale covers for setting knobs		1	1	1	1	1	1	1	1				-	1	1	1					
Remote motorized operating mechanisms					1				1				1								
Pages		7/37	7/5	59																	
and the second second									1)	_											

<sup>✓</sup> Has this function or can use this accessory

<sup>--</sup> Does not have this function or cannot use this accessory

<sup>1)</sup> For symmetrical loading of the three phases.

With molded-plastic enclosure 500 V AC. For DC applications, see "Technical Specifications" → "DC Short-Circuit Breaking Capacity", page 7/17.

<sup>3)</sup> For overload protection of the motors, appropriate overload relays must be used.

 $<sup>^{\</sup>rm 4)}$  According to UL 489 at 480 Y/277 V AC: 65 kA or 50 kA.

## Introduction



S00

7/60, 7/61



Type	3RV1611-0BD10	3RV1611-1.G14
SIRIUS 3RV1 motor starter protectors/circ	uit breakers	
Applications		
System protection		
Motor protection		
<ul> <li>Motor protection with overload relay function</li> </ul>		
Starter combinations		
Transformer protection		
Fuse monitoring	✓	
<ul> <li>Voltage transformer circuit breakers for distance protection</li> </ul>		1
Size	S00	S00
Rated current I <sub>n</sub>		
• Size S00	0.2	Up to 3
Rated operational voltage $U_{\rm e}$ acc. to IEC	690 AC <sup>1)</sup>	400 AC
Rated frequency	50/60	$16^2/_3 \dots 60$
Trip class		
Thermal overload releases	0.2	1.4 3
<b>Electronic releases</b> A multiple of the rated current	6 times	4 7 times
Short-circuit breaking capacity $I_{\rm cu}$ at 400 V AC	100	50
Pages	7/60	7/61
Accessories		

S00

✓ Has this function or can use this accessory

For sizes

- -- Does not have this function or cannot use this accessory
- With molded-plastic enclosure 500 V AC. For DC applications, see "Technical Specifications" → "DC Short-Circuit Breaking Capacity", page 7/18.

## Introduction





		-								
Type		3RV10			3RV13					
SIRIUS 3RV1 molded of	ase	motor star	rter protecto	ors						
Applications										
<ul> <li>Motor protection</li> </ul>		✓								
<ul> <li>Starter combinations</li> </ul>					1					
Switching capacity		Standard sw	ritching capac	ity	Standard swit	ching capacit	ty		Increased st capacity	witching
Туре		3RV1063	3RV1073	3RV1083	3RV1353	3RV1363	3RV1373	3RV1383	3RV1364	3RV1374
Rated current In	Α	100 200	400	630	1 32	100 250	400, 630	630, 800	100 250	400
Rated operational voltage $U_{\rm e}$ acc. to IEC	V	690 AC			690 AC					
Rated frequency	Hz	50/60			50/60					
Trip class		CLASS 10A,	10, 20, 30		1)					
Thermal overload releases	s A A	40 100 to 252 630			Without <sup>1)</sup>					
Electronic releases A multiple of the rated current		Adjustable,	6 13 times		Non-adjustable 1 12.5 A: 13 times; Adjustable 20 A, 32 A: 6 12 times	1 10 times	3			
Short-circuit breaking capacity I <sub>cu</sub> at 400 V AC	kA	120	120	100	85	120	120	100	200	200
Trip unit (release)		TU 4			TU 1: 1 12.5 A; TU 2: 20 A, 32 A	TU 3				
Pages		7/67			7/68					
Assessation										

Accessories													
For molded case motor starter protectors	3RV1063	3RV1073	3RV1083	3RV1353	3RV1363	3RV1373	3RV1383	3RV1364	3RV1374				
Auxiliary switches	1	1	✓	1	✓	1	✓	1	1				
Undervoltage releases	✓	1	✓	1	1	✓	1	1	1				
Shunt releases	1	1	✓	1	✓	1	✓	1	1				
Rotary operating mechanisms	1	1	✓	✓	1	1	1	✓	1				
Connection methods • Extended terminals on the front • Cable terminals on the front • Rear terminals	<i>I I</i>	/ /	 ✓	/ /	<i>y y y</i>	/ /	 <i>y</i>	/ /	/ /				
Pages	7/69, 7/70												

## Pages

- ✓ Has this function or can use this accessory
- -- Does not have this function or cannot use this accessory

For overload protection of the motors, appropriate overload relays must be used.

Introduction



Type		3RU21	3RB30	3RB31
SIRIUS overload relays				
Applications				
System protection		<b>√</b> 1)	<b>√</b> 1)	<b>✓</b> <sup>1)</sup>
Motor protection		✓	✓	✓
Alternating current, three-phase		✓	✓	✓
Alternating current, single-phase		✓		
Direct current		✓		
Size contactor		S00, S0, S2, S3	S00, S0, S2, S3	S00, S0, S2, S3
Rated operational current $I_e$				
• Size S00	Α	Up to 16	Up to 16	Up to 16
• Size S0	Α	Up to 40	Up to 40	Up to 40
• Size S2	Α	Up to 80	Up to 80	Up to 80
• Size S3	Α	Up to 100	Up to 115	Up to 115
Rated operational voltage $U_{\rm e}$	V	690 AC	690 AC	690 AC
Rated frequency	Hz	50/60	50/60	50/60
Trip class		CLASS 10, 10A	CLASS 10E, 20E	CLASS 5E, 10E, 20E, 30E (adjustable)
Thermal overload releases	A A	0.11 0.16 to 80 100		-
Electronic overload releases	A A		0.1 0.4 to 32 115	0.1 0.4 to 32 115
Pages		7/84 7/87	7/97, 7/98	7/99


Accessories												
For sizes	S00	S0	S2	S3	S00	S0	S2	S3	S00	S0	S2	S3
Terminal supports for stand-alone installation	✓	✓	1	1	✓	1	1	1	1	✓	1	1
Mechanical RESET	1	1	1	1	1	1	1	1	1	1	1	✓
Cable releases for RESET	1	1	1	1	1	1	1	1	1	1	1	✓
Electrical remote RESET	1	1	1	1					Integra	ted in th	e unit	
Terminal covers												
• For box terminals			1	1			1	1			✓	✓
Sealable covers for setting knobs	1	1	1	1	1	1	1	1	1	1	/	✓
Pages	7/88, 7/	/89			7/100,	7/101			7/100,	7/101		

<sup>✓</sup> Has this function or can use this accessory

<sup>--</sup> Does not have this function or cannot use this accessory

<sup>1)</sup> The units are responsible in the main circuit for overload protection of the assigned electrical loads (e.g. motors), feeder cable, and other switching and protection devices in the respective load feeder.

### Introduction



7/112, 7/113

✓ Has this function or can use this accessory

Operator panel for 3RB24 evaluation

-- Does not have this function or cannot use this accessory

7/112, 7/113

- 1) The units are responsible in the main circuit for overload protection of the assigned electrical loads (e.g. motors), feeder cable, and other switching and protection devices in the respective load feeder.
- <sup>2)</sup> With reference to the 3RB29.6 current measuring modules.
- 3) Stand-alone installation without accessories is possible.

. 7/134

7/132

**Pages** 

## \_

## Motor Starter Protectors/Circuit Breakers SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers

General data

### Overview

#### More information

Home page, see www.siemens.com/sirius-circuit-breaker Industry Mall, see www.siemens.com/product?3RV2 Conversion tool, e.g. from 3RV1 to 3RV2, see

The following illustration shows 3RV2 motor starter protectors/circuit breakers with the accessories which can be mounted for the sizes S00 to S3, see also "Introduction" → "Overview",


Application Manual "SIRIUS Controls with IE3/IE4 Motors", see https://support.industry.siemens.com/cs/ww/en/view/94770820

System Manual "SIRIUS – System Overview", see https://support.industry.siemens.com/cs/ww/en/view/60311318

Manual "SIRIUS – SIRIUS 3RV2 Motor Starter Protectors", see https://support.industry.siemens.com/cs/ww/en/view/60279172

Certificates, see https://support.industry.siemens.com/cs/ww/en/ps/16245/cert

Accessories, see page 7/37 onwards.



Mountable accessories for SIRIUS 3RV2 motor starter protectors/circuit breakers



SIRIUS motor starter protector with spring-type terminals, size S0 (left) and SIRIUS motor starter protector with screw terminals, size S00 (right)

The SIRIUS 3RV2 motor starter protectors/circuit breakers are compact, current limiting motor starter protectors/circuit breakers which are optimized for load feeders. The motor starter protectors/circuit breakers are used for switching and protecting three-phase motors of up to 55/45 kW at 400 V AC and for other loads with rated currents of up to 100 A.

The new 3RV2 motor starter protectors/circuit breakers are usually approved according to IEC and UL/CSA. According to UL 508/UL 60947-4-1, the 3RV2 motor starter protectors/circuit breakers in sizes S00 to S3 are approved as:

- "Manual Motor Controllers"
- "Manual Motor Controllers" for "Group Installations"
- "Manual Motor Controllers Suitable for Tab Conductor Protection in Group Installations"
- "Self-Protected Combination Motor Controllers (Type E)"
   Please note that for this approval the 3RV20 motor starter protectors must be equipped with additional infeed terminals or phase barriers. For more information, see "Accessories" on page 7/45.

Corresponding short-circuit values, see pages 7/10 to 7/16.

The 3RV27 and 3RV28 are approved as circuit breakers according to UL 489; they are a special version of the 3RV2 motor starter protectors.

#### SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers

### General data

#### Type of construction

The 3RV2 motor starter protectors are available in four sizes:

- Size S00 width 45 mm, max. rated current 16 A, at 400 V AC suitable for three-phase motors up to 7.5 kW
- Size S0 width 45 mm, max. rated current 40 A, at 400 V AC suitable for three-phase motors up to 18.5 kW
- Size S2 width 55 mm, max. rated current 80 A, at 400 V AC suitable for three-phase motors up to 37 kW
- Size S3 width 70 mm, max. rated current 100 A, at 400 V AC suitable for three-phase motors up to 45/55 kW


#### Circuit breakers acc. to UL 489

The 3RV27 and 3RV28 circuit breakers are available in two or three sizes:

- Size S00 width 45 mm, max. rated current 15 A, at 480 Y/277 V AC
- Size S0 width 45 mm, max. rated current 22 A, at 480 Y/277 V AC
- Size S3 width 70 mm, max. rated current 70 A, at 480 Y/277 V AC

#### Connection methods

The 3RV2 motor starter protectors/circuit breakers can be supplied with screw terminals and spring-type terminals.



The terminals are indicated in the corresponding tables by the symbols shown on orange backgrounds.

#### Use in hazardous areas

The 3RV20 motor starter protectors for motor protection in sizes S00 and S0 have certification in accordance with both the European explosion protection directive ATEX and the international explosion protection standard (IECEx). Size S3 available on request.

In accordance with the European directive (ATEX), the 3RV20 are able to switch and protect explosion-proof motors of type of protection "Increased Safety EEx e".

In accordance with the international guideline (IECEx), the 3RV20 are able to switch and protect motors of the types "Increased Safety Ex e" or "Flameproof enclosure Ex d"

#### Article No. scheme

Product versions		Article number			
Motor starter protectors/circuit	breakers	3RV2 □ □ □ -		<b>–</b>	
Type of motor starter protector/circuit breaker	e. g. 0 = for motor protection/system protection				
Size	e. g. 1 = 16 A (7.5 kW) for size S00				
Breaking capacity	e. g. 1 = standard switching capacity				
Setting range for overload release	e e. g. 1A = 1.1 1.6 A				
Trip class (CLASS)	e.g. A = a (adjustable CLASS 10) / n (13 or 20 x $I_{ m n}$ )				
Connection methods	e. g. 1 = screw terminals				
With or without auxiliary switch	e. g. 0 = without				
Special versions					
Example		3RV2 0 1 1 -	1 A A 1	0	

#### Note:


The Article No. scheme shows an overview of product versions for better understanding of the logic behind the article numbers.

For your orders please use the article numbers quoted in the selection and ordering data.

General data

### Benefits

#### Advantages through energy efficiency



Overview of the energy management process

We offer you a unique portfolio for industrial energy management, using an energy management system that helps to optimally define your energy needs. We split up our industrial energy management into three phases – identify, evaluate, and realize – and we support you with the appropriate hardware and software solutions in every process phase.

The innovative products of the SIRIUS industrial controls portfolio can also make a substantial contribution to a plant's energy efficiency (see www.siemens.com/sirius/energysaving).

3RV2 motor starter protectors/circuit breaker contribute to energy efficiency throughout the plant as follows:

- Minimization of energy losses through optimization of the bimetal trip units
- Reduction of inherent power loss
- · Less heating of the control cabinet
- Smaller control cabinet air conditioners can be used

## Application

#### Operating conditions

3RV2 motor starter protectors/circuit breakers are suitable for use in any climate. They are intended for use in enclosed rooms in which no severe operating conditions (such as dust, caustic vapors, hazardous gases) prevail. When installed in dusty and damp areas, suitable enclosures must be provided.

3RV2 motor starter protectors/circuit breakers can optionally be fed from the top or from below.

The permissible ambient temperatures, the maximum switching capacities, the tripping currents and other boundary conditions can be found in the technical specifications and tripping characteristics, see Manual.

3RV2 motor starter protectors/circuit breakers are suitable for operation in IT systems (IT networks). In this case, the different short-circuit breaking capacity in the IT system must be taken into account, see page 7/12.

Since operational currents, starting currents and current peaks are different even for motors with identical power ratings due to the inrush current, the motor ratings in the selection tables are only guide values. The specific rated and startup data of the motor to be protected is always paramount to the choice of the most suitable motor starter protector/circuit breaker. This also applies to motor starter protectors for transformer protection.

#### Possible uses

The 3RV motor starter protectors/circuit breakers can be used:

- For short-circuit protection
- For motor protection (also with overload relay function)
- For system protection
- For short-circuit protection for starter combinations
- For transformer protection
- As main and EMERGENCY-STOP switches
- For operation in IT systems (IT networks)
- · For switching of DC currents
- In areas subject to explosion hazard (ATEX)
- As circuit breakers according to UL 489 (3RV27 and 3RV28)
- For fuse monitoring
- For distance protection

## Use of SIRIUS protection devices in conjunction with IE3/IE4 motors

#### Note

For the use of 3RV2 motor starter protectors/circuit breakers in conjunction with highly energy-efficient IE3/IE4 motors, please observe the information on dimensioning and configuring, see Application Manual.

For more information, see Preface on page 7.

## General data

#### Technical specifications

#### More information

System Manual "SIRIUS – System Overview", see https://support.industry.siemens.com/cs/ww/en/view/60311318

Configuration manual "Configuring SIRIUS Innovations – Selection Data for Fuseless and Fused Load Feeders", see https://support.industry.siemens.com/cs/ww/en/view/39714188

Manual "SIRIUS – SIRIUS 3RV2 Motor Starter Protectors", see https://support.industry.siemens.com/cs/ww/en/view/60279172

Technical specifications, see

https://support.industry.siemens.com/cs/ww/en/ps/16245/td

UL reports of the individual devices, see www.siemens.com/sirius/manuals

#### Short-circuit breaking capacity $I_{\rm cu}$ , $I_{\rm cs}$ according to IEC 60947-2

The table shows the rated ultimate short-circuit breaking capacity  $I_{\rm Cu}$  and the rated service short-circuit breaking capacity  $I_{\rm CS}$  of the 3RV2 motor starter protectors/circuit breakers with different operating voltages dependent on the rated current  $I_{\rm n}$  of the motor starter protectors/circuit breakers.

Power can be supplied to the motor starter protectors/circuit breakers via the terminals at the top or at the bottom without restricting the rated data. If the short-circuit current at the place of installation exceeds the rated short-circuit breaking capacity of the motor starter protector/circuit breaker as specified in the table, a back-up fuse is required. It is also possible to install an

upstream motor starter protector/circuit breaker with a limiter function

The maximum rated current of this back-up fuse is indicated in the tables. The rated ultimate short-circuit breaking capacity then applies as specified on the fuse.

#### Fuseless design

Motor starter protector/contactor assemblies for short-circuit currents up to 150 kA can be ordered as 3RA2 fuseless load feeders, see page 8/4 onwards.

Motor starter protectors /	Rated current $I_n$	Up to	240 \	/ AC <sup>1)</sup>	Up to	400 \ / AC <sup>2)</sup>	/ AC <sup>1)</sup> /	Up to 460 \	440 \ / AC <sup>2)</sup>	/ AC <sup>1)</sup> /	Up to 500 V AC <sup>1)</sup> / 525 V AC <sup>2)</sup>			Up to 690 V AC <sup>1)</sup>		
circuit breakers		$I_{\mathrm{CU}}$	$I_{\rm CS}$	Max. fuse (gG)	$I_{\mathrm{CU}}$	$I_{\mathrm{CS}}$	Max. fuse (gG) <sup>3)</sup>	$I_{\mathrm{CU}}$	$I_{\mathrm{CS}}$	Max. fuse (gG) <sup>3)</sup>	$I_{ m CU}$	$I_{ t CS}$	Max. fuse (gG) <sup>3)</sup>	$I_{\mathrm{CU}}$	$I_{\mathrm{CS}}$	Max. fuse (gG) <sup>3)4)</sup>
Туре	Α	kA	kA	Α	kA	kA	Α	kA	kA	Α	kA	kA	Α	kA	kA	Α
Size S00																
3RV2.11	0.16 1.6 2; 2.5 3.2	100 100 100	100 100 100	  	100 100 100	100 100 100	  	100 100 100	100 100 100	  	100 100 100	100 100 100	  	100 10 10	100 10 10	 25 32
	4; 5 6.3 8	100 100 100	100 100 100	  	100 100 100	100 100 100	  	100 100 50	100 100 50	  63	100 100 42	100 100 42	  63	6 6 6	4 4 4	32 50 50
	10 12.5 16	100 100 100	100 100 100	  	100 100 55	100 100 30	  100	50 50 50	50 50 12.5	80 80 80	42 42 10	42 42 5	63 80 80	6 6 4	4 4 4	50 63 63
3RV1611-0BD10	0.2	100	100		100	100		100	100		100	100		100	100	
Size S0																
3RV2.21	0.16 1.6 2; 2.5 3.2	100 100 100	100 100 100	  	100 100 100	100 100 100	  	100 100 100	100 100 100	  	100 100 100	100 100 100	  	100 10 10	100 10 10	 25 32
	4; 5 6.3 8	100 100 100	100 100 100	  	100 100 100	100 100 100	  	100 100 50	100 100 50	  63	100 100 42	100 100 42	  63	6 6 6	4 4 4	32 50 50
	10 12.5 16	100 100 100	100 100 100	  	100 100 55	100 100 25	  100	50 50 50	50 50 12.5	80 80 80	42 42 10	42 42 5	63 80 80	6 6 4	4 4 2	50 63 63
	20 22; 25 28; 32 36; 40	100 100 100 100	100 100 100 100	  	55 55 55 20	25 25 25 10	125 125 125 125	50 50 30 12	10 10 10 8	80 100 125 125	10 10 10 6	5 5 5 3	80 80 100 100	4 4 4 3	2 2 2 2	63 63 100 100

<sup>--</sup> No back-up fuse required, since short-circuit resistant up to 100 kA

<sup>1) 10 %</sup> overvoltage.

<sup>2) 5 %</sup> overvoltage.

 $<sup>^{3)}</sup>$  Back-up fuse only required if short-circuit current at the place of installation is  $>I_{\rm cu}.$ 

<sup>&</sup>lt;sup>4)</sup> Alternatively, fuseless limiter combinations for 690 V AC can also be used.

Motor starter protectors/	Rated current $I_n$	Up to	240 \	/ AC <sup>1)</sup>	Up to 415 \	400 \ / AC <sup>2)</sup>	/ AC <sup>1)</sup> /		440 V / AC <sup>2)</sup>	/ AC <sup>1)</sup> /	Up to 500 V AC <sup>1)</sup> / 525 V AC <sup>2)</sup>			Up to 690 V AC <sup>1)</sup>		
circuit breakers		$I_{\mathrm{CU}}$	$I_{\mathrm{CS}}$	Max. fuse (gG)	$I_{\mathrm{CU}}$	$I_{\mathrm{CS}}$	Max. fuse (gG) <sup>3)</sup>	$I_{\mathrm{CU}}$	$I_{\mathrm{CS}}$	Max. fuse (gG) <sup>3)</sup>	$I_{\mathrm{CU}}$	$I_{\mathrm{CS}}$	Max. fuse (gG) <sup>3)</sup>	$I_{\mathrm{CU}}$	$I_{\mathrm{CS}}$	Max. fuse (gG) <sup>3)4)</sup>
Type	Α	kA	kA	А	kA	kA	Α	kA	kA	А	kA	kA	А	kA	kA	А
Size S2																
3RV2.31	14; 17 20 25	100 100 100	100 100 100	  	65 65 65	30 30 30	100 100 100	50 50 50	25 25 15	100 100 100	12 12 12	6 6 6	63 80 80	5 5 5	3 3 3	63 80 80
	32; 36 40; 45 52	100 100 100	100 100 100	  	65 65 65	30 30 30	125 160 160	50 50 50	15 15 15	125 125 125	10 10 10	5 5 5	100 100 125	4 4 4	2 2 2	100 100 125
	59; 65 73; 80	100 100	100 100		65 65	30 30	160 200	50 50	15 15	160 200	8 8	4 4	125 160	4	2	125 125
Size S2, with inc switching capac																
3RV2.32	14; 17 20; 25 32 45 52 59; 65 73: 80	100 100 100 100 100	100 100 100 100 100	   	100 100 100 100 100	50 50 50 50 50	   	65 65 65 65 50	30 30 30 30 15	100 100 125 125 160 200	18 18 15 15 10	10 10 8 8 5	63 80 100 125 125 160	8 8 6 6 6 6 6 6 6 6 6 6 6 6 6 6 6 6 6 6	5 5 4 4 4	63 80 100 125 125 125
Size S3	73, 60	100	100		100	30		30	13	200	10	J	100	U	4	123
3RV2.41	40 100	On re	equest													
Size S3, with inc switching capac	city															
3RV2.42/ 3RV2742	<b>5)</b> 40 100	On re	equest													

<sup>--</sup> No back-up fuse required, since short-circuit resistant up to 100 kA

<sup>1) 10 %</sup> overvoltage.

<sup>&</sup>lt;sup>2)</sup> 5 % overvoltage.

<sup>3)</sup> Back-up fuse only required if short-circuit current at the place of installation

Alternatively, fuseless limiter combinations for 690 V AC can also be used.
 The values for the 3RV2742 circuit breakers have been tested only up to 400 V/415 V AC.

#### SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers

### General data

### Short-circuit breaking capacity $I_{\text{culT}}$ in the IT system (IT network) according to IEC 60947-2

3RV2 motor starter protectors/circuit breakers are suitable for use in IT systems. The values of  $I_{\rm Cu}$  and  $I_{\rm Cs}$  apply for the three-pole short circuit. In the case of a double ground fault in different phases at the input and output side of a motor starter protector/circuit breaker, the special short-circuit breaking capacity  $I_{\rm culT}$  applies. The specifications in the table below apply to 3RV2 motor starter protectors/circuit breakers.

If the short-circuit current at the place of installation exceeds the motor starter protector/circuit breaker's specified rated short-circuit breaking capacity, you will need to use a back-up fuse. The maximum rated current of this back-up fuse is indicated in the tables. The rated short-circuit breaking capacity then applies as specified on the fuse.

Motor starter protectors/	Rated current I <sub>n</sub>	Up to 24	40 V AC <sup>1)</sup>	Up to 400 415 V AC	V AC <sup>1)</sup> /	Up to 440 460 V AC <sup>2</sup>	V AC <sup>1)</sup> /	Up to 50 525 V A	0 V AC <sup>1)</sup> /	Up to 6	690 V AC <sup>1)5)</sup> Max. fuse
circuit breakers		$I_{CulT}$	Max. fuse (gG) <sup>3)</sup>	$I_{culT}$	Max. fuse (gG) <sup>3)4)</sup>	$I_{culT}$	Max. fuse (gG) <sup>3)</sup>	$I_{culT}$	Max. fuse (gG) <sup>3)</sup>	Cult	Max. fuse (gG) <sup>3)</sup>
Type	Α	kA	А	kA	Α	kA	Α	kA	А	kA	А
Size S00											
3RV2.11	0.16 0.4 0.5 0.63; 0.8	100 100 100	  	100 100 100	  	100 100 100	 	100 100 100	  	100 0.5 0.5	 4 6
	1 1.25 1.6	100 100 100	 	100 100 100	  	2 2 2	10 16 20	2 2 2	10 16 20	1.5 1.5 1.5	10 16 16
	2; 2.5 3.2 4; 5	100 100 100	  	8 8 4	25 32 32	2 2 1.5	25 32 32	2 2 1.5	25 32 32	1.5 1.5 1.5	20 25 25
	6.3; 8 10 12.5 16	100 100 100 55	  80	4 4 4	50 50 63 63	1 1 1 1	40 40 50 50	1 1 1 1	40 40 50 50	1 1 1 1	35 40 40 40
3RV1611-0BD10	0.2	100		100				100		100	
Size S0											
3RV2.21	0.16 0.4 0.5 0.63; 0.8	100 100 100	 	100 100 100	  	100 100 100	 	100 100 100	  	100 0.5 0.5	 4 6
	1 1.25 1.6	100 100 100	 	100 100 100	  	2 2 2	10 16 20	2 2 2	10 16 20	1.5 1.5 1.5	10 16 16
	2; 2.5 3.2 4; 5	100 100 100	  	8 8 4	25 32 32	2 2 1.5	25 32 32	2 2 1.5	25 32 32	1.5 1.5 1.5	20 25 25
	6.3; 8 10 12.5	100 100 100	  	4 4 4	50 50 63	1 1 1	40 40 50	1 1 1	40 40 50	1 1 1	35 40 40
	16 20 25 28; 32 36; 40	55 55 55 20	80 80 80 80	4 4 2 2	63 63 63	1 1 1 1	50 50 63 63	1 1 1 1	50 50 63 63	1 1 1 1	40 50 63 63

<sup>--</sup> No back-up fuse required, since short-circuit resistant up to 100 kA

<sup>1) 5 %</sup> overvoltage.

<sup>2)</sup> Without overvoltage.

 $<sup>^{3)}</sup>$  Back-up fuse only required if short-circuit current at installation location is  $>\!I_{\rm culT}\!.$ 

<sup>4)</sup> Alternatively, fuseless limiter combinations for 690 V AC can also be used.

<sup>5)</sup> Overvoltage category II applies for applications in IT systems > 600 V.

General data

Motor starter	Rated current $I_n$	Up to 2	40 V AC <sup>1)</sup>	Up to 400 415 V AC <sup>2</sup>	V AC1)/	Up to 440 460 V AC <sup>2</sup>		Up to 50 525 V AG	0 V AC1)/	Up to 6	590 V AC1)5
protectors/ circuit breakers		$I_{CulT}$	Max. fuse (gG) <sup>3)</sup>	I <sub>culT</sub>	Max. fuse (gG) <sup>3)4)</sup>	Lault	Max. fuse (gG) <sup>3)</sup>	I <sub>CUIT</sub>	Max. fuse (gG) <sup>3)</sup>	$I_{culT}$	Max. fuse (gG) <sup>3)</sup>
Туре	Α	kA	A	kA	A	kA	A	kA	A	kA	Α
Size S2											
3RV2031, 3RV2131, 3RV2331	14 25 32 45 52 80	100 100 100	  	8 6 4	100 125 160	6 4 3	80 100 125	6 4 3	80 100 125	4 3 2	63 80 100
Size S2, with increasure switching capacity	ased										
3RV2032, 3RV2332	14 25 32 45 52 59 80	100 100 100 100	  	8 6 6	100 125 160 160	6 6 6 4	80 100 125 125	6 6 6 4	80 100 125 125	4 4 4 4	63 80 100 100
Size S3											
3RV2.41	40 100	On requ	est								
Size S3, with increasure switching capacity											
3RV2.42	40 100	On requ	est								

<sup>--</sup> No back-up fuse required, since short-circuit resistant up to 100 kA

## Limiter function with standard devices for 500 V AC and 690 V AC according to IEC 60947-2

The table shows the rated ultimate short-circuit breaking capacity  $I_{\rm Cu}$  and the rated service short-circuit breaking capacity  $I_{\rm CS}$  with an upstream standard motor starter protector/circuit breaker that fulfills the limiter function at voltages 500 V AC and 690 V AC.

The short-circuit breaking capacity can be increased significantly with an upstream standard motor starter protector/circuit breaker with limiter function. The motor starter protector/circuit

breaker which is connected downstream must be set to the rated current of the load.

With motor starter protector/circuit breaker assemblies, note the clearance to grounded parts and between the motor starter protectors/circuit breaker. Short-circuit proof wiring between the motor starter protectors/circuit breaker must be ensured. The motor starter protectors/circuit breakers can be mounted side by side in a modular arrangement.

Standard motor s	starter protectors/circuit breakers	Rated current I <sub>n</sub>	Up to 500 V AC1)/5	525 V AC <sup>2)</sup>	Up to 690 V AC <sup>1)</sup>	
	With limiter Rated current In		$I_{ extsf{CU}}$	$I_{ t CS}$	$I_{ extsf{CU}}$	$I_{ t CS}$
Туре	Туре	А	kA	kA	kA	kA
Size S00						
3RV2011	Size S0: 3RV2321-4EC10	2 6.3 8	 100	 50	50 20	25 10
	$I_{n} = 32 \text{ A}$	10 16	100	50	20 <sup>3)</sup>	10 <sup>3)</sup>
	Size S2: 3RV2331-4WC10	10 16	<del></del>		50	25
	$I_{n} = 52 \text{ A}$					
Size S0						
3RV2021	Size S0: 3RV2321-4EC10	16 32	100	50	20 <sup>3)</sup>	10 <sup>3)</sup>
	$I_{n} = 32 \text{ A}$					
	Size S2: 3RV2331-4WC10	16 32			50	20
	$I_{\rm n} = 52 \ {\rm A}$					
Size S2, with ir	ncreased switching capacity					
3RV2032	Size S2: 3RV2332-4RC10	14 80	100	50	70	35
	$I_{\cap} = 80 \text{ A}$					
Size S3, with ir	ncreased switching capacity					
3RV2042		40 100	On request			

<sup>--</sup> No limiter required

<sup>1) 10 %</sup> overvoltage.

<sup>&</sup>lt;sup>2)</sup> 5 % overvoltage.

 $<sup>^{3)}</sup>$  Back-up fuse only required if short-circuit current at installation location is  $>\!I_{\rm culT}\!.$ 

<sup>4)</sup> Alternatively, fuseless limiter combinations for 690 V AC can also be used.

 $<sup>^{5)}</sup>$  Overvoltage category II applies for applications in IT systems > 600 V.

<sup>1) 10 %</sup> overvoltage.

<sup>&</sup>lt;sup>2)</sup> 5 % overvoltage.

<sup>3)</sup> Infeed to the limiter is always on the side 1L1/3L2/5L3.

#### SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers

### General data

#### Permissible rated data of devices approved for North America (UL/CSA)

Motor starter protectors of the 3RV2 series are approved for UL/CSA, and according to UL 508/UL 60947-4-1 and CSA C22.2 No. 14/CSA C22.2 No. 60947-4-1 they can be used on their own or as load feeders in combination with a contactor.

These motor starter protectors/circuit breakers can be used as "Manual Motor Controllers" for "Group Installations", as "Manual Motor Controllers Suitable for Tap Conductor Protection in Group Installations" and as "Self-Protected Combination Motor Controllers" (Type E).

#### 3RV2 motor starter protectors as "Manual Motor Controllers"

If used as a "Manual Motor Controller", the motor starter protector is always operated in combination with an upstream short-circuit protection device. Approved fuses or a circuit breaker according to UL 489/CSA C22.2 No. 5 may be used for this purpose. These devices must be dimensioned according to the National Electrical Code (UL) or Canadian Electrical Code (CSA).

The file numbers for the approval of the 3RV2 as a Manual Motor Controller are as follows:

- UL File No. 47705, CCN: NLRV
- CSA Master Contract 165071, Product Class: 3211

Motor starter protect	tors/	hp rating <sup>1</sup>	) for FLA <sup>2)</sup>	Rated current	240 V AC		480 V AC		600 V AC	
circuit breakers		max.		$I_{n}$	UL $I_{\rm bc}^{(3)}$	CSA $I_{bc}^{3)}$	UL $I_{bc}^{(3)}$	CSA $I_{bc}^{3)}$	UL $I_{bc}^{(3)}$	CSA $I_{\rm bc}^{3)}$
Туре	V	Single- phase	3-phase	А	kA	kA	kA	kA	kA	kA
Size S00										
3RV2011, 3RV2111,	3RV2311, 3R\	/2411		0.16 12.5 16	65 65	65 65	65 65	65 65	30	30
FLA <sup>2)</sup> max. 16 A, 480 V 12.5 A, 600 V	115 200 230 460 575/600	1 2 2 	2 3 5 10 10							
3RV1611-0BD10				0.2	65	65	65	65	10	10
Size S0										
3RV2021, 3RV2121,	•			0.16 12.5 16 25	65 65	65 65	65 65	65 65	30 /(30) <sup>4)</sup>	30 /(30) <sup>4)</sup>
FLA <sup>2)</sup> max. 40 A, 480 V 12.5 A, 600 V	115 200 230 460 575/600	3 5 7 1/2 	5 10 10 30	28, 32 36, 40	65 65	65 65	50 12	50 12		
Size S2										
3RV2031, 3RV2331				14 36 40 52	65 65	65 65	65 65	65 65	25 22	25 22
FLA <sup>2)</sup> max. 80 A, 600 V	115/120 200/208 230/240 460/480 575/600	7.5 15 15  	10 25 30 60 75	59 65 73 80	65 65	65 65	65 <sup>5)</sup> 65 <sup>5)</sup>	65 <sup>5</sup> 65 <sup>5)</sup>	22 20 <sup>5</sup> 20 <sup>5</sup>	22 20 <sup>5</sup> 20 <sup>5</sup>
Size S2, with incr	eased swite	ching capa	city							
3RV2032, 3RV2332				14 36 40 52	100 100	100 100	100 100	100 100	25 22	25 22
FLA <sup>2)</sup> max. 80 A, 600 V	115/120 200/208 230/240 460/480 575/600	7.5 15 15 	10 25 30 60 75	59 65 73 80	100	100	100 <sup>5)</sup> 100 <sup>5)</sup>	100 <sup>5)</sup> 100 <sup>5)</sup>	25 <sup>5)</sup> 25 <sup>5)</sup>	22 25 <sup>5)</sup> 25 <sup>5)</sup>

## Size S3 available on request

<sup>--</sup> No approval

<sup>1)</sup> hp rating = Power rating in horse power (maximum motor rating).

<sup>2)</sup> FLA = Full Load Amps/motor full load current.

<sup>3)</sup> Corresponds to "short-circuit breaking capacity" according to UL/CSA.

<sup>&</sup>lt;sup>4)</sup> Values in brackets only apply to 3RV2.23 motor starter protectors.

<sup>5)</sup> With Class J fuse.

General data

3RV20 motor starter protectors (up to 100 A) as "Manual Motor Controller Suitable for Tap Conductor Protection in Group Installations"

The application as "Manual Motor Controllers Suitable for Tap Conductor Protection in Group Installations" is only available for UL. CSA does not recognize this approval! When the motor starter protector is used as a "Manual Motor Controller Suitable for Tap Conductor Protection in Group Installations", it must always be combined with upstream short-circuit protection. Approved fuses or a circuit breaker according to UL 489 may be used for this purpose. These devices must be dimensioned according to the National Electrical Code.

The 3RV20 motor starter protectors are approved as "Manual Motor Controllers Suitable for Tap Conductor Protection in Group Installations" under the following file number:

• UL File No. 47705, CCN: NLRV

Motor starter protection circuit breakers	ctors/	hp rating <sup>1)</sup> max.	for FLA <sup>2)</sup>	Rated current I <sub>n</sub>	<b>240 V AC</b> UL <i>I</i> <sub>bc</sub> <sup>3)</sup>	<b>480 Y/277 V AC</b> UL $I_{ m bc}{}^{3)}$	<b>600 Y/347 V AC</b> UL $I_{\rm bc}{}^{3)}$
Туре	V	Single- phase	3-phase	А	kA	kA	kA
Size S00							
3RV2011				0.16 12.5 16	65 65	65 65	30
FLA <sup>2)</sup> max. 16 A, 480 V 12.5 A, 600 V	115 200 230 460 575/600	1 2 2 	2 3 5 10	10	00	65	
Size S0							
<b>3RV2021</b> FLA <sup>2)</sup> max. 32 A, 480 V 12.5 A, 600 V	115 200 230 460 575/600	2 3 5 	5 7.5 10 20	0.16 12.5 16 25 28; 32	65 65 50	65 65 50	30  
Size S2							
<b>3RV2031</b> FLA <sup>2)</sup> max. 80 A, 480 V 52 A, 600 V	115/120 200/208 230/240 460/480 575/600	7.5 15 15 	10 25 30 60 75	14 36 40 52 59 65 73 80	65 65 65 65 65	65 65 30 20 10	25 22   
Size S2, with inc	reased swit	ching capa	city				
<b>3RV2032</b> FLA <sup>2)</sup> max. 80 A, 480 V 52 A, 600 V  Size S3 available	115/120 200/208 230/240 460/480 575/600	7.5 15 15  	10 25 30 60 75	14 36 40 52 59 65 73 80	100 100 100 100 100	100 100 42 30 10	25 22   

<sup>--</sup> No approval

<sup>1)</sup> hp rating = Power rating in horse power (maximum motor rating).

<sup>2)</sup> FLA = Full Load Amps/motor full load current.

<sup>3)</sup> Corresponds to "short-circuit breaking capacity" according to UL.

#### SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers

### General data

3RV20 motor starter protectors (up to 100 A) as "Self-Protected Combination Motor Controller (Type E)"

UL 508/UL 60947-4-1 approval demands 1-inch through air spacing and 2-inch over surface spacing at line side for "Self-Protected Combination Motor Controller Type E".

Therefore, 3RV20 motor starter protectors of sizes S00 to S3 are approved according to UL 508/UL 60947-4-1 in combination with the terminal blocks listed below.

CSA does not require these extended clearances. According to CSA, these terminal blocks can be omitted when the device is used as a "Self-Protected Combination Motor Controller".

The 3RV20 motor starter protectors are approved as "Self-Protected Combination Motor Controllers" under the following file numbers:

- UL File No. E156943, CCN: NKJH
- CSA Master Contract 165071, Product Class: 3211 08

Motor starter pro circuit breakers	otectors/	hp rating <sup>1</sup> max.	) for FLA <sup>2)</sup>	Rated current In	<b>Up to 240 V</b> UL	V <b>AC</b> CSA	<b>Up to 480 \</b> UL	<b>7/277 V AC</b> CSA	Up to 600 Y	<b>Y/347 V AC</b> CSA
Туре	V	Single- phase	3-phase	A	$I_{\rm bc}^{(3)}$ kA	$I_{\rm bc}^{(3)}$ kA	I <sub>bc</sub> <sup>3)</sup> kA	$I_{\rm bc}^{(3)}$	$I_{\rm bc}^{(3)}$ kA	I <sub>bc</sub> <sup>3)</sup> kA
Size S00										
3RV2011 + 3RV2	928-1H <sup>4)5)</sup>			0.16 12.5 16	65 65	65 65	65 65	65 65	30	30
FLA <sup>2)</sup> max. 16 A, 480 V; 12.5 A, 600 V	115 200 230 460 575/600	1 2 2 	2 3 5 10 10							
Size S0										
3RV2021 + 3RV2	928-1H <sup>4)5)</sup>			0.16 12.5 16 25	65 65	65 65	65 65	65 65	30 	30
FLA <sup>2)</sup> max. 32 A, 480 V 12.5 A, 600 V	115 200 230 460 575/600	2 3 5 	5 7.5 10 20 	28; 32	50	50	50	50		
Size S2										
3RV2031+ 3RV29				14 36 40 52	65 65	65 65	65 65	65 65	25 22	25 22
FLA <sup>2)</sup> max. 73 A, 480 V 52 A, 600 V	115/120 200/208 230/240 460/480 575/600	7.5 15 15  	10 25 30 60 75	59 73	65	65	20	20		
Size S2, with i	ncreased swi	tching cap	pacity							
<b>3RV2032 + 3RV2</b> 9 FLA <sup>2)</sup> max.	938-1K <sup>4)</sup>	7.5	10	14 36 40 52 59 73	100 100 100	100 100 100	100 100 30	100 100 30	25 22 	25 22 
73 A, 480 V 52 A, 600 V	200/208 230/240 460/480 575/600	15 15 	25 30 60 75							

#### Size S3 available on request

- 1) hp rating = Power rating in horse power (maximum motor rating).
- 2) FLA = Full Load Amps/motor full load current.

## 3RV27 and 3RV28 motor starter protectors as "circuit breakers"

These motor starter protectors are approved as circuit breakers according to UL 489 and CSA C22.2 No. 5. They can be used therefore as upstream short-circuit protective devices for "Manual Motor Controllers" and "Manual Motor Controllers Suitable for Tap Conductor Protection in Group Installations".

3RV27 and 3RV28 motor starter protectors are approved as "circuit breakers" under the following file numbers:

- UL File No. E235044, CCN: DIVQ
- CSA Master Contract 165071, Product Class: 1432 01

Motor starter	Rated current I <sub>n</sub>	240 V A	2	480 Y/27	7 V AC	480 V AC	;	600 Y/34	17 V AC
protectors/ circuit breakers		UL	CSA	UL	CSA	UL	CSA	UL	CSA
on out breakers		$I_{bc1)}$	$I_{bc1)}$	$I_{bc1)}$	$I_{bc1)}$	$I_{\text{bc1})}$	$I_{bc1)}$	$I_{\text{bc1}}$	$I_{bc1)}$
Туре	Α	kA	kA	kA	kA	kA	kA	kA	kA
Size S00									
3RV2711	0.16 12.5 15	65 65	65 65	65 65	65 65			10	10
3RV2811	0.16 12.5 15	65 65	65 65	65 65	65 65			10	10
Size S0									
3RV2721	20; 22	50	50	50	50				
3RV2821	20; 22	50	50	50	50				
Size S3 available	e on request								

<sup>3)</sup> Corresponds to "short-circuit breaking capacity" according to UL/CSA.

<sup>4)</sup> Not required for CSA.

<sup>5)</sup> Alternatively phase barrier 3RV2928-1K can be used.

<sup>1)</sup> Corresponds to "short-circuit breaking capacity" according to UL.

General data							
Туре			3RV2.1.	3RV2.2.	3RV2.3.	3RV2.4.	3RV27, 3RV28
Size	1 ■   ■		S00	S0	S2	S3	S00, S0
Dimensions (W x H x D)  • Screw terminals		mm	45 x 97 x 91	45 x 97 x 91	55 x 140 x 149	70 x 165 x 169	45 x 144 x 92
Spring-type terminals	l w l y v	mm	45 x 106 x 91	45 x 119 x 91			
<b>Standards</b> • IEC 60947-1, EN 60947-1 (VDE	0660 Part 100)		Yes				
• IEC 60947-2, EN 60947-2 (VDE	0660 Part 101)		Yes				
<ul> <li>IEC 60947-4-1, EN 60947-4-1 (V</li> <li>UL 508/UL 60947-4-1.</li> </ul>	'DE 0660 Part 102)		Yes Yes	Yes Yes	Yes Yes	Yes Yes	
CSA C22.2 No. 14/CSA C22.2 N	lo. 60947-4-1						
• UL 489, CSA C22.2 No. 5 Number of poles			3				Yes
Max. rated current $I_{\text{n max}}$		A	16	40	80	100	22
(= max. rated operational curren	it I <sub>e</sub> )						
Permissible ambient temperatur  Storage/transport	e	°C	-50 +80				
Operation	<i>I</i> <sub>n</sub> : 0.16 32 A	°C	-20 +70				
	<i>I</i> <sub>n</sub> : 36 40 A	°C	(current reduction	n above +60 °C) -20 +40			
	τη. σσ το / τ	Ü		(The devices must			
				not be mounted side-by-side and			
				they must not be assembled with			
				link modules with			
				contactors. Lateral clearance = 9 mm)			
	<i>I</i> <sub>∩</sub> : 14 80 A	°C			-20 +70		
					(current reduction above		
	I : 40 100 A	°C			+60 °C)	-20 +70	
	<i>I</i> <sub>∩</sub> : 40 100 A	C				current	
						reduction above +60 °C)	
Permissible rated current at insi	de temperature of					100 0)	
control cabinet • +60 °C	•	%	100				
• +70 °C		%	87				
Permissible rated current at ami							
enclosure (applies to motor star breaker inside enclosure): S00/5							
• +35 °C • +60 °C	,	% %	100 87		100	100 87	
Rated operational voltage $U_e$		/0	07			01	
Acc. to IEC				ded-plastic enclosure	e is used only 500	V)	
• Acc. to UL/CSA		V AC Hz	50/60				
Rated frequency Rated insulation voltage <i>U</i> <sub>i</sub>		V	690			1 000	690
Rated impulse withstand voltage	e <i>U</i> imn	kV	6			8	6
Utilization category							
<ul><li>IEC 60947-2 (motor starter prote</li><li>IEC 60947-4-1 (motor starter)</li></ul>	ector/circuit breaker)		A AC-3				
Trip class CLASS	Acc. to IEC 60947-4-1		10		10/20		
DC short-circuit breaking capac							
(time constant <i>t</i> = 5 ms) • 1 conducting path 150 V DC		kA	10		On		10
• 2 conducting paths in series 300		kΑ	10		request		10
• 3 conducting paths in series 450		kA W	5				10 5
Power loss P <sub>v</sub> for each motor starter protector/circuit breaker		W	6		 		6
Dependent on rated current $I_n$	<i>I</i> <sub>n</sub> : 8 16 A	W	7	-			7
(upper setting range)	<i>I</i> <sub>n</sub> : 14 16 A	W		7	10		7
R = P	<i>I</i> <sub>n</sub> : 17 25 A <i>I</i> <sub>n</sub> : 28 32 A	W		8 11	12 14		8
$R_{\text{per conducting path}} = \frac{P}{I^2 \times 3}$	<i>I</i> <sub>n</sub> : 36 40 A	W		14	15		
	<i>I</i> <sub>n</sub> : 45 52 A	W W			17		
	<i>I</i> <sub>∩</sub> : 59 65 A <i>I</i> <sub>∩</sub> : 73 80 A	W			19 21		
	<i>I</i> <sub>n</sub> : 40 50 A	W				21	
	<i>I</i> <sub>n</sub> : 63 75 A <i>I</i> <sub>n</sub> : 84 93 A	W				21 32	
	<i>I</i> <sub>n</sub> : 100 A	w				38	
Shock resistance	Acc. to IEC 60068-2-27	g/ms	25/11 (square and	d sine pulse)			

## SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers

General data (continued)							
Туре			3RV2.1.	3RV2.2.	3RV2.3.	3RV2.4.	3RV27, 3RV28
Size			S00	S0	S2	S3	S00, S0
Dimensions (W x H x D) • Screw terminals • Spring-type terminals	T W	mm mm	45 x 97 x 91 45 x 106 x 91	45 x 97 x 91 45 x 119 x 91	55 x 140 x 149	70 x 165 x 169	45 x 144 x 92
Degree of protection	Acc. to IEC 60529		IP20			de) ) (use additional te e of protection)	rminal covers for
Touch protection	Acc. to IEC 60529		Finger-safe		Finger-safe, for	vertical contact fro	m the front
Temperature compensation	Acc. to IEC 60947-4-1	°C	–20 +60				
Phase failure sensitivity	Acc. to IEC 60947-4-1		Yes (not for 3RV	'23 motor starter p	rotectors)		No
Protection of motors in hazardo • EC type-examination certificate European Directive 2014/34/EU	number according to			V20 motor starter 001 & II (2) GD	protectors)	On request On request	No No
according to international standard			IECEx BVS1.01	02 [Ex]		On request	No
Isolating function Main and EMERGENCY-STOP switch characteristics (with corresponding accessories)	Acc. to IEC 60947-2 Acc. to EN 60204-1 VDE 0113		Yes Yes				
Protective separation between main and auxiliary circuits required for PELV-applications	Acc. to IEC 60947-1						
<ul><li>Up to 400 V + 10 %</li><li>Up to 415 V + 5 % (higher voltage)</li></ul>	ges on request)		Yes Yes				
Permissible mounting position			Any, acc. to IEC	60447 start comr	nand "I" right-hand	side or top	
Mechanical endurance (operating	ig cycles)		100 000		52 A: 50 000, 80 A: 20 000	On request	100 000
Electrical endurance (operating	cycles)		100 000		52 A: 50 000, 80 A: 20 000	25 000	100 000
Max. switching frequency per ho	our (motor starts)	1/h	15				

General data			
Type Size Dimensions (W x H x D)	mm	<b>3RV2742</b> S3 70 x 168 x 169	<b>3RV1611-0BD10<sup>1)</sup></b> S00 45 x 90 x 70
Standards • IEC 60947-1, EN 60947-1 (VDE 0660 Part 100) • IEC 60947-2, EN 60947-2 (VDE 0660 Part 101) • UL 508/UL 60947-4-1, CSA C22.2 No.14/CSA 60947-4-1 • UL 489, CSA C22.2 No.5	I	Yes Yes No Yes	Yes No
Number of poles		3	
Max. rated current $I_{n \text{ max}}$ (= max. rated operational current $I_{e}$ )	Α	70	0.2
Permissible ambient temperature • Storage/transport • Operation	°C °C	-50 +80 -20 +70 (current reducti	on above +60 °C)
Permissible rated current at inside temperature of con cabinet  • +60 °C  • +70 °C	trol % %	100 87	
Permissible rated current at enclosure ambient temperature (applies for motor starter protector inside enclosure)  • +35 °C	%	100	
• +60 °C	%	87	
<ul> <li>Rated operational voltage U<sub>e</sub></li> <li>Acc. to IEC</li> <li>Acc. to UL/CSA</li> </ul>	V AC V AC	690 (with molded-plastic e 600	nclosure 500 V)
Rated frequency	Hz	50/60	
Rated insulation voltage <i>U</i> <sub>i</sub>	V	1 000	690
Rated impulse withstand voltage $U_{\rm imp}$	kV	8	6
Utilization category • IEC 60947-2 (motor starter protector/circuit breaker)		А	
DC short-circuit breaking capacity (time constant t = 5 ms)  • 1 conducting path 150 V DC  • 2 conducting paths in series 300 V DC  • 3 conducting paths in series 450 V DC	kA kA kA	On request	

 <sup>&</sup>quot;Technical Specifications" for 3RV1611 voltage transformer circuit breakers, see page 7/23.

General data

General data (continued)				
Туре			3RV2742	3RV1611-0BD10 <sup>1)</sup>
Size Dimensions (W x H x D)		mm	S3 70 x 168 x 169	S00 45 x 90 x 70
Power loss P <sub>v</sub> for each motor	<i>I</i> <sub>n</sub> : 0.2 A	W		5
starter protector/circuit breaker Dependent on rated current In (upper setting range)	<i>I</i> <sub>n</sub> : 10 A <i>I</i> <sub>n</sub> : 15 35 A <i>I</i> <sub>n</sub> : 40 70 A	W W W	8 12 20	  
$R_{\text{per conducting path}} = \frac{P}{I^2 \times 3}$				
Shock resistance	Acc. to IEC 60068-2-27	g/ms	25/11 (square and sine pulse)	
Degree of protection	Acc. to IEC 60529		<ul><li>IP20 (front side)</li><li>Connecting terminal IP00</li></ul>	IP20
Touch protection	Acc. to IEC 60529		Finger-safe, for vertical contact from the front	Finger-safe
Temperature compensation	Acc. to IEC 60947-4-1	°C	-20 <b>+</b> 60	
Phase failure sensitivity	Acc. to IEC 60947-4-1		No	Yes
Explosion protection – Safe oper "increased safety" type of protect EC type-examination certificate nu according to directive 2014/34/EU	ction mber		No	No
Isolating function Main and EMERGENCY-STOP switch characteristics (with corresponding accessories)	Acc. to IEC 60947-2 Acc. to EN 60204-1		Yes Yes	
Protective separation between main and auxiliary circuits required for PELV applications	Acc. to IEC 60947-1		V	
<ul> <li>Up to 400 V + 10 %</li> <li>Up to 415 V + 5 % (higher voltace)</li> </ul>	es on request)		Yes Yes	
Permissible mounting position	,		Any, acc. to IEC 60447 start co	ommand "I" right-hand side or top
Mechanical endurance	Operatir	g cycles	On request	100 000
Electrical endurance	Operatir	g cycles	25 000	100 000
Max. switching frequency per ho	our (motor starts)	1/h	15	

<sup>1) &</sup>quot;Technical Specifications" for 3RV1611 voltage transformer circuit breakers, see page 7/23.

# Rated data of the auxiliary switches and signaling switches

		Lateral auxiliary switch with	Signaling switch	Transverse auxiliary switch with		
		1 NO + 1 NC, 2 NO, 2 NC, 2 NO + 2 NC		1 CO	1 NO + 1 NC, 2 NO	
Max. rated voltage						
• Acc. to NEMA (UL)	V AC	600			250	
• Acc. to NEMA (CSA)	V AC	600			250	
Uninterrupted current	А	10		5	2.5	
Switching capacity		1 NO + 1 NC, 2 NO, 2 NC: A600, Q300; 2 NO + 2 NC: A300, Q300	A600, Q300	B600, R300	C300, R300	

## SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers

Front transverse auxiliary switches			
		Switching capacity f	or different voltages
		1 CO	1 NO + 1 NC, 2 NO
Rated operational current I <sub>e</sub>			
<ul> <li>At AC-15, alternating voltage</li> <li>24 V</li> <li>230 V</li> </ul>	A A	4 3	2 0.5
<ul> <li>At AC-12 = I<sub>th</sub>, alternating voltage</li> <li>24 V</li> <li>230 V</li> </ul>	A A	10 10	2.5 2.5
• At DC-13, direct voltage <i>L/R</i> 200 ms - 24 V - 48 V - 60 V - 110 V - 220 V	A A A A	1  0.22 0.1	1 0.3 0.15 
Minimum load capacity	V mA	17 1	

Front transverse solid-state comp	oatible auxiliary switches		
			Switching capacity for different voltages
			1 CO
Rated operational voltage U <sub>e</sub>	Alternating voltage	٧	125
Rated operational current I <sub>e</sub> /AC-14	At $U_{\rm e}$ = 125 V	Α	0.1
Rated operational voltage $U_{\rm e}$	Direct voltage L/R 200 ms	V	60
Rated operational current I <sub>e</sub> /DC-13	At $U_{\rm e}$ = 60 V	Α	0.3
Minimum load capacity		V	5
		mΑ	1

Lateral auxiliary switches with signaling switch		
		Switching capacity for different voltages: Lateral auxiliary switch with 1 NO + 1 NC, 2 NO, 2 NC, 2 NO + 2 NC; Signaling switch
Rated operational current I <sub>e</sub>		
<ul> <li>At AC-15, alternating voltage</li> <li>24 V</li> <li>230 V</li> <li>400 V</li> <li>690 V</li> </ul>	A A A	6 4 3 1
<ul> <li>At AC-12 = I<sub>th</sub>, alternating voltage</li> <li>24 V</li> <li>230 V</li> <li>400 V</li> <li>690 V</li> </ul>	A A A	10 10 10 10
• At DC-13, direct voltage <i>L/R</i> 200 ms - 24 V - 110 V - 220 V - 440 V	A A A	2 0.5 0.25 0.1
Minimum load capacity	V mA	17

Auxiliary releases			
		Undervoltage releases	Shunt releases
Power consumption			
<ul><li>During pick-up</li><li>AC voltages</li><li>DC voltages</li></ul>	VA/W W	20.2/13 20	20.2/13 13 80
<ul><li>During uninterrupted duty</li><li>AC voltages</li><li>DC voltages</li></ul>	VA/W W	7.2/2.4 2.1	
Response voltage			
• Tripping	V	0.35 0.7 x <i>U</i> <sub>s</sub>	0.7 1.1 x U <sub>s</sub>
• Pick-up	V	0.85 1.1 x <i>U</i> <sub>s</sub>	
Opening time maximum	ms	20	

Short-circuit protection for auxiliary and control circuits		
Melting fuses operational class gG	А	10
Miniature circuit breakers C characteristic	Α	6 (prospective short-circuit current < 0.4 kA)

Conductor cross sections of main circuit						
Conductor cross-sections of main circuit						
Туре		3RV2.11	3RV2.21	3RV2.31-4B.1., 3RV2.31-4D.1., 3RV2.31-4E.1., 3RV2.31-4P.1., 3RV2.31-4T.1., 3RV2.31-4T.1., 3RV2.31-4U.1., 3RV2.31-4V.1.	3RV2.31-4J.1., 3RV2.31-4K.1., 3RV2.31-4R.1., 3RV2.31-4W.1., 3RV2.31-4X.1., 3RV2431-4VA1., 3RV2.32	3RV27, 3RV28
Size		S00	S0	S2		S00, S0
Connection type		Screw termi	nals			
Terminal screw		M3, Pozidriv size 2	M4, Pozidriv size 2	M6, Pozidriv size 2		M4, Pozidriv size 2
Operating devices	mm	Ø56	Ø 5 6	Ø 5 6		Ø 5 6
Prescribed tightening torque	Nm	0.8 1.2	2 2.5	3.0 4.5		2.5 3
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected						
Solid or stranded	$\text{mm}^2$	2 x (0.75 2.5) <sup>1)</sup> , 2 x 4	$2 \times (1 \dots 2.5)^{1)}$ $2 \times (2.5 \dots 10)^{1}$	2 x (1 25) <sup>1)</sup> , 1 x (1 35) <sup>1)</sup>	2 x (1 35) <sup>1)</sup> , 1 x (1 50) <sup>1)</sup>	2 x (1 10) <sup>1)</sup> , max 1 x 25
• Finely stranded with end sleeve (DIN 46228-1)	mm <sup>2</sup>	2 x (0.5 1.5) <sup>1)</sup> 2 x (0.75 2.5) <sup>†)</sup>	2 x (1 2.5) <sup>1)</sup> , 2 x (2.5 6) <sup>1)</sup> , 1 x 10	2 x (1 16) <sup>1)</sup> , 1 x (1 25) <sup>1)</sup>	2 x (1 25) <sup>1)</sup> , 1 x (1 35) <sup>1)</sup>	1 x (1 16), max. 6 + 16
AWG cables, solid or stranded	AWG	2 x (20 16) <sup>1)</sup> , 2 x (18 12) <sup>1)</sup>	2 x (18 12) <sup>1)</sup> , 2 x (14 8) <sup>1)</sup>	2 x (18 3) <sup>1)</sup> , 1 x (18 2) <sup>1)</sup>	2 x (18 2) <sup>1)</sup> , 1 x (18 1) <sup>1)</sup>	2 x (14 10)
Connection type		Spring-type	terminals			
Operating devices	mm	3.0 x 0.5				
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected						
Solid or stranded	$\text{mm}^2$	2 x (0.5 4)	2 x (1 10)			
Finely stranded without end sleeve	$\text{mm}^2$	2 x (0.5 2.5)	2 x (1 6)			
• Finely stranded with end sleeve (DIN 46228-1)	$\text{mm}^2$		2 x (1 6)			
AWG cables, solid or stranded	AWG	2 x (20 12)	2 x (18 8)			
Max. external diameter of the conductor insulation	mm	3.6	6.4			

<sup>1)</sup> If two different conductor cross-sections are connected to one clamping point, both cross-sections must be in the range specified.

## SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers

Туре		3RV2.4./ 3RV2742	3RV1611-0BD10 <sup>1)</sup>
Size		S3	S00
Connection type		Screw terminals with box terminal	Screw terminals
Terminal screw		M6	Pozidriv size 2
Prescribed tightening torque	Nm	4.5 6	
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected			
Solid or stranded	mm <sup>2</sup>	2 x (2.5 16) <sup>2)</sup> , 2 x (10 50) <sup>2)</sup> , 1 x (10 70) <sup>2)</sup>	2 x (0.5 1.5) <sup>2)</sup> , 2 x (0.75 2.5) <sup>2)</sup>
• Finely stranded with end sleeve (DIN 46228-1)	mm <sup>2</sup>	2 x (2.5 35) <sup>2)</sup> , 1 x (2.5 50) <sup>2)</sup>	2 x (0.5 1.5) <sup>2)</sup> , 2 x (0.75 2.5) <sup>2)</sup>
AWG cables, solid or stranded	AWG	2 x (10 1/0) <sup>2)</sup> , 1 x (10 2/0) <sup>2)</sup>	2 x (18 14)
Ribbon cable conductors (Number x Width x Thickness)	mm	2 x (6 x 9 x 0.8)	
Removable box terminals <sup>3)</sup>			
• With copper bars <sup>4)</sup>	mm	2 x 12 x 4	
• With cable lugs <sup>5)</sup>			
- Terminal screw		M6	
- Prescribed tightening torque	Nm	4.5 6	
- Usable ring terminal lugs	201_12740 mm mm	$d_2 = min. 6.3$ $d_3 = max. 19$	

 $<sup>^{\</sup>rm 1)}$  "Technical Specifications" for 3RV16 voltage transformer circuit breakers, see page 7/23.

 <sup>4)</sup> If bars larger than 12 mm x 10 mm are connected, a 3RT2946-4EA2 cover is needed to maintain the required phase clearance, see page 7/47.
 5) When conductors larger than 25 mm² are connected, the 3RT2946-4EA2 cover is needed to maintain the required phase clearance, see page 7/47.

Conductor cross-sections for auxiliary and control circuits							
Туре		3RV2.11	3RV1611- 0BD10 <sup>1)</sup>	3RV2.21	3RV2.3	3RV2.4	3RV27, 3RV28
Size		S00		S0	S2	S3	S00, S0, S3
Connection type		Scre	w terminals				
Terminal screw		M3, Pozidr	iv size 2				
Operating devices	mm	Ø 5 6					
Prescribed tightening torque	Nm	0.8 1.2					
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected							
Solid or stranded	mm <sup>2</sup>	2 x (0.5	1.5) <sup>2)</sup> , 2 x (0	.75 2.5) <sup>2</sup>	)		
• Finely stranded with end sleeve (DIN 46228-1)	mm <sup>2</sup>	2 x (0.5	1.5) <sup>2)</sup> , 2 x (0	.75 2.5) <sup>2</sup>	)		
AWG cables, solid or stranded	AWG	2 x (18 1	(14) <sup>2)</sup> , 2 x (20	16) <sup>2)</sup>			
Connection type		Sprir	ng-type tern	ninals			
Operating devices	mm	3.0 x 0.5					
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected							
Solid or stranded	mm <sup>2</sup>	2 x (0.5	2.5)				
• Finely stranded without end sleeve	mm <sup>2</sup>	2 x (0.5	2.5)				
• Finely stranded with end sleeve (DIN 46228-1)	mm <sup>2</sup>	2 x (0.5	1.5)				
AWG cables, solid or stranded	AWG	2 x (20 1	14)				
Max. external diameter of the conductor insulation	mm	3.6					
1) "Tachnical Chariffestions" for 2DV1C valtors transformer sireuit breakers	2)	16 4					no alamaina

<sup>1) &</sup>quot;Technical Specifications" for 3RV16 voltage transformer circuit breakers,

<sup>2)</sup> If two different conductor cross-sections are connected to one clamping point, both cross-sections must be in the range specified.

<sup>3)</sup> Cable lug and busbar connection possible after removing the box terminals.

<sup>2)</sup> If two different conductor cross-sections are connected to one clamping point, both cross-sections must be in the range specified.

General data

## Voltage transformer circuit breakers

General data							
Туре		3RV1611-1AG14	3RV1611-1CG14	3RV1611-1DG14			
Size		S00	S00	S00			
Dimensions (W x H x D)	mm o	45 x 90 x 70	45 x 90 x 70	45 x 90 x 70			
Rated current I <sub>n</sub>	A	1.4	2.5	3			
Ambient temperature							
During storage/transport	°C	–50 +80					
During operation	°C	-20 +60 (up to +70	0 °C possible with currer	nt reduction)			
Rated operational voltage U <sub>e</sub>	V	400					
Rated frequency	Hz	16.66 60					
Rated insulation voltage <i>U</i> <sub>i</sub>	V	690					
Short-circuit breaking capacity I <sub>cu</sub> at 400 V AC	kA	50					
Set value of the thermal overload release	А	1.4	2.5	3			
Response value of the instantaneous overcurrent release	А	6 ± 20 %	10.5 ± 20 %	20 ± 20 %			
Tripping time of the instantaneous overcurrent release	ms	Approx. 6 at 12 A	Approx. 6 at 20 A	Approx. 6 at 40 A			
Internal resistance							
• In cold state	Ω	$> 0.25 \pm 6.5 \%$					
• In heated state	Ω	$> 0.30 \pm 6.5 \%$					
Shock resistance acc. to IEC 60068-2-27	<i>g</i> /ms	15					
Degree of protection acc. to IEC 60529		IP20					
Touch protection acc. to EN 50274		Finger-safe for vertical	al contact from the front				
Endurance							
Mechanical	Operating cycles	10 000					
Electrical	Operating cycles	10 000					
Permissible mounting position		Any					

Туре			3RV1611-1AG14	3RV1611-1CG14	3RV1611-1DG14
Conductor cross-sections, main	circuit, 1 or 2 conductors				
Connection type			Screw terminal	s	
Terminal screw			Pozidriv size 2		
Conductor cross-sections (min./max.) 1 or 2 conductors can be connected	,				
Solid or stranded		$\text{mm}^2$	2 x (0.5 1.5) <sup>1)</sup> , 2 x (	0.75 2.5) <sup>1)</sup> , 2 x (1 4	1)
• Finely stranded with end sleeve (DIN 4	6228-1)	$\rm mm^2$	2 x (0.5 1.5) <sup>1)</sup> , 2 x (	0.75 2.5) <sup>1)</sup>	
Auxiliary switches for blocking the	ne distance protection				
With defined lateral assignment for blodistance protection	ocking		1 CO (for use as 1 NC	or 1 NC)	
Rated operational voltage U <sub>e</sub>	Alternating voltage	V	125		
Rated operational current I <sub>e</sub> /AC-14	At $U_{\rm e}$ = 125 V	Α	0.1		
Rated operational voltage U <sub>e</sub>	Direct voltage L/R 200 ms	V	60		
Rated operational current I <sub>e</sub> /DC-13	At $U_e$ = 60 V	Α	0.3		
Minimum load capacity		V mA	5 1		
Short-circuit protection for auxili	ary circuit				
Melting fuse		А	250 V type FF 2A (pro	spective short-circuit cu	urrent < 1.1 kA)

<sup>1)</sup> If two different conductor cross-sections are connected to one clamping point, both cross-sections must be in the range specified.

## SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers

## General data

Terminals for "Self-Protected Combination Motor Controllers (Type E) according to UL 508/UL 60947-4-1"

according_	000141119 10 01 000/01 000+1 + 1		
Туре			3RV2928-1H
Prescribed ti	ghtening torque	Nm	2.5 3
Conductor c	ross-sections		
• Front clamp	ing point connected - Solid - Finely stranded with end sleeve - Stranded - AWG cables, solid or stranded - Terminal screw	mm <sup>2</sup> mm <sup>2</sup> mm <sup>2</sup> AWG	1 10 1 16 2.5 25 14 3
Rear clamp	ing point connected		
NSB0_00480	<ul> <li>Solid</li> <li>Finely stranded with end sleeve</li> <li>Stranded</li> <li>AWG cables, solid or stranded</li> <li>Terminal screw</li> </ul>	mm <sup>2</sup> mm <sup>2</sup> mm <sup>2</sup> AWG	1 10 1 16 1.5 25 14 6 M4
Both clampi	ing points connected		
NSB0_00481	<ul> <li>Front clamping point:         Solid         Finely stranded with end sleeve         Stranded         AWG cables, solid or stranded         Terminal screw</li> </ul>	mm <sup>2</sup> mm <sup>2</sup> mm <sup>2</sup> AWG	1 10 1 10 <sup>1)</sup> , 1 6 <sup>1)</sup> 2.5 10 14 6 M4
	<ul> <li>Rear clamping point:         Solid         Finely stranded with end sleeve         Stranded         AWG cables, solid or stranded         Terminal screw     </li> </ul>	mm <sup>2</sup> mm <sup>2</sup> mm <sup>2</sup> AWG	1 10 1 10 <sup>1)</sup> , 1 16 <sup>1)</sup> 2.5 10 16 3

<sup>1)</sup> The following connections are possible when both clamping points are connected:

- front 1 ... 10 mm<sup>2</sup> and rear 1 ... 10 mm<sup>2</sup>, front 1 ... 6 mm<sup>2</sup> and rear 1 ... 16 mm<sup>2</sup>.

Motor feeder connectors for motor starter prote circuit breakers with screw terminals	ectors/		
Version	Туре	3RT1900-4RE01 Motor feeder connector S0	3RT1926-4RD01 Adapter S0
General data			
Rated insulation voltage <i>U</i> i (pollution degree 3)	V	690	
Rated impulse withstand voltage U <sub>imp</sub> (pollution degree 3)	kV	6	
Rated operational voltage <i>U</i> <sub>e</sub>	V	440	
Rated frequency f For AC operation	Hz	50/60	
Rated operational current $I_{\mathbf{e}}$ AC-3 at 400 V	А	25	
Mechanical endurance	Operating cycles	10 million	
Electrical endurance at I <sub>e</sub>	Operating cycles	1 million	
Protective separation according to IEC 60947-1 (pollution degree 3)	V	400	
Permissible ambient temperature			
During operation	°C	-25 +60	
During storage	°C	-50 +80	
Degree of protection acc. to IEC 60529		IP20 (front side)	
Conductor cross-sections			
Connection type		Screw terminals	
• Solid	mm <sup>2</sup>	1 x (0.5 6)	
Finely stranded without/with end sleeve	mm <sup>2</sup>	1 x (0.5 6)	
• Stranded	mm <sup>2</sup>	1 x (0.5 6)	
AWG cables, solid or stranded	AWG	1 x (20 10)	
Tightening torque	Nm	0.6 0.8	
Corresponding opening tool		Cross-tip screwdriver PZ2	
® and ® rated data			
Rated operational voltage $U_{\rm e}$	V	480	
Rated insulation voltage $U_{\rm i}$	V	600	
Uninterrupted current, at 40 °C	A	25	
Short-circuit protection 1)			
• At 600 V	kA	5	
CLASS RK5 fuse	А	100	
Circuit breaker     with overload protection acc. to UL 489	А	100	
Combination motor controllers type E according to UI	. 508		
•	At 480 V Type	3RV202	
	A	22	
	kA	65	
	At 600 V Type	3RV202	
	A	22	


<sup>1)</sup> For more information about short-circuit values, e.g. for protection against high short-circuit currents, see the UL reports of the individual devices, www.siemens.com/sirius/manuals.


SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers

For motor protection IE3/IE4 ready

#### Selection and ordering data

#### CLASS 10, without auxiliary switches













3RV2011-0AA10

3RV2011-0EA20

3RV2021-4AA10

Rated current	Suitable for three-phase motors <sup>1)</sup> with <i>P</i>	Setting range for thermal overload release	Instanta- neous overcurrent release	Short-circuit breaking capacity at 400 V AC	SD	Screw terminals	<b>+</b>	SD	Spring-type terminals	
$I_{n}$		(三)	<i>I</i> >	$I_{ m CU}$		Article No.	Price per PU		Article No.	Price per PU
Α	kW	A	A	kA	d		perio	d		perio
Size S00	)									
0.16	0.04	0.11 0.16	2.1	100	<b>&gt;</b>	3RV2011-0AA10		<b>•</b>	3RV2011-0AA20	
0.2 0.25	0.06 0.06	0.14 0.2 0.18 0.25	2.6 3.3	100 100	<b>&gt;</b>	3RV2011-0BA10 3RV2011-0CA10		<b>&gt;</b>	3RV2011-0BA20 3RV2011-0CA20	
0.32	0.09	0.22 0.32	4.2	100	<b>&gt;</b>	3RV2011-0DA10		<b></b>	3RV2011-0DA20	
0.4	0.09	0.28 0.4	5.2	100	<b>&gt;</b>	3RV2011-0EA10		<b>&gt;</b>	3RV2011-0EA20	
0.5 0.63	0.12 0.18	0.35 0.5 0.45 0.63	6.5 8.2	100 100	<b>&gt;</b>	3RV2011-0FA10 3RV2011-0GA10		<b>&gt;</b>	3RV2011-0FA20 3RV2011-0GA20	
0.8	0.18	0.55 0.8	10	100	<b></b>	3RV2011-0HA10		<b></b>	3RV2011-0HA20	
1	0.25	0.7 1	13	100	<b></b>	3RV2011-0JA10		<b>•</b>	3RV2011-0JA20	
1.25 1.6	0.37 0.55	0.9 1.25 1.1 1.6	16 21	100 100	<b>&gt;</b>	3RV2011-0KA10 3RV2011-1AA10		<b>▶</b>	3RV2011-0KA20 3RV2011-1AA20	
2	0.75	1.4 2	26	100	<b>•</b>	3RV2011-1BA10		<b></b>	3RV2011-1BA20	
2.5	0.75	1.8 2.5	33	100	<b></b>	3RV2011-1CA10		<b></b>	3RV2011-1CA20	
3.2 4	1.1 1.5	2.2 3.2 2.8 4	42 52	100 100	<b>&gt;</b>	3RV2011-1DA10 3RV2011-1EA10		<b>▶</b>	3RV2011-1DA20 3RV2011-1EA20	
5	1.5	3.5 5	65	100		3RV2011-1EA10		•	3RV2011-1EA20	
6.3	2.2	4.5 6.3	82	100	<b></b>	3RV2011-1GA10		<b></b>	3RV2011-1GA20	
8	3	5.5 8	104	100	<b>&gt;</b>	3RV2011-1HA10		<b>&gt;</b>	3RV2011-1HA20	
10 12.5	5.5	7 10 9 12.5	130 163	100 100		3RV2011-1JA10 3RV2011-1KA10		<b>-</b>	3RV2011-1JA20 3RV2011-1KA20	
16	7.5	10 <sup>2)</sup> 16	208	55	<b>&gt;</b>	3RV2011-4AA10		<b></b>	3RV2011-4AA20	
Size S0										
0.63	0.18	0.45 0.63	8.2	100	5	3RV2021-0GA10		5	3RV2021-0GA20	
0.8	0.18	0.55 0.8	10	100	5	3RV2021-0HA10		5	3RV2021-0HA20	
1 1.25	0.25 0.37	0.7 1 0.9 1.25	13 16	100 100	5 5	3RV2021-0JA10 3RV2021-0KA10		5 5	3RV2021-0JA20 3RV2021-0KA20	
1.6	0.55	1.1 1.6	21	100	5	3RV2021-1AA10		5	3RV2021-1AA20	
2	0.75	1.4 2	26	100	5	3RV2021-1BA10		5	3RV2021-1BA20	
2.5 3.2	0.75 1.1	1.8 2.5 2.2 3.2	33 42	100 100	5 5	3RV2021-1CA10 3RV2021-1DA10		5 5	3RV2021-1CA20 3RV2021-1DA20	
3.2 4	1.5	2.8 4	52	100	5	3RV2021-1DA10 3RV2021-1EA10		5	3RV2021-1DA20 3RV2021-1EA20	
5	1.5	3.5 5	65	100	5	3RV2021-1FA10		5	3RV2021-1FA20	
6.3	2.2	4.5 6.3	82	100	5	3RV2021-1GA10		5	3RV2021-1GA20	
8 10	3	5.5 8 7 10	104 130	100 100	5 5	3RV2021-1HA10 3RV2021-1JA10		5 5	3RV2021-1HA20 3RV2021-1JA20	
12.5	5.5	9 12.5	163	100	5	3RV2021-1KA10		5	3RV2021-1KA20	
16	7.5	10 <sup>2)</sup> 16	208	55	<b></b>	3RV2021-4AA10		<b></b>	3RV2021-4AA20	
20 22	7.5 11	13 <sup>2)</sup> 20 16 <sup>2)</sup> 22	260 286	55 55	<b>&gt;</b>	3RV2021-4BA10 3RV2021-4CA10		<b>&gt;</b>	3RV2021-4BA20 3RV2021-4CA20	
25	11	18 <sup>2)</sup> 25	325	55	•	3RV2021-4DA10		<b>•</b>	3RV2021-4DA20	
28 32 <sup>3)</sup>	15 15	23 28 27 32	364 400	55 55	<b>&gt;</b>	3RV2021-4NA10 3RV2021-4EA10		<b>&gt;</b>	3RV2021-4NA20 3RV2021-4EA20	
36 <sup>4)</sup> 40 <sup>4)</sup>	18.5 18.5	30 36 34 40	432 480	20 20	<b>&gt;</b>	3RV2021-4PA10 3RV2021-4FA10			_	

 $<sup>^{\</sup>rm 1)}$  Guide value for 4-pole standard motors at 50 Hz 400 V AC. The actual starting and rated data of the motor to be protected must be considered when selecting the units.

Auxiliary switches and other accessories can be ordered separately (see "Accessories" page 7/38 onwards).

<sup>2)</sup> The setting range of the thermal overload releases has been extended.

<sup>3)</sup> Suitable for use with IE3/IE4 motors up to a starting current of 256 A. For higher starting currents we recommend using 3RV2 motor starter protectors size S2.

<sup>4)</sup> The devices must not be mounted side-by-side and they must not be assembled with link modules with contactors. A lateral clearance of 9 mm is required. For use with IE3/IE4 motors we recommend using 3RV2 motor starter protectors size S2.

**IE3/IE4 ready** For motor protection

### CLASS 10, without auxiliary switches







3RV2031-4SA10

3RV2032-4RA10

3RV2042-4MA10

		3HV2031-43A10	3NVZU3Z-4NA	10 3NVZU4Z						
Rated current	Suitable for three-phase motors <sup>1)</sup> with <i>P</i>	Setting range for thermal overload release	Instantaneous overcurrent release	Short-circuit breaking capacity at 400 V AC		Screw terminals	<b>+</b>	PU (UNIT, SET, M)	PS*	PG
$I_{n}$		<b>G</b>	<i>I</i> >	$I_{ m CU}$		Article No.	Price per PU			
Α	kW	A	A	kA	d		per Pu			
Size S2										_
14 17	5.5 7.5	9.5 14 12 17	208 260	65 65	<b>&gt;</b>	3RV2031-4SA10 3RV2031-4TA10		1 1	1 unit 1 unit	41E 41E
20	7.5	14 20	260	65		3RV2031-4BA10		1	1 unit	41E
25	11	18 25	325	65	<b></b>	3RV2031-4DA10		1	1 unit	41E
32 36	15 18.5	22 32 28 36	416 520	65 65	<b>&gt;</b>	3RV2031-4EA10 3RV2031-4PA10		1 1	1 unit 1 unit	41E 41E
40	18.5	32 40	585	65 65	<b>&gt;</b>	3RV2031-4UA10		1	1 unit	41E
45 52	22	35 45 42 52	741	65	<u> </u>	3RV2031-4VA10 3RV2031-4WA10		1	1 unit 1 unit	41E 41E
59	30	49 59	845	65	<b>&gt;</b>	3RV2031-4XA10		1	1 unit	41E
65 73	30 37	54 65 62 73	845 949	65 65	<b>&gt;</b>	3RV2031-4JA10 3RV2031-4KA10		1	1 unit 1 unit	41E 41E
80 <sup>2)</sup>	37	70 80	1 040	65	<b>&gt;</b>	3RV2031-4RA10		<u>i</u>	1 unit	41E
	•	ed switching capac								
14 17	5.5 7.5	9.5 14 12 17	208 260	100 100	<b>&gt;</b>	3RV2032-4SA10 3RV2032-4TA10		1 1	1 unit 1 unit	41E 41E
20	7.5	14 20	260	100	<b>&gt;</b>	3RV2032-4BA10		1	1 unit	41E
25 32	11 15	18 25 22 32	325	100	<u> </u>	3RV2032-4DA10		1	1 unit	41E 41E
36	18.5	28 36	416 520	100	<b>•</b>	3RV2032-4EA10 3RV2032-4PA10		1 1	1 unit 1 unit	41E
40 45	18.5 22	32 40 35 45	585 650	100 100	<b>&gt;</b>	3RV2032-4UA10 3RV2032-4VA10		1 1	1 unit 1 unit	41E 41E
52	22	42 52	741	100	<u> </u>	3RV2032-4VA10		1	1 unit	41E
59	30	49 59	845	100	<b>&gt;</b>	3RV2032-4XA10		1	1 unit	41E
65 73	30 37	54 65 62 73	845 949	100 100	<b>&gt;</b>	3RV2032-4JA10 3RV2032-4KA10		1 1	1 unit 1 unit	41E 41E
80 <sup>2)</sup>	37	70 80	1 040	100	▶	3RV2032-4RA10		1	1 unit	41E
Size S3										
40 50	18.5 22	28 40 36 50	520 650	65 65	1	3RV2041-4FA10 3RV2041-4HA10		1	1 unit 1 unit	41E 41E
63	30	45 63	819	65	<u>i</u>	3RV2041-4JA10		1	1 unit	41E
75 84	37 45	57 75 65 84	975 1 170	65 65	1	3RV2041-4KA10 3RV2041-4RA10		1 1	1 unit 1 unit	41E 41E
93	45	75 93	1 300	65	i	3RV2041-4YA10		1	1 unit	41E
100	45, 55	80 100	1 300	65	1	3RV2041-4MA10		1	1 unit	41E
		ed switching capac		100	4	2DV2042 4EA10		4	1 unit	/1E
40 50	18.5 22	28 40 36 50	520 650	100 100	1	3RV2042-4FA10 3RV2042-4HA10		1 1	1 unit 1 unit	41E 41E
63	30	45 63	819	100	1	3RV2042-4JA10		1	1 unit	41E
75 84	37 45	57 75 65 84	975 1 170	100 100	1	3RV2042-4KA10 3RV2042-4RA10		1 1	1 unit 1 unit	41E 41E
93	45	75 93	1 300	100	i	3RV2042-4YA10		i	1 unit	41E
100	45, 55	80 100	1 300	100	1	3RV2042-4MA10		1	1 unit	41E

<sup>1)</sup> Guide value for 4-pole standard motors at 50 Hz 400 V AC. The actual starting and rated data of the motor to be protected must be considered when selecting the units.

Auxiliary switches and other accessories can be ordered separately (see "Accessories" page 7/38 onwards).

<sup>2)</sup> Suitable for use with IE3/IE4 motors up to a starting current of 720 A. For higher starting currents we recommend using motor starter protectors size S3.

### SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers

For motor protection IE3/IE4 ready

#### CLASS 10, with transverse auxiliary switch (1 NO + 1 NC)

 $\begin{array}{ll} PU \text{ (UNIT, SET, M)} = 1 \\ PS^* & = 1 \text{ unit} \\ PG & = 41E \end{array}$ 





3RV2011-4AA15 with integrated transverse auxiliary switch



3RV2011-0EA25 with integrated transverse auxiliary switch



3RV2021-4AA15 with integrated transverse auxiliary switch



3RV2021-4AA25 with integrated transverse auxiliary switch

		auxiliary Switch		auxiliary Switch		auxilial y Switch		auxiliary Switch	
Rated current	Suitable for three-phase motors <sup>1)</sup> with <i>P</i>	Setting range for thermal overload release	Instanta- neous overcurrent release	Short-circuit breaking capacity at 400 V AC	SD	Screw terminals	⊕ SE	terminals	
$I_{n}$			[ >	$I_{ m CU}$		Article No.	Price	Article No.	Price
Α	kW	A	A	kA	d		per PU d		per PU
Size S0	0								
0.16	0.04	0.11 0.16	2.1	100	<b></b>	3RV2011-0AA15	<b></b>	3RV2011-0AA25	
0.2	0.06	0.14 0.2	2.6	100	<b>&gt;</b>	3RV2011-0BA15	▶	3RV2011-0BA25	
0.25	0.06	0.18 0.25	3.3	100	<b>&gt;</b>	3RV2011-0CA15	▶	3RV2011-0CA25	
0.32	0.09	0.22 0.32	4.2	100	<b>&gt;</b>	3RV2011-0DA15	<b>•</b>	3RV2011-0DA25	
0.4	0.09	0.28 0.4	5.2	100	<b></b>	3RV2011-0EA15	<b></b>	3RV2011-0EA25	
0.5	0.12	0.35 0.5	6.5	100	<b>&gt;</b>	3RV2011-0FA15	▶	3RV2011-0FA25	
0.63	0.18	0.45 0.63	8.2	100	<b>&gt;</b>	3RV2011-0GA15	▶	3RV2011-0GA25	
0.8	0.18	0.55 0.8	10	100	<b>&gt;</b>	3RV2011-0HA15	<b></b>	3RV2011-0HA25	
1	0.25	0.7 1	13	100	<b></b>	3RV2011-0JA15	<b></b>	3RV2011-0JA25	
1.25	0.37	0.9 1.25	16	100	<b>&gt;</b>	3RV2011-0KA15	▶	3RV2011-0KA25	
1.6	0.55	1.1 1.6	21	100	▶	3RV2011-1AA15	▶	3RV2011-1AA25	
2	0.75	1.4 2	26	100	<b>&gt;</b>	3RV2011-1BA15	<b>&gt;</b>	3RV2011-1BA25	
2.5	0.75	1.8 2.5	33	100	<b></b>	3RV2011-1CA15	<b></b>	3RV2011-1CA25	
3.2	1.1	2.2 3.2	42	100	<b></b>	3RV2011-1DA15	▶	3RV2011-1DA25	
4	1.5	2.8 4	52	100	<b>&gt;</b>	3RV2011-1EA15	<b></b>	3RV2011-1EA25	
5	1.5	3.5 5	65	100	<b>&gt;</b>	3RV2011-1FA15	<b>•</b>	3RV2011-1FA25	
6.3	2.2	4.5 6.3	82	100	<b></b>	3RV2011-1GA15	<b></b>	3RV2011-1GA25	
8	3	5.5 8	104	100	<b></b>	3RV2011-1HA15	▶	3RV2011-1HA25	
10	4	7 10	130	100	▶	3RV2011-1JA15	▶	3RV2011-1JA25	
12.5	5.5	9 12.5	163	100	<b></b>	3RV2011-1KA15	▶	3RV2011-1KA25	
16	7.5	10 <sup>2)</sup> 16	208	55	<b>&gt;</b>	3RV2011-4AA15	<b></b>	3RV2011-4AA25	
Size S0									
16	7.5	10 <sup>2)</sup> 16	208	55	▶	3RV2021-4AA15	<b></b>	3RV2021-4AA25	
20	7.5	13 <sup>2)</sup> 20	260	55	<b>&gt;</b>	3RV2021-4BA15	▶	3RV2021-4BA25	
22	11	16 <sup>2)</sup> 22	286	55	<b>&gt;</b>	3RV2021-4CA15	▶	3RV2021-4CA25	
25	11	18 <sup>2)</sup> 25	325	55	<b>&gt;</b>	3RV2021-4DA15	▶	3RV2021-4DA25	
28 32 <sup>3)</sup> 36 <sup>4)</sup>	15	23 28	364	55	<b></b>	3RV2021-4NA15	<b></b>	3RV2021-4NA25	
32 <sup>3)</sup>	15	27 32	400	55	<b>&gt;</b>	3RV2021-4EA15	▶	3RV2021-4EA25	
36 <sup>4)</sup>	18.5	30 36	432	20	<b>&gt;</b>	3RV2021-4PA15			
40 <sup>4)</sup>	18.5	34 40	480	20	<b>&gt;</b>	3RV2021-4FA15		-	

<sup>1)</sup> Guide value for 4-pole standard motors at 50 Hz 400 V AC. The actual starting and rated data of the motor to be protected must be considered when selecting the units.

Auxiliary switches and other accessories can be ordered separately (see "Accessories" page 7/38 onwards).

when selecting the units. <sup>2)</sup> The setting range of the thermal overload releases has been extended.


<sup>3)</sup> Suitable for use with IE3/IE4 motors up to a starting current of 256 A. For higher starting currents we recommend using 3RV2 motor starter protectors size S2.

<sup>&</sup>lt;sup>4)</sup> The devices must not be mounted side-by-side and they must not be assembled with link modules with contactors. A lateral clearance of 9 mm is required. For use with IE3/IE4 motors we recommend using 3RV2 motor starter protectors size S2.

SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers

IE3/IE4 ready For motor protection

### CLASS 20, without auxiliary switches











		3RV2031-4SB10	3RV2031-4	WB10 3RV	2042-	-4FB10	3RV2042-4KB	10		
Rated current	Suitable for three-phase motors <sup>1)</sup> with <i>P</i>	Setting range for thermal overload release	Instantaneous overcurrent release	Short-circuit breaking capacity at 400 V AC	SD	Screw terminals	•	PU (UNIT, SET, M)	PS*	PG
$I_{n}$		[ <del>c</del> ]	[ >	$I_{\mathrm{CU}}$		Article No.	Price			
Α	kW	A	A	kA	d		per PU			
Size S2										
14 17 20 25	5.5 7.5 7.5 11	9.5 14 12 17 14 20 18 25	208 260 260 325	65 65 65 65	2 2 2 2	3RV2031-4SB10 3RV2031-4TB10 3RV2031-4BB10 3RV2031-4DB10	1	1 1 1 1	1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E
32 36	15 18.5	22 32 28 36	416 520	65 65	2	3RV2031-4EB10 3RV2031-4PB10		1 1	1 unit 1 unit	41E 41E
40 45	18.5 22	32 40 35 45	585 650	65 65	2	3RV2031-4UB10 3RV2031-4VB10		1	1 unit 1 unit	41E 41E
52 59 65	22 30 30	42 52 49 59 54 65	741 845 845	65 65 65	2	3RV2031-4WB10 3RV2031-4XB10 3RV2031-4JB10		1 1 1	1 unit 1 unit 1 unit	41E 41E 41E
Size S3	, with increase	ed switching capac	city <b>NEW</b>							
40 50 63	18.5 22 30	28 40 36 50 45 63	520 650 819	100 100 100	2 2 2	3RV2042-4FB10 3RV2042-4HB10 3RV2042-4JB10	)	1 1 1	1 unit 1 unit 1 unit	41E 41E 41E
75 84 93	37 45 45	57 75 65 84 75 93	975 1 170 1 300	100 100 100	2 2 2	3RV2042-4KB10 3RV2042-4RB10 3RV2042-4YB10	<b>(</b>	1 1 1	1 unit 1 unit 1 unit	41E 41E 41E
100	45, 55	80 100	1 300	100	2	3RV2042-4MB10		1	1 unit	41E

<sup>1)</sup> Guide value for 4-pole standard motors at 50 Hz 400 V AC. The actual starting and rated data of the motor to be protected must be considered when selecting the units.


Auxiliary switches and other accessories can be ordered separately (see "Accessories" page 7/38 onwards).

SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers

For motor protection with overload relay function IE3/IE4 ready

#### Selection and ordering data

### CLASS 10, with overload relay function (automatic RESET), without auxiliary switches











3RV2111-4FA10

3RV2111-0BA10

3RV2131-4WB10

3RV2142-4FA10

Rated current	Suitable for three-phase motors <sup>1)</sup>	Setting range for thermal overload release	Instantaneous overcurrent release	Short-circuit breaking capacity at 400 V AC	SD	Screw terminals	<b>(+)</b>	PU (UNIT, SET, M)	PS*	PG
	with P	release	Toloado	at 400 V/10				OL 1, 1VI)		
$I_{n}$		[ <del>【</del> ]	<i>I</i> >	$I_{ extsf{cu}}$		Article No.	Price			
Α	kW	A	A	kA	d		per PU			
Size S0	0 <sup>2)</sup>									
0.16	0.04	0.11 0.16	2.1	100	2	3RV2111-0AA10		1	1 unit	41E
0.2 0.25	0.06 0.06	0.14 0.2 0.18 0.25	2.6 3.3	100 100	2 2	3RV2111-0BA10 3RV2111-0CA10		1 1	1 unit 1 unit	41E 41E
0.23	0.00	0.16 0.23	4.2	100	2	3RV2111-0CA10		1	1 unit	41E
0.4	0.09	0.28 0.4	5.2	100	2	3RV2111-0EA10		1	1 unit	41E
0.5 0.63	0.12 0.18	0.35 0.5 0.45 0.63	6.5 8.2	100 100	2 2	3RV2111-0FA10 3RV2111-0GA10		1 1	1 unit 1 unit	41E 41E
0.8	0.18	0.55 0.8	10	100	2	3RV2111-0HA10		1	1 unit	41E
1	0.25	0.7 1	13	100	2	3RV2111-0JA10		1	1 unit	41E
1.25 1.6	0.37 0.55	0.9 1.25 1.1 1.6	16 21	100 100	2	3RV2111-0KA10 3RV2111-1AA10		1 1	1 unit 1 unit	41E 41E
2	0.75	1.4 2	26	100	2	3RV2111-1BA10		1	1 unit	41E
2.5 3.2	0.75 1.1	1.8 2.5 2.2 3.2	33 42	100 100	2 2	3RV2111-1CA10 3RV2111-1DA10		1 1	1 unit 1 unit	41E 41E
3.2 4	1.5	2.2 3.2 2.8 4	52	100	2	3RV2111-1DA10		1	1 unit	41E
5	1.5	3.5 5	65	100	2	3RV2111-1FA10		1	1 unit	41E
6.3 8	2.2 3	4.5 6.3 5.5 8	82 104	100 100	2 2	3RV2111-1GA10 3RV2111-1HA10		1 1	1 unit 1 unit	41E 41E
10	4	7 10	130	100	2	3RV2111-1JA10		1	1 unit	41E
12.5 16	5.5 7.5	9 12.5 10 <sup>3)</sup> 16	163 208	100 55	2	3RV2111-1KA10 3RV2111-4AA10		1 1	1 unit 1 unit	41E 41E
Size S0		10 10	200			OHVETTI TAATO		'	1 dilit	712
16	7.5	10 <sup>3)</sup> 16	208	55	2	3RV2121-4AA10		1	1 unit	41E
20	7.5	103) 00	260	55	2	3RV2121-4BA10		1	1 unit	41E
22 25	11 11	16 <sup>3)</sup> 22 18 <sup>3)</sup> 25	286 325	55 55	2 2	3RV2121-4CA10 3RV2121-4DA10		1 1	1 unit 1 unit	41E 41E
28	15	23 28	364	55	2	3RV2121-4NA10		1	1 unit	41E
32 <sup>4)</sup>	15	27 32	400	55	2	3RV2121-4EA10		1	1 unit	41E
Size S2										
14 17	5.5 7.5	9.5 14 12 17	208 260	65 65	2 2	3RV2131-4SA10 3RV2131-4TA10		1 1	1 unit 1 unit	41E 41E
20	7.5	14 20	260	65	2	3RV2131-4BA10		1	1 unit	41E
25	11	18 25	325	65	2	3RV2131-4DA10		1	1 unit	41E
32 36	15 18.5	22 32 28 36	416 520	65 65	2 2	3RV2131-4EA10 3RV2131-4PA10		1 1	1 unit 1 unit	41E 41E
40	18.5	32 40	585	65	2	3RV2131-4UA10		1	1 unit	41E
45	22	35 45	741	65	2	3RV2131-4VA10		1	1 unit	41E 41E
52 59	32 30	42 52 49 59	741 845	65 65	2 2	3RV2131-4WA10 3RV2131-4XA10		1 1	1 unit 1 unit	41E 41E
65	30	54 65	845	65	2	3RV2131-4JA10		1	1 unit	41E
73 80 <sup>5)</sup>	37 37	62 73 70 80	949 1 040	65 65	2	3RV2131-4KA10 3RV2131-4RA10		1 1	1 unit 1 unit	41E 41E

<sup>1)</sup> Guide value for 4-pole standard motors at 50 Hz 400 V AC. The actual starting and rated data of the motor to be protected must be considered when selecting the units.

Auxiliary switches and other accessories can be ordered separately (see "Accessories" page 7/38 onwards).

<sup>2)</sup> Accessories for mounting on the right and 3RV2915 three-phase busbars cannot be used.


 $<sup>^{\</sup>rm 3)}$  The setting range of the thermal overload releases has been extended.

<sup>4)</sup> Suitable for use with IE3/IE4 motors up to a starting current of 256 A. For higher starting currents we recommend using 3RV2 motor starter protectors size S2.

<sup>5)</sup> Suitable for use with IE3/IE4 motors up to a starting current of 720 A. For higher starting currents we recommend using 3RV2 motor starter protectors size S3.

IE3/IE4 ready For motor protection with overload relay function

## CLASS 10, with overload relay function (automatic RESET), without auxiliary switches (continued)











3RV2142-4FA10

41E

41E

41E

41E 41E

41E

		3RV2111-4FA10	#FATU 3RV2TTT-UBATU			3RV2131-4WB10		3RV2142-4FA10	
Rated current	Suitable for three-phase motors <sup>1)</sup> with <i>P</i>	Setting range for thermal overload release	Instantaneous overcurrent release	Short-circuit breaking capacity at 400 V AC	SD	Screw terminals	<b>+</b>	PU (UNIT, SET, M)	PS*
$I_{n}$		<u> </u>	<i>I</i> >	$I_{\mathrm{CU}}$		Article No.	Price per PU		
Α	kW	Α	Α	kA	d		,		
Size S3	, with increase	ed switching capacit	ty <sup>2)</sup> NEW						
40 50 63	18.5 22 30	28 40 36 50 45 63	520 650 819	100 100 100	2 2 2	3RV2142-4FA10 3RV2142-4HA10 3RV2142-4JA10		1 1 1	1 unit 1 unit 1 unit
75 84 93 100	37 45 45 45, 55	57 75 65 84 75 93 80 100	975 1 170 1 300 1 300	100 100 100 100	2 2 2 2	3RV2142-4KA10 3RV2142-4RA10 3RV2142-4YA10 3RV2142-4MA10		1 1 1 1	1 unit 1 unit 1 unit 1 unit

 $<sup>^{\</sup>rm 1)}$  Guide value for 4-pole standard motors at 50 Hz 400 V AC. The actual starting and rated data of the motor to be protected must be considered when selecting the units.

 $<sup>^{2)}\,</sup>$  Accessories for mounting on the right and 3RV2915 three-phase busbars cannot be used.

Auxiliary switches and other accessories can be ordered separately (see "Accessories" page 7/38 onwards).


SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers

## For starter combinations IE3/IE4 ready

## Selection and ordering data

## Without auxiliary switches

PU (UNIT, SET, M) = 1 PS\* = 1 unit PG = 41E











3RV2311-4AC10

3RV2311-0JC20

3RV2321-4AC10

3RV2321-4AC20

Rated current	Suitable for three-phase motors <sup>1)</sup> with <i>P</i>	Thermal overload releases <sup>2)</sup>	Instanta- neous overcurrent release	Short-circuit breaking capacity at 400 V AC	SD	Screw terminals	⊕ SD	Spring-type terminals	<u> </u>
$I_{D}$		<b>G</b>	[ >	$I_{ extsf{CU}}$			Price er PU	Article No.	Price per PU
Α	kW	A	A	kA	d	ρι	d		perro
Size S0	0								
0.16	0.04	Without	2.1	100	5	3RV2311-0AC10	5	3RV2311-0AC20	
0.2	0.06	Without	2.6	100	5	3RV2311-0BC10	5	3RV2311-0BC20	
0.25	0.06	Without	3.3	100	5	3RV2311-0CC10	5	3RV2311-0CC20	
0.32	0.09	Without	4.2	100	5	3RV2311-0DC10	5	3RV2311-0DC20	
0.4	0.09	Without	5.2	100	5	3RV2311-0EC10	5	3RV2311-0EC20	
0.5	0.12	Without	6.5	100	5	3RV2311-0FC10	5	3RV2311-0FC20	
0.63	0.18	Without	8.2	100	5	3RV2311-0GC10	5	3RV2311-0GC20	
0.8	0.18	Without	10	100	5	3RV2311-0HC10	5	3RV2311-0HC20	
1	0.25	Without	13	100	5	3RV2311-0JC10	5	3RV2311-0JC20	
1.25	0.37	Without	16	100	5	3RV2311-0KC10	5	3RV2311-0KC20	
1.6	0.55	Without	21	100	5	3RV2311-1AC10	5	3RV2311-1AC20	
2	0.75	Without	26	100	5	3RV2311-1BC10	5	3RV2311-1BC20	
2.5	0.75	Without	33	100	5	3RV2311-1CC10	5	3RV2311-1CC20	
3.2	1.1	Without	42	100	5	3RV2311-1DC10	5	3RV2311-1DC20	
4	1.5	Without	52	100	5	3RV2311-1EC10	5	3RV2311-1EC20	
5	1.5	Without	65	100	5	3RV2311-1FC10	5	3RV2311-1FC20	
6.3 8 10 12.5 16	2.2 3 4 5.5 7.5	Without Without Without Without Without	82 104 130 163 208	100 100 100 100 100 55	5 5 5 5 5	3RV2311-1GC10 3RV2311-1HC10 3RV2311-1JC10 3RV2311-1KC10 3RV2311-4AC10	5 5 5 5 5	3RV2311-1GC20 3RV2311-1HC20 3RV2311-1JC20 3RV2311-1KC20 3RV2311-4AC20	
Size S0									
1.6	0.55	Without	21	100	5	3RV2321-1AC10	5	3RV2321-1AC20	
2	0.75	Without	26	100	5	3RV2321-1BC10	5	3RV2321-1BC20	
2.5	0.75	Without	33	100	5	3RV2321-1CC10	5	3RV2321-1CC20	
3.2	1.1	Without	42	100	5	3RV2321-1DC10	5	3RV2321-1DC20	
4	1.5	Without	52	100	5	3RV2321-1EC10	5	3RV2321-1EC20	
5	1.5	Without	65	100	5	3RV2321-1FC10	5	3RV2321-1FC20	
6.3	2.2	Without	82	100	5	3RV2321-1GC10	5	3RV2321-1GC20	
8	3	Without	104	100	5	3RV2321-1HC10	5	3RV2321-1HC20	
10	4	Without	130	100	5	3RV2321-1JC10	5	3RV2321-1JC20	
12.5	5.5	Without	163	100	5	3RV2321-1KC10	5	3RV2321-1KC20	
16	7.5	Without	208	55	5	3RV2321-4AC10	5	3RV2321-4AC20	
20	7.5	Without	260	55	5	3RV2321-4BC10	5	3RV2321-4BC20	
22	11	Without	286	55	5	3RV2321-4CC10	5	3RV2321-4CC20	
25	11	Without	325	55	5	3RV2321-4DC10	5	3RV2321-4DC20	
28	15	Without	364	55	5	3RV2321-4NC10	5	3RV2321-4NC20	
32 <sup>3)</sup>	15	Without	400	55	5	3RV2321-4EC10	5	3RV2321-4EC20	
36 <sup>4)</sup> 40 <sup>4)</sup>	18.5 18.5	Without Without	432 480	20 20	5 5	3RV2321-4PC10 3RV2321-4FC10		-	

<sup>1)</sup> Guide value for 4-pole standard motors at 50 Hz 400 V AC. The actual starting and rated data of the motor to be protected must be considered when selecting the units.

Sizes S2 and S3 see page 7/33.

Auxiliary switches and other accessories can be ordered separately (see "Accessories" page 7/38 onwards).


<sup>2)</sup> For overload protection of the motors, appropriate overload relays must be used.

<sup>3)</sup> Suitable for use with IE3/IE4 motors up to a starting current of 256 A. For higher starting currents we recommend using 3RV2 motor starter protectors size S2.

<sup>4)</sup> The devices must not be mounted side-by-side and they must not be assembled with link modules with contactors. A lateral clearance of 9 mm is required. For use with IE3/IE4 motors we recommend using 3RV2 motor starter protectors size S2.

**IE3/IE4 ready** For starter combinations

## Without auxiliary switches (continued)













RV2331-4SC10	31

3RV2341-4FC10

Rated current	Suitable for three-phase motors <sup>1)</sup> with <i>P</i>	Thermal overload releases <sup>2)</sup>	Instantaneous overcurrent release	Short-circuit breaking capacity at 400 V AC	SD	Screw terminals	<b>+</b>	PU (UNIT, SET, M)	PS*	PG
$I_{n}$		G	<i>I</i> >	$I_{\mathrm{CU}}$		Article No.	Price per PU			
Α	kW	Ā	A	kA	d		perro			
Size S2										
14 17	5.5 7.5	Without Without	208 260	65 65	2 2	3RV2331-4SC10 3RV2331-4TC10		1 1	1 unit 1 unit	41E 41E
20	7.5 7.5	Without	260	65	2	3RV2331-4FC10		1	1 unit	41E
25	11	Without	325	65	2	3RV2331-4DC10		1	1 unit	41E
32 36	15 18.5	Without Without	416 520	65 65	2 2	3RV2331-4EC10 3RV2331-4PC10		1 1	1 unit 1 unit	41E 41E
40	18.5	Without	585	65	2	3RV2331-4UC10		1	1 unit	41E
45	22	Without	650	65	2	3RV2331-4VC10		1	1 unit	41E
52 59	22 30	Without Without	741 845	65 65	2 2	3RV2331-4WC10 3RV2331-4XC10		1 1	1 unit 1 unit	41E 41E
65	30	Without	845	65	2	3RV2331-4JC10		1	1 unit	41E
73 80 <sup>3)</sup>	37 37	Without Without	949 1 040	65 65	2	3RV2331-4KC10 3RV2331-4RC10		1 1	1 unit 1 unit	41E 41E
		switching capacit				01172001 411010		'	T GITTE	
14	5.5	Without	208	100	2	3RV2332-4SC10		1	1 unit	41E
17	7.5	Without	260	100	2	3RV2332-4TC10		1	1 unit	41E
20 25	7.5 11	Without Without	260 325	100 100	2	3RV2332-4BC10 3RV2332-4DC10		1 1	1 unit 1 unit	41E 41E
32	15	Without	416	100	2	3RV2332-4EC10		1	1 unit	41E
36 40	18.5 18.5	Without Without	520 585	100 100	2	3RV2332-4PC10 3RV2332-4UC10		1 1	1 unit	41E 41E
40 45	22	Without	650	100	2	3RV2332-4VC10		1	1 unit 1 unit	41E 41E
52	22	Without	741	100	2	3RV2332-4WC10		1	1 unit	41E
59 65	30 30	Without Without	845 845	100 100	2 2	3RV2332-4XC10 3RV2332-4JC10		1 1	1 unit 1 unit	41E 41E
73	37	Without	949	100	2	3RV2332-4KC10		1	1 unit	41E
80 <sup>3)</sup>	37	Without	1 040	100	2	3RV2332-4RC10		1	1 unit	41E
Size S3		AACH .	500	0.5		0.DV.00.44 4.E.0.40			4 0	
40 50	18.5 22	Without Without	520 650	65 65	2	3RV2341-4FC10 3RV2341-4HC10		1 1	1 unit 1 unit	41E 41E
63	30	Without	819	65	2	3RV2341-4JC10		1	1 unit	41E
75 84	37 45	Without Without	975 1 170	65 65	2	3RV2341-4KC10 3RV2341-4RC10		1 1	1 unit	41E 41E
93	45 45	Without	1 300	65	2	3RV2341-4YC10		1	1 unit 1 unit	41E 41E
100	45, 55	Without	1 300	65	2	3RV2341-4MC10		1	1 unit	41E
		switching capacit	•							
40 50	18.5 22	Without Without	520 650	100 100	2 2	3RV2342-4FC10 3RV2342-4HC10		1 1	1 unit 1 unit	41E 41E
63	30	Without	819	100	2	3RV2342-4JC10		1	1 unit	41E
75	37	Without	975	100	2	3RV2342-4KC10		1	1 unit	41E
84 93	45 45	Without Without	1 170 1 300	100 100	2 2	3RV2342-4RC10 3RV2342-4YC10		1 1	1 unit 1 unit	41E 41E
100	45, 55	Without	1 300	100	2	3RV2342-4MC10		i	1 unit	41E

Guide value for 4-pole standard motors at 50 Hz 400 V AC. The actual starting and rated data of the motor to be protected must be considered when selecting the units.

For overload protection of the motors, appropriate overload relays must be used.

<sup>3)</sup> Suitable for use with IE3/IE4 motors up to a starting current of 720 A. For higher starting currents we recommend using 3RV2 motor starter protectors size S3.

Auxiliary switches and other accessories can be ordered separately (see "Accessories" page 7/38 onwards).

## SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers


## For transformer protection

### Selection and ordering data

## CLASS 10, without auxiliary switches

Motor starter protectors for the protection of transformers with high inrush current

PU (UNIT, SET, M) = 1 PS\* = 1 unit PG = 41E













1-0AA10	3RV2411-0AA20	3RV2421-4AA10	3RV2421-4AA20	3RV2431-4WA10

Rated current	Setting range for thermal overload release	Instantaneous overcurrent release	Short-circuit breaking capacity at 400 V AC	SD	Screw terminals	<b>+</b>	SD	Spring-type terminals	8
$I_{n}$	G	[	$I_{\mathrm{CU}}$		Article No.	Price per PU		Article No.	Price per PU
Α	A	A	kA	d		perio	d		perio
Size S00									
0.16 0.2 0.25 0.32	0.11 0.16 0.14 0.2 0.18 0.25 0.22 0.32	3.3 4.2 5.2 6.5	100 100 100 100	<b>* * *</b>	3RV2411-0AA10 3RV2411-0BA10 3RV2411-0CA10 3RV2411-0DA10		2 2 2 2	3RV2411-0AA20 3RV2411-0BA20 3RV2411-0CA20 3RV2411-0DA20	
0.4 0.5 0.63 0.8	0.28 0.4 0.35 0.5 0.45 0.63 0.55 0.8	8.2 10 13 16	100 100 100 100	<b>* * *</b>	3RV2411-0EA10 3RV2411-0FA10 3RV2411-0GA10 3RV2411-0HA10		2 2 2 2	3RV2411-0EA20 3RV2411-0FA20 3RV2411-0GA20 3RV2411-0HA20	
1 1.25 1.6 2	0.7 1 0.9 1.25 1.1 1.6 1.4 2	21 26 33 42	100 100 100 100	<b>* * *</b>	3RV2411-0JA10 3RV2411-0KA10 3RV2411-1AA10 3RV2411-1BA10		2 2 2 2	3RV2411-0JA20 3RV2411-0KA20 3RV2411-1AA20 3RV2411-1BA20	
2.5 3.2 4 5	1.8 2.5 2.2 3.2 2.8 4 3.5 5	52 65 82 104	100 100 100 100	<b>* * *</b>	3RV2411-1CA10 3RV2411-1DA10 3RV2411-1EA10 3RV2411-1FA10		2 2 2 2	3RV2411-1CA20 3RV2411-1DA20 3RV2411-1EA20 3RV2411-1FA20	
6.3 8 10 12.5 16	4.5 6.3 5.5 8 7 10 9 12.5 10 <sup>1)</sup> 16	130 163 208 260 286	100 100 100 100 55	* * * *	3RV2411-1GA10 3RV2411-1HA10 3RV2411-1JA10 3RV2411-1KA10 3RV2411-4AA10		2 2 2 2 2	3RV2411-1GA20 3RV2411-1HA20 3RV2411-1JA20 3RV2411-1KA20 3RV2411-4AA20	
Size S0									
16 20 22 25	10 <sup>1)</sup> 16 13 <sup>1)</sup> 20 16 <sup>1)</sup> 22 18 <sup>1)</sup> 25	286 325 364 400	55 55 55 55	<b>A A A</b>	3RV2421-4AA10 3RV2421-4BA10 3RV2421-4CA10 3RV2421-4DA10		2 2 2 2	3RV2421-4AA20 3RV2421-4BA20 3RV2421-4CA20 3RV2421-4DA20	
Size S2 14 17 20 25	9.5 14 12 17 14 20 18 25	328 410 410 512	65 65 65 65	<b>*</b> * * *	3RV2431-4SA10 3RV2431-4TA10 3RV2431-4BA10 3RV2431-4DA10			- - I	
32 36 40 45	22 32 28 36 32 40 35 45	656 820 820 922	65 65 65 65	<b>* * *</b>	3RV2431-4EA10 3RV2431-4PA10 3RV2431-4UA10 3RV2431-4VA10			  	
52 59 65	42 52 49 59 54 65	1 025 1 040 1 040	65 65 65	<b>&gt; &gt;</b>	3RV2431-4WA10 3RV2431-4XA10 3RV2431-4JA10			  	

 $<sup>^{\</sup>mbox{\scriptsize 1})}$  The setting range of the thermal overload releases has been extended.


Auxiliary switches and other accessories can be ordered separately (see "Accessories" page 7/38 onwards).

For system protection according to UL 489/CSA C22.2 No. 5

## Selection and ordering data

## Without auxiliary switches

Circuit breakers for system protection and non-motor loads according to UL/CSA







3DV3711 0AD10

3RV2742-5FD10

Rated current <sup>1)</sup>	Thermal overload release (non-adjustable)	Instantaneous overcurrent release	Short-circuit break capacity at 480 Y/277 V AC <sup>2)</sup>	Ü	SD	Screw terminals	<b>+</b>	PU (UNIT, SET, M)	PS*	PG
$I_n^{1)}$	G	<i>I</i> >	$I_{bc}$			Article No.	Price			
Α	A	A	kA		d		per PU			
Size S00										
0.16	0.16	2.1	65		5	3RV2711-0AD10		1	1 unit	41E
0.2	0.2	2.6	65		5	3RV2711-0BD10		1	1 unit	41E
0.25 0.32	0.25 0.32	3.3 4.2	65 65		5 5	3RV2711-0CD10 3RV2711-0DD10		1	1 unit 1 unit	41E 41E
0.32	0.4	5.2	65		5	3RV2711-0DD10 3RV2711-0ED10		1	1 unit	41E
0.4	0.4	6.5	65		5	3RV2711-0ED10		1	1 unit	41E 41E
0.63	0.63	8.2	65		5	3RV2711-0GD10		i	1 unit	41E
0.8	0.8	10	65		5	3RV2711-0HD10		1	1 unit	41E
1	1	13	65		5	3RV2711-0JD10		1	1 unit	41E
1.25	1.25	16	65		5	3RV2711-0KD10		1	1 unit	41E
1.6	1.6	21	65 65		5 5	3RV2711-1AD10		1	1 unit	41E
2	2	26				3RV2711-1BD10		<u> </u>	1 unit	41E
2.5 3.2	2.5 3.2	33 42	65 65		5 5	3RV2711-1CD10 3RV2711-1DD10		1	1 unit 1 unit	41E 41E
3.2 4	3.2 4	52	65		5	3RV2711-1DD10		1	1 unit	41E 41E
5	5	65	65		5	3RV2711-1FD10		i	1 unit	41E
6.3	6.3	82	65		5	3RV2711-1GD10		1	1 unit	41E
8	8	104	65		5	3RV2711-1HD10		1	1 unit	41E
10	10	130	65		5	3RV2711-1JD10		1	1 unit	41E
12.5 15	12.5 15	163 208	65 65		5 5	3RV2711-1KD10 3RV2711-4AD10		1	1 unit	41E 41E
Size S0	10	206	65		5	3RV2/11-4AD10		ı	1 unit	415
20	20	260	50		5	3RV2721-4BD10		4	1 unit	41E
22	22	286	50		5	3RV2721-4BD10		1	1 unit	41E
Size S3 NEW		200				01112121 10210			T GITTE	
10	10	150	65	65	5	3RV2742-5AD10		1	1 unit	41E
15	15	225	65	65	5	3RV2742-5BD10		i	1 unit	41E
20	20	260	65	65	5	3RV2742-5CD10		1	1 unit	41E
25	25	325	65	65	5	3RV2742-5DD10		1	1 unit	41E
30	30	390	65	65	5	3RV2742-5ED10		1	1 unit	41E
35	35	455	65		5	3RV2742-5FD10		1	1 unit	41E
40	40	520	65		5	3RV2742-5GD10		1	1 unit	41E
45 50	45 50	585 650	65 65		5 5	3RV2742-5HD10 3RV2742-5JD10		1	1 unit 1 unit	41E 41E
								ا		
60 70	60 70	780 910	65 65		5 5	3RV2742-5LD10		1	1 unit	41E 41E
/ U	70	910	00		Э	3RV2742-5QD10			1 unit	41E

<sup>1)</sup> Rated value 100 % according to UL 489 and IEC 60947-2 ("100 % rated breaker").

Lateral and transverse auxiliary switches can be ordered separately (see "Accessories" page 7/38 onwards)

<sup>2)</sup> Values for 600 Y/347 V AC, see page 7/16.


SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers

For transformer protection according to UL 489/CSA C22.2 No.5

### Selection and ordering data

## Without auxiliary switches

Circuit breakers for system and transformer protection according to UL/CSA, specially designed for transformers with high inrush current





3RV2811-0AD10

Rated current <sup>1)</sup>	Thermal overload release (non-adjustable)	Instantaneous overcurrent release	Short-circuit breaking capacity at 480 Y/277 V AC <sup>2)</sup>	SD	Screw terminals	<b></b>	PU (UNIT, SET, M)	PS*	PG
$I_{n}^{1)}$	<u></u>	<i>I</i> >	$I_{ m bc}$		Article No.	Price per PU			
Α	А	Α	kA	d					
Size S00									
0.16 0.2 0.25 0.32	0.16 0.2 0.25 0.32	3.3 4.2 5.2 6.5	65 65 65 65	5 5 5 5	3RV2811-0AD10 3RV2811-0BD10 3RV2811-0CD10 3RV2811-0DD10		1 1 1 1	1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E
0.4 0.5 0.63 0.8	0.4 0.5 0.63 0.8	8.2 10 13 16	65 65 65 65	5 5 5 5	3RV2811-0ED10 3RV2811-0FD10 3RV2811-0GD10 3RV2811-0HD10		1 1 1 1	1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E
1 1.25 1.6 2	1 1.25 1.6 2	21 26 33 42	65 65 65 65	5 5 5 5	3RV2811-0JD10 3RV2811-0KD10 3RV2811-1AD10 3RV2811-1BD10		1 1 1 1	1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E
2.5 3.2 4 5	2.5 3.2 4 5	52 65 82 104	65 65 65 65	5 5 5 5	3RV2811-1CD10 3RV2811-1DD10 3RV2811-1ED10 3RV2811-1FD10		1 1 1 1	1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E
6.3 8 10 12.5 15	6.3 8 10 12.5 15	130 163 208 260 286	65 65 65 65 65	5 5 5 5 5	3RV2811-1GD10 3RV2811-1HD10 3RV2811-1JD10 3RV2811-1KD10 3RV2811-4AD10		1 1 1 1	1 unit 1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E 41E
Size S0 20 22	20 22	325 364	50 50	5 5	3RV2821-4BD10 3RV2821-4CD10		1	1 unit 1 unit	41E 41F

Rated value 100 % according to UL 489 and IEC 60947-2 ("100 % rated breaker").

Lateral and transverse auxiliary switches can be ordered separately (see "Accessories" page 7/38 onwards)

<sup>2)</sup> Values for 600 Y/347 V AC, see page 7/16.

Mountable accessories

#### Overview

#### Mounting location and function

The 3RV2 motor starter protectors/circuit breakers have three main contact elements. In order to achieve maximum flexibility, auxiliary switches, signaling switches, auxiliary releases and isolator modules can be supplied separately.

These components are easily fitted to the switches without the use of any tools according to requirements.

Overview graphic, see page 7/7.

#### Front side

#### Note:

 A maximum of four auxiliary contacts with auxiliary switches can be mounted on each motor starter protector/circuit breaker

#### Transverse auxiliary switches, solid-state compatible transverse auxiliary switches

1 NO + 1 NC or 2 NO An auxiliary switch block can be inserted transversely on the front. The overall width of the motor starter protectors/circuit breakers remains unchanged.

#### Left-hand side

#### Notes

- A maximum of four auxiliary contacts with auxiliary switches can be mounted on each motor starter protector/circuit breaker
- Lateral auxiliary switches (two contacts) and signaling switches can be mounted separately or together
- Signaling switches cannot be used for 3RV27 and 3RV28 circuit breakers

# Lateral auxiliary switches (2 contacts)

1 NO + 1 NC or 2 NO or 2 NC

1 CO

One of the three lateral auxiliary switches can be mounted on the left side per motor starter protector/circuit breaker. The contacts of the auxiliary switch close and open together with the main contacts of the motor starter protector/circuit breaker.

The width of the lateral auxiliary switch with two contacts is 9 mm.

# Lateral auxiliary switches (4 contacts)

2 NO + 2 NC

One lateral auxiliary switch with four contacts can be mounted on the left side per motor starter protector/circuit breaker. The contacts of the auxiliary switch close and open together with the main contacts of the motor starter protector/circuit breaker.

The width of the lateral auxiliary switch with four contacts is 18 mm.

#### Signaling switches

Tripping 1 NO + 1 NC Short circuit 1 NO + 1 NC One signaling switch can be mounted on the left side of each motor starter protector.

The signaling switch has two contact systems.

One contact system always signals <u>tripping</u> irrespective of whether this was caused by a short circuit, an overload or an auxiliary release. The other contact system only switches in the event of a short circuit. There is no signaling as a result of <u>switching off</u> with the actuator.

In order to be able to switch on the motor starter protector again after a short circuit, the signaling switch must be reset manually after the error cause has been eliminated.

The width of the signaling switch is 18 mm.

#### Right-hand side

#### Notes:

- One auxiliary release can be mounted per motor starter protector/circuit breaker
- Accessories cannot be mounted on the right-hand side of the 3RV21 motor starter protectors for motor protection with overload relay function

#### **Auxiliary releases**

Shunt releases

For remote-controlled tripping of the motor starter protector/circuit breaker. The release coil should only be energized for short periods (see circuit diagrams).

or

Undervoltage releases

Trips the motor starter protector/circuit breaker when the voltage is interrupted and prevents the motor from being restarted accidentally when the voltage is restored. Used for remote-controlled tripping of the motor starter protector/circuit breaker.

Particularly suitable for EMERGENCY-STOP disconnection by way of corresponding EMERGENCY-STOP pushbuttons according to EN 60204-1.

or

Undervoltage releases with leading auxiliary contacts 2 NO

Function and use as for the undervoltage release without leading auxiliary contacts, but with the following additional function: the auxiliary contacts will open in switch position OFF to deenergize the coil of the undervoltage release, thus interrupting energy consumption. In the "tripped" position, these auxiliary contacts are not guaranteed to open. The leading contacts permit the motor starter protector/circuit breaker to reclose.

The width of the auxiliary release is 18 mm

## Тор

#### Notes:

- Isolator modules cannot be used for 3RV27 and 3RV28 circuit breakers
- Isolator module for size S2:
- only with 3RV2 motor starter protectors/circuit breakers up to max. 65 A
- not with the transverse auxiliary switch
- Terminal screws of the transverse auxiliary switch are covered by the isolator module; Recommendation: Lateral auxiliary switches should be used in combination with the isolator module, or the isolator module should not be mounted until the auxiliary switch has been wired up

#### Isolator modules

Isolator modules can be mounted to the upper connection side of the motor starter protectors.

The supply cable is connected to the motor starter protector through the isolator module.

The plug can only be unplugged when the motor starter protector is open and isolates all 3 poles of the motor starter protector from the network. The shock-protected isolation point is clearly visible and secured with a padlock to prevent reinsertion of the plug.

For a complete overview of which accessories can be used for the various motor starter protectors/circuit breakers, see page 7/2.

# SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers

#### Accessories

# Mountable accessories

## Selection and ordering data

PU (UNIT, SET, M) = 1 PS\* = 1 PG = 4 = 1 unit (unless otherwise specified)

= 41E

1 4	- 416								
		Version	For motor starter protectors/ circuit breakers	SD	Screw terminals	<b>+</b>	SD	Spring-type terminals	
			Size	d	Article No.	Price per PU	d	Article No.	Price per PU
Auxiliary sw	ritches <sup>1)</sup>		Size	u		•	u		
		Transverse auxiliary							
10-10-1	7	switches For mounting on the front							
46.66		1 CO	S00 S3	<b>&gt;</b>	3RV2901-1D				
3RV2901-1E		1 NO + 1 NC	000 111 00	<b>&gt;</b>	3RV2901-1E		<b>&gt;</b>	3RV2901-2E	
		2 NO Solid-state compatible		•	3RV2901-1F		<b></b>	3RV2901-2F	
********	<b>y</b>	transverse auxiliary							
3RV2901-2E		switches For mounting on the front,							
	-17	for operation in dusty atmo-							
	12	spheres and in solid-state circuits with low operating							
3RV2901-1G		currents							
		1 00	S00 S3	2	3RV2901-1G				
All Property lies		Covers for transverse auxiliary switches	500 53	•	3RV2901-0H				
		$(PS^* = 10 \text{ units})$							
3RV2901-0H	_								
A CONTRACTOR OF THE PARTY OF TH	- A	Lateral auxiliary switches							
	99	For mounting on the left 1 NO + 1 NC	S00 S3	<b>&gt;</b>	3RV2901-1A			3RV2901-2A	
<u> </u>		2 NO	300 33	<b>&gt;</b>	3RV2901-1B		•	3RV2901-2B	
		2 NC 2 NO + 2 NC		2	3RV2901-1C 3RV2901-1J		<b></b>	3RV2901-2C	
		2110 + 2110		۷	31172901-10				
	10								
3RV2901-1A	3RV2901-2A								
Signaling sw	vitches <sup>2)</sup>								
		Signaling switches	S00 S3	<b>&gt;</b>	3RV2921-1M		<b></b>	3RV2921-2M	
20	20 Mg	One signaling switch can be mounted on the left per motor							
	11 HR -	starter protector.							
= 112	The state of	Separate tripped and short-circuit alarms,							
		1 NO + 1 NC each							
25/45 (444)	200 mg 22								
	DE DE								
3RV2921-1M	3RV2921-2M								
Isolator mod	dules <sup>2)</sup>	2)							
1111	111	Isolator modules <sup>3)</sup>	S00, S0 S2 <sup>4)</sup>	<b>&gt;</b>	3RV2928-1A			-	
	-11-1	Visible isolating distance for isolating individual motor	52"		3RV2938-1A				
	000	starter protectors from the network, lockable in							
		disconnected position							
	- 0								
	-1								
3RV2928-1A	3RV2938-1A			-					

<sup>1)</sup> Each motor starter protector/circuit breaker can be fitted with one transverse and one lateral auxiliary switch. The lateral auxiliary switch with 2 NO + 2 NC is used without a transverse auxiliary switch.

 $<sup>^{2)}</sup>$  This accessory cannot be used for the 3RV27 and 3RV28 circuit breakers (sizes S00, S0, S3).

 <sup>(</sup>SIZES SOU, SU, SS).
 The isolator module for size S2 can be used only with 3RV2 motor starter protectors/circuit breakers up to max. 65 A. Similarly, it cannot be used with the transverse auxiliary switch.

Mountable accessories

PU (UNIT, SET, M) = 1 PS\* = 1 PG = 4 = 1 unit = 41E









922-1CP0 3RV2902-2DB0

Rated co AC 50 Hz	ontrol supp AC 60 Hz	ply voltage <i>U</i> <sub>s</sub> AC  50/60 Hz  100 % ON period 1	AC/DC 50/60 Hz, DC	DC	For motor starter protectors/ circuit breakers	SD	Screw terminals	<b>+</b>	SD	Spring-type terminals	8
V	V	V	V	V	Size	d	Article No.	Price per PU	d	Article No.	Price per PU
Auxilia	ary releas	ses <sup>3)</sup>									
Underv	oltage rele	eases									
 24 110  230 400	 120 208 240 440	   	   	24    	\$00 \$3 \$00 \$3 \$00 \$3 \$00 \$3 \$00 \$3 \$00 \$3	2 2 2 2	3RV2902-1AB4 3RV2902-1AB0 3RV2902-1AF0 3RV2902-1AM1 3RV2902-1AP0 3RV2902-1AV0		<b>A A</b>	   3RV2902-2AP0 3RV2902-2AV0	
415 500	480 600	 			S00 S3 S00 S3	2 2	3RV2902-1AV1 3RV2902-1AS0			 	
Underv	oltage rele	eases with leading a	uxiliary contacts	2 NO							
24 230 400 415	24 240 440 480	  	  	  	S00 S3 S00 S3 S00 S3 S00 S3	5 2 2 2	3RV2922-1CB0 3RV2922-1CP0 3RV2922-1CV0 3RV2922-1CV1		2 2 2	 3RV2922-2CP0 3RV2922-2CV0 3RV2922-2CV1	
Shunt re	eleases										
  	   	20 24 90 110 210 240 350 415 500	20 70 70 190 190 330 330 500 500	   	\$00 \$3 \$00 \$3 \$00 \$3 \$00 \$3 \$00 \$3	2 2 2 2	3RV2902-1DB0 3RV2902-1DF0 3RV2902-1DP0 3RV2902-1DV0 3RV2902-1DS0		2	3RV2902-2DB0 3RV2902-2DF0 3RV2902-2DP0 	

The voltage range is valid for 100 % (infinite) ON period. The response voltage lies at 0.9 of the lower limit of the voltage range.
 The voltage range is valid for 5 s ON period at AC 50/60 Hz and DC. The response voltage lies at 0.85 of the lower limit of the voltage range.

<sup>3)</sup> One auxiliary release can be mounted on the right per motor starter protector/circuit breaker (does not apply to 3RV21 motor starter protectors with overload relay function).

**Busbar accessories** 

#### Overview


#### Insulated three-phase busbar system

Three-phase busbar systems provide an easy, time-saving and clearly arranged means of feeding 3RV2 motor starter protectors/circuit breakers with screw terminals. Different versions are available for sizes S00 to S2 and can be used for the various different types of motor starter protectors/circuit breakers (size S0 up to 32 A).


The 3RV1915 and 3RV1935 three-phase busbar systems are generally unsuitable for the 3RV21 motor starter protectors for motor protection with overload relay function and 3RV27 and 3RV28 circuit breakers according to UL 489/CSA C22.2 No. 5.

The busbars are suitable for between two and five motor starter protectors/circuit breakers. However, any kind of extension is possible by clamping the tags of an additional busbar (rotated by 180°) underneath the terminals of the respective last motor starter protector/circuit breaker.

A combination of motor starter protectors/circuit breakers of size S00 and S0 is possible. The motor starter protectors/circuit breakers are supplied by appropriate infeed terminals.



SIRIUS three-phase busbar system size S00/S0



SIRIUS three-phase busbar system size S2

The three-phase busbar systems are finger-safe. They are designed for any short-circuit stress which can occur at the output side of connected motor starter protectors/circuit breakers.

The three-phase busbar systems can also be used to construct "Type E Starters" according to UL/CSA. Special infeed terminals must be used for this purpose, however (see "Selection and ordering data", page 7/41).


#### 8US busbar adapters for 60 mm systems

The motor starter protectors/circuit breakers are mounted directly with the aid of busbar adapters on busbar systems with 60 mm center-to-center clearance in order to save space and to reduce infeed times and costs.

Busbar adapters for busbar systems with 60 mm center-tocenter clearance are suitable for copper busbars with a width of 12 mm to 30 mm. The busbars can be 5 mm or 10 mm thick.

The motor starter protectors/circuit breakers are snapped onto the adapter and connected on the line side. This prepared unit is then plugged directly onto the busbar system, and is thus connected both mechanically and electrically at the same time.

For further busbar adapters for snap-mounting direct-on-line starters and reversing starters as well as additional accessories such as incoming and outgoing terminals, flat copper profile etc., see Catalog LV 10.



SIRIUS load feeders with busbar adapters snapped onto busbars

**Busbar accessories** 

#### Selection and ordering data

	Modular	Number o	f motor starte	r protectors	Rated	For motor	SD	Article No.	Price	PU	PS*	PG
	spacing		e connected	, protoctoro	current In	starter	0.5	7 11 11 01 0 7 10 1	per PU	(UNIT,	, 0	
		Without lateral ac- cessories		incl. auxiliary release	at 690 V	protectors				SET, M)		
	mm				А	Size	d					
Three-phase bu	sbars <sup>1)</sup>											
MANNA		d side by sid	motor starter de on standar				ıch					
3RV1915-1AB	45 <sup>3)</sup>	2			63	S00, S0 <sup>2)</sup>	<b>&gt;</b>	3RV1915-1AB		1	1 unit	41E
		3			63 63	S00, S0 <sup>2)</sup> S00, S0 <sup>2)</sup>	<b>&gt;</b>	3RV1915-1BB 3RV1915-1CB		1	1 unit 1 unit	41E 41E
44.0.0.0.0.0		5			63	S00, S0 <sup>2)</sup>	•	3RV1915-1CB		1	1 unit	41E
3RV1915-1BB	55 <sup>4)</sup>		2		63	S00, S0 <sup>2)</sup>	<b></b>	3RV1915-2AB		1	1 unit	41E
			3		63	S00, S0 <sup>2)</sup>	<b>&gt;</b>	3RV1915-2BB		1	1 unit	41E
444444			4 5		63 63	S00, S0 <sup>2)</sup> S00, S0 <sup>2)</sup>	<b>&gt;</b>	3RV1915-2CB 3RV1915-2DB		1	1 unit 1 unit	41E 41E
3RV1915-1CB	1	2			108	S2	<b>&gt;</b>	3RV1935-1A		1	1 unit	41E
3111 1313-101		3			108	S2	<b>&gt;</b>	3RV1935-1B		1	1 unit	41E
Contract of the Contract of th		4			108	S2	<b></b>	3RV1935-1C		1	1 unit	41E
444444444	63 <sup>5)</sup>			2 4	63 63	S00, S0 <sup>2)</sup> S00, S0 <sup>2)</sup>	<b>&gt;</b>	3RV1915-3AB 3RV1915-3CB		1 1	1 unit 1 unit	41E 41E
3RV1915-1DB	75 <sup>5)</sup>		2	2	108	S2	<b></b>	3RV1935-3A		1	1 unit	41E
			3	3	108	S2	<b>&gt;</b>	3RV1935-3B		1	1 unit	41E
			4	4	108	S2	<b>&gt;</b>	3RV1935-3C		1	1 unit	41E

- Not suitable for 3RV21 motor starter protectors for motor protection with overload relay function and for 3RV27 and 3RV28 circuit breakers according to UL 489/CSA C22.2 No.5.
- <sup>2)</sup> Approved for motor starter protectors size S0 with  $I_{\rm n}$   $\leq$  32 A.
- 3) For 3RV2 motor starter protectors without accessories mounted on the side.
- <sup>4)</sup> For 3RV2 motor starter protectors with auxiliary switches with 1 NO + 1 NC, 2 NO and 2 NC mounted on the left (9 mm wide).
- 5) For 3RV2 motor starter protectors with mounted accessories (18 mm wide). Auxiliary switches with 2 NO + 2 NC or signaling switch (mounted on the left) or with auxiliary release (mounted on the right).

side.											
	Conductor cr Solid or stranded	Finely stranded with end sleeve	AWG cables, solid or stranded	Tightening torque	For motor starter protectors/ circuit breakers	SD	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
	mm²	mm²	AWG	Nm	Size	d					
Three-phase infee	d terminals										
	Connection	from top									
G G G	2.5 25	2.5 16	10 4	3 4	S00, S0	<b>&gt;</b>	3RV2925-5AB		1	1 unit	41E
3RV2925-5AB	2 x (2.5 50) <sup>1),</sup> 1 x	2 x (2.5 35) <sup>1)</sup> , 1 x	2 x (10 1/0) <sup>1)</sup> , 1 x	4 6	S2	•	3RV2935-5A		1	1 unit	41E
3RV2935-5A	(2.5 70) <sup>1)</sup>	(2.5 50) <sup>1)</sup>	(10 2/0) <sup>1)</sup>								
	Connection Terminal is co into account		ace of a switch,	take space r	equirement						
5 5 5	2.5 25	2.5 16	10 4	Input: 4, Output: 2 2.5	S00, S0	•	3RV2915-5B		1	1 unit	41E
3RV2915-5B											
Three-phase infee	d terminals	for construc	ting "Type E	Starters" '							
	Connection	from top									
The state of the s	2.5 25	2.5 16	10 4	3 4	S00, S0	2	3RV2925-5EB		1	1 unit	41E
	2 x (2.5 50) <sup>1),</sup> 1 x	2 x (2.5 35) <sup>1)</sup> , 1 x	2 x (10 1/0) <sup>1)</sup> , 1 x	4 6	S2	<b>&gt;</b>	3RV2935-5E		1	1 unit	41E
3RV2925-5EB	(2.5 70) <sup>1)</sup>	(2.5 50) <sup>1)</sup>									

<sup>3</sup>RV2935-5E

<sup>1)</sup> If two different conductor cross-sections are connected to one clamping point, both cross-sections must be in the range specified.

# SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers

#### Accessories

# **Busbar accessories**

	Version	For motor starter protectors/circuit breakers	SD	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
		Size	d					
Covers for connec	tion tags							
	Touch protection for empty positions	S00, S0	$\blacktriangleright$	3RV1915-6AB		1	10 units	41E
3RV1915-6AB		S2	•	3RV1935-6A		1	5 units	41E

#### Busbar adapters











8US1251-5DS10

8US1251-5DT11

8US1250-5AS10

8US1250-5AT10

8US1211-4RT00

0051251-50510	00512	ווועפ-ופ		0031230	F-5A-5 TU	(	5031250-5A110		0031211	-4h100	
For motor starter protectors/circuit breakers	Rated current	Connecting cable	Adapter length	Adapter width	Rated voltage	SD	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
Size	Α	AWG	mm	mm	V	d					
Busbar adapters f	or 60 mm sy:	stems									
For copper busbars ac Width: 12 mm and 30 Thickness: 5 mm and also for T and double-	mm 10 mm										
For motor starter pro	tectors/circuit b	reakers with	screw term	ninals			Screw terminals	<b>+</b>			
S00, S0 <sup>2)</sup>	25	12	200	45	690	2	8US1251-5DS10		1	1 unit	140
S0 <sup>2)</sup>	32	10	260	45	690	2	8US1251-5NT10		1	1 unit	140
S2	80	4	200	55	69	5	8US1261-5MS13		1	1 unit	140
S2	80	4	260	55	690	5	8US1261-6MT10		1	1 unit	140
S2 <sup>1)</sup>	80	4	260	118	690	5	8US1211-6MT10		1	1 unit	140
S3	100/70 <sup>3)</sup>	4	215	72	690/600 <sup>3)</sup> <b>NEW</b>	2	8US1211-4TR00		1	1 unit	140
For motor starter pro	tectors/circuit b	reakers with	spring-type	e terminals			Spring-type terminals	$\overset{\infty}{\boxplus}$			
S00, S0 <sup>2)</sup>	25	12	200	45	690	2	8US1251-5DS11		1	1 unit	140
S00, S0 <sup>2)</sup>	25	12	260	45	690	2	8US1251-5DT11		1	1 unit	140
S0 <sup>2)</sup>	32	10	260	45	690	2	8US1251-5NT11		1	1 unit	140
Accessories											
Device holders			200	45		2	8US1250-5AS10		1	1 unit	140
For lateral mounting to busbar adapters			260	45		2	8US1250-5AT10		1	1 unit	140
Side modules For widening of busbar adapters			200	9		2	8US1998-2BJ10		1	10 units	140
Spacers For fixing the feeder onto the busbar adapter						2	8US1998-1BA10		1	50 units	140
Vibration and shock kits For high vibration and shock leads											

For the assembly of feeders for reversing starters comprising a motor starter protector and two contactors.
 Also approved for 3RV27, 3RV28 according to UL.

8US1998-1CA10

8US1998-1DA10

2

5

140

140

2 units

1 unit

shock loads S00/S0

S2

For additional busbar adapters, see Catalog LV 10.

Also approved for SHV21, SHV20


Values according to UL/CSA:
-Rated current: 70 A at 600 V AC
-Short-circuit breaking capacity:
480 V AC: 65 kA, up to I<sub>n</sub> = 30 A
480 Y/277 V AC: 65 kA
600 Y/347 V AC: 20 kA.

Rotary operating mechanisms


#### Overview

#### Door-coupling rotary operating mechanisms

Motor starter protectors/circuit breakers with a rotary operating mechanism can be mounted in a control cabinet and operated externally by means of a door-coupling rotary operating mechanism. When the cabinet door with motor starter protector/circuit breaker is closed, the operating mechanism is coupled. When the motor starter protector/circuit breaker closes, the coupling is locked which prevents the door from being opened unintentionally. This interlock can be defeated by the maintenance personnel. In the OPEN position, the rotary operating mechanism can be secured against reclosing with up to three padlocks. Inadvertent opening of the door is not possible in this case either.



SIRIUS 3RV2926-0K door-coupling rotary operating mechanism



SIRIUS 3RV2926-2B door-coupling rotary operating mechanism for arduous conditions

#### Remote motorized operating mechanisms

3RV motor starter protectors are manually operated switching devices. They automatically trip in response to an overload or short circuit. Intentional remote-controlled tripping is possible by means of a shunt release or an undervoltage release. Reclosing is only possible directly at the motor starter protector/circuit breaker.

The remote motorized operating mechanism allows the motor starter protectors/circuit breakers to be opened and closed by electrical commands. This enables a load or an installation to be isolated from the network or reconnected to it from an operator panel.


If the motor starter protector/circuit breaker is tripped as a result of overload or short circuit, it will be in the tripped position. For reclosing, the remote motorized operating mechanism must first be set manually or electrically to the 0 position (electrically by means of the Open command). Then it can be reclosed.

The remote motorized operating mechanism is available for motor starter protectors/circuit breakers in size S3 for control voltages of 230 V AC and 24 V DC. The motor starter protector/circuit breaker is fitted into the remote motorized operating mechanism as shown in the drawing.

In the "MANUAL" position, the motor starter protector/circuit breaker in the remote motorized operating mechanism can continue to be switched manually on site. In the "AUTOMATIC" position, the motor starter protector/circuit breaker is switched by means of electrical commands. The switching command must be applied for a minimum of 100 ms. The remote motorized operating mechanism closes the motor starter protector after a maximum of 1 s. On voltage failure during the switching operation it is ensured that the motor starter protector/circuit breaker remains in the "OPEN" or "CLOSED" position. In the "MANUAL" and "OFF" position, the remote motorized operating mechanism can be locked with a padlock.

#### RESET function

The RESET button on the motorized operating mechanism serves to reset any 3RV2921-1M signaling switch that might be installed.



SIRIUS 3RV1946-3A.. remote motorized operating mechanism

## SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers

Accessories

# Rotary operating mechanisms

#### Technical specifications

Remote motorized operating mechanisms		
Туре		3RV1946
	W VA	48 170
Operating range		0.85 1.1 x <i>U</i> <sub>s</sub>
Minimum command duration at $U_{\rm S}$	S	0.1
Max. command duration		Unlimited (uninterrupted operation)
Max. total make/break time, remote-controlled	S	2
Ready to reclose after approx.	S	2.5
Switching frequency	1/h	25
Internal back-up fuse • 230 V AC • 24 V DC	A A	0.8 1.6
Connection type of control cables		Plug-in connectors with screw terminals
Shock resistance acc. to IEC 60068-2-27	<i>g</i> /ms	25/11 (square and sine pulse)

#### Selection and ordering data

Version	Color of actuator	Version of extension shaft	For motor starter protectors/ circuit breakers	SD	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
		mm	Size	d					

## Door-coupling rotary operating mechanisms



3RV2926-0B

Door-coupling rotary operating mechanisms consisting of an actuator, a coupling driver and a 130/330 mm long extension shaft

Designed for degree of protection IP65; the door locking device prevents accidental opening of the control cabinet door when the switch is set to ON. The OFF position can be locked with up to three padlocks.

Door-coupling rotary operating mechanisms	Black	130 330	S00 S3 S00 S3	<b>&gt;</b>	3RV2926-0B 3RV2926-0K	1 1	1 unit 1 unit	41E 41E
EMERGENCY- STOP door- coupling rotary operating mechanisms	Red/yellow	130 330	S00 S3 S00 S3	<b>*</b>	3RV2926-0C 3RV2926-0L	1	1 unit 1 unit	41E 41E

#### Door-coupling rotary operating mechanisms for arduous conditions



3RV2926-2B



3RV2936-2C

The door-coupling rotary operating mechanisms consist of an actuator, a coupling driver, an extension shaft of 300 mm in length (8 mm x 8 mm), a spacer and two metal brackets into which the motor starter protector/circuit breaker is inserted.

The door-coupling rotary operating mechanisms are designed to degree of protection IP65. The door interlocking reliably prevents opening of the control cabinet door in the ON position of the motor starter protector/circuit breaker. The OFF position can be locked with up to three padlocks.

Laterally mountable auxiliary releases and two-pole auxiliary switches can be used.

The door-coupling rotary operating mechanisms thus meet the requirements for isolating functions according to IEC 60947-2.

Door-coupling	Gray	300	S00, S0	<b>&gt;</b>	3RV2926-2B	1	1 unit	41E
rotary operating mechanisms			S2	<b>&gt;</b>	3RV2936-2B	1	1 unit	41E
			S3	<b>&gt;</b>	3RV2946-2B	1	1 unit	41E
EMERGENCY-	Red/yellow	300	S00, S0	<b></b>	3RV2926-2C	1	1 unit	41E
STOP door- coupling rotary			S2	<b>&gt;</b>	3RV2936-2C	1	1 unit	41E
operating mechanisms			S3	<b>&gt;</b>	3RV2946-2C	1	1 unit	41E

Version	Rated control supply voltage $U_{\rm S}$	For motor starter protectors/ circuit breakers	SD	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
		Size						

#### Remote motorized operating mechanisms



motorized
operating mechanisms

Remote

50/60 Hz, 230 V AC	S3	X	3RV1946-3A
24 V DC	S3		3RV1946-3A

3RV1946-3A..

1 unit

1 unit

41E

41E

**Mounting accessories** 

#### Overview

#### More information


System Manual "SIRIUS – System Overview", see https://support.industry.siemens.com/cs/ww/en/view/60311318

Manual "SIRIUS – SIRIUS 3RV2 Motor Starter Protectors", see https://support.industry.siemens.com/cs/ww/en/view/60279172


#### Accessories for "Self-Protected Combination Motor Controllers (Type E)" according to UL 508/UL 60947-4-1

The 3RV20 motor starter protectors with screw terminals are approved according to UL 508/UL 60947-4-1 as "Self-Protected Combination Motor Controllers (Type E)".


This requires increased through air and over surface spacing (1 inch and 2 inches respectively) at the input side of the device, which are achieved by mounting a terminal block or a phase barrier.



SIRIUS 3RV2928-1H terminal block



SIRIUS 3RT2946-4GA07 terminal block (type E)



SIRIUS 3RV2928-1K phase barrier

Motor starter protectors/circuit breakers	Size	Essential accessories for "Self-Protected Combination Motor Controllers (Type E)" according to UL 508/UL 60947-4-1
3RV201., 3RV202.	S00/S0	3RV2928-1H terminal block or 3RV2928-1K phase barrier
3RV2031-4B.1., 3RV2031-4D.1., 3RV2031-4E.1., 3RV2031-4P.1., 3RV2031-4S.1., 3RV2031-4U.1., 3RV2031-4U.1., 3RV2031-4U.1.	\$2	_
3RV2031-4J.1., 3RV2031-4K.1., 3RV2031-4R.1., 3RV2031-4W.1., 3RV2031-4X.1., 3RV2032	S2	3RV2938-1K phase barrier
3RV204.	S3	3RT2946-4GA07 terminal block

-- No accessories needed

Special three-phase infeed terminals are required for constructing "Type E Starters" with an insulated three-phase busbar system (see "Busbar Accessories", page 7/41).

The 3RV29 infeed system also enables the assembly of "Type E Starters", see page 7/55 onwards.

#### Note:

According to CSA, these terminal blocks and the phase barriers can be omitted when the device is used as a "Self-Protected Combination Motor Controller (Type E)".

#### SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers

#### Accessories

## **Mounting accessories**

#### Link modules

Feeders can be easily assembled from single devices with the help of the link modules. The following table shows the different combination options for devices with screw or spring-type terminals.

Combination devices	3RV2 motor starter protectors/	3RT2 contactors; 3RW30, 3RW40 soft starters;	Link modules	
	circuit breakers	3RF34 solid-state contactors	Screw terminals	Spring-type terminals
	Size	Size		
Link modules for connecting switching devices to	3RV2 motor starter prote	ectors/circuit breakers <sup>1)</sup>		
3RT2 contactors with AC or DC coil	S00	S00	3RA1921-1DA00	3RA2911-2AA00
	S0	S00		
	S2	S2	3RA2931-1AA00	
	S3 <sup>2)</sup>	S3 <sup>2)</sup>	3RA1941-1AA00	
3RT2 contactors with AC coil	S0	S0	3RA2921-1AA00	3RA2921-2AA00 <sup>3)</sup>
	S00	S0		
3RT2 contactors with DC coil	S0	S0	3RA2921-1BA00	3RA2921-2AA00
	S00	S0		
3RW30 soft starters	S00	S00	3RA2921-1BA00	3RA2911-2GA00
	S0	S00	_	
3RW30/3RW40 soft starters	S0	S0	3RA2921-1BA00	3RA2921-2GA00
	S00	S0		
	S2 <sup>4)</sup>	S2 <sup>4)</sup>	3RA2931-1AA00	
	S3 <sup>5)</sup>	S3 <sup>5)</sup>	3RA1941-1AA00	
3RF34 solid-state contactors	S00/S0	S00	3RA2921-1BA00	
Hybrid link modules for connecting contactors with spri	ng-type terminals to 3RV2	motor starter protectors/circuit l	breakers with screw te	rminals <sup>6)</sup>
3RT2 contactors with AC or DC coil	S00	S00	3RA2911-2FA00	
	S0	S0	3RA2921-2FA00	

- -- Version not possible
- The link modules cannot be used for 3RV2.21-4PA1., 3RV2.21-4FA1., 3RV2.31-4K.1., 3RV2.31-4R.1., 3RV2.32-4K.1., 3RV2.32-4R.1., 3RV27 and 3RV28 motor starter protectors/circuit breakers.
- 2) To assemble the feeder between a motor starter protector and a contactor in size S3, the 3RA2942-1A00 standard mounting rail adapter must be used
- 3) A spacer for height compensation on AC contactors, size S0, is optionally available, see page 7/49.
- 4) To assemble the feeder between a motor starter protector and a soft starter in size S2, the 3RA2932-1CA00 standard mounting rail adapter must be used.
- 5) It is only permissible to assemble the feeder between the motor starter protector and the soft starter in size S3 on a mounting plate.
- 6) The motor starter protector to contactor hybrid link modules cannot be used for the 3RV2.21-4PA1., 3RV2.21-4FA1., 3RV27 and 3RV28 motor starter protectors/circuit breakers. They are suitable only for constructing direct-on-line starters.

#### Note:

- Link modules can be used in
  - Sizes S00 and S0: up to max. 32 A
  - Size S2: up to max. 65 A
- Hybrid link modules can be used in
  - Sizes S00 and S0: up to max. 32 A

Mounting accessories

# Selection and ordering data

## Accessories

7.0000007.00								
	Version	For motor starter protectors/ circuit breakers	SD		rice PU	PU (UNIT, SET, M)	PS*	PG
		Size	d					
Covers								
3RV2 (size S3) with	Terminal covers For cable lug and busbar connection for maintaining the required voltage clearances and as touch protection if box terminal is removed (2 units can be mounted per motor starter protector/circuit breaker)	S3	5	3RT1946-4EA1		1	1 unit	41B
3RT1946-4EA1 (left)								
	Scale covers Sealable, for covering the set current scale	3RV20, 3RV21, 3RV24: S00 S3	<b>&gt;</b>	3RV2908-0P		100	10 units	41E
3RV2908-0P								
-/-	Covers for devices with screw terminals (box terminals)			Screw terminals	<b>+</b>			
10:00	Additional touch protection for fastening to the box terminals (2 units required per device)							
3RT2936-4EA2	Main current level	S2	2	3RT2936-4EA2		1	1 unit	41B
		S3 NEW	<b>&gt;</b>	3RT2946-4EA2		1	1 unit	41B
Fixing accessories								
3RV2928-0B	Push-in lugs For screwing the motor starter protector onto mounting plates Two units are required for each motor starter protector.	S00, S0	2	3RV2928-0B		100	10 units	41E
Tools for opening	spring-type terminals							
	Screwdrivers For all SIRIUS devices with spring-type term	inals		Spring-type terminals	$\overset{\infty}{\square}$			
3RA2908-1A	Length, approx. 200 mm, 3.0 mm x 0.5 mm, titanium gray/black, partially insulated	S00 S3	2	3RA2908-1A		1	1 unit	41B

#### SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers

#### Accessories

# Mounting accessories

Version	For motor starter sprotectors/ circuit breakers	SD	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
	Size	d					

Terminal blocks and phase barriers for "Self-Protected Combination Motor Controllers (Type E)" according to UL 508/UL 60947-4-1

Terminal blocks type E

For extended clearances (1 and 2 inch)

For extended clearances (1 and 2 inch)

Phase barriers



UL 508/UL 60947-4-1 approval demands 1-inch through air spacing and 2-inch over surface spacing for "Self-Protected Combination Motor Controllers (Type E)". The following terminal blocks or phase barriers must be used for the 3RV20 motor starter protectors with screw terminals. 3RV20 motor starter protectors with spring-type terminals must be assembled with the 3RV29 infeed system for approval as "Self-Protected Combination Motor Controllers (Type E)" according to UL 508/UL 60947-4-1.

3RV2928-1H

3RV2928-1K

3RV2938-1K

3RT2946-4GA07

The terminal block or phase barriers cannot be used in combination with the 3RV19.5 three-phase busbars.

**NEW** 3

For construction with three-phase busbars, see "Busbar Accessories", page 7/40 onwards.

S3

S2

S3

S00, S0

S00, S0







3RV2928-1K



3RV2938-1K

Auxiliary terminals, 3-pole



For connection of auxiliary and control cables to the main conductor connections (for one side)

**NEW** 5

3RT2946-4F

1 unit

1

1

1 unit

1 unit

1 unit

1 unit

41E

41B

41E

41E

41B

# **Mounting accessories**

#### Link modules

Link modules									
	Actuating voltage of contactor	Size 3RT2 contactors	3RV2 motor starter protectors/circuit breakers	SD	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
			1\	d					
Link modules for mot	<u> </u>					_			
	For electrical and mech motor starter protector				Screw terminals	Ð			
	Single-unit packaging								
3RA2921-1AA00	AC/DC AC DC AC/DC AC/DC	\$00 \$0 \$0 \$2 \$3	\$00/\$0 \$00/\$0 \$00/\$0 \$2 \$3	2 2	3RA1921-1DA00 3RA2921-1AA00 3RA2921-1BA00 3RA2931-1AA00 3RA1941-1AA00		1 1 1 1	1 unit 1 unit 1 unit 1 unit 1 unit	41B 41B 41B 41B 41B
	Multi-unit packaging						·		
	AC/DC AC DC AC/DC AC/DC	S00 S0 S0 S2 S3	S00/S0 S00/S0 S00/S0 S2 S3	2 2 •	3RA1921-1D 3RA2921-1A 3RA2921-1B 3RA2931-1A 3RA1941-1A		1 1 1 1	10 units 10 units 10 units 5 units 5 units	41B 41B 41B 41B 41B
3RA2931-1AA00									
فالشأم	For electrical and mech starter protector and co				Spring-type terminals	8			
1000	Single-unit packaging								
111	AC/DC AC <sup>2)</sup> DC	S00 S0 S0	\$00 \$0 \$0	<b>* *</b>	3RA2911-2AA00 3RA2921-2AA00 3RA2921-2AA00		1 1 1	1 unit 1 unit 1 unit	41B 41B 41B
3RA2911-2AA00	Multi-unit packaging								
	AC/DC AC <sup>2)</sup> DC	S00 S0 S0	\$00 \$0 \$0	<b>* *</b>	3RA2911-2A 3RA2921-2A 3RA2921-2A		1 1 1	10 units 10 units 10 units	41B 41B 41B
	Spacers <sup>2)</sup> For compensating the h	neight on AC c	ontactors						
	Single-unit packaging Multi-unit packaging	S0 S0	S0 S0	2 2	3RA2911-1CA00 3RA2911-1C		1 1	1 unit 5 units	41B 41B

#### 3RA2911-1CA00

#### Note:

Link modules can be used in

- Sizes S00 and S0 up to max. 32 A
- Size S2 up to max. 65 A

The link modules for motor starter protector to contactor cannot be used for 3RV2.21-4PA1., 3RV2.21-4FA1., 3RV2.31-4K.1., 3RV2.31-4R.1., 3RV2.32-4K.1., 3RV2.32-4R.1., 3RV27 and 3RV28 motor starter protectors/ circuit breakers.

<sup>2)</sup> A spacer for height compensation on AC contactors size S0 is optionally available.

## **Mounting accessories**

	Size 3RW30, 3RW40 soft starters; 3RF34 solid-state contactors	3RV2 motor starter protectors/circuit breakers	SD	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
			d					
Link modules for r protector to solid-	notor starter protector to s state contactor <sup>1)</sup>	oft starter <sup>1)</sup> and motor sta	rter					
	Connection between motor sta solid-state contactor with screw			Screw terminals	<b></b>			
	Single-unit packaging							
The state of the s	S00	S00/S0	2	3RA2921-1BA00		1	1 unit	41B
	SO	S00/S0	2	3RA2921-1BA00		1	1 unit	41B
3RA2921-1BA00	S2 <sup>2)</sup> S3 <sup>3)</sup>	S2 S3 <sup>3)</sup>	<b>&gt;</b>	3RA2931-1AA00 3RA1941-1AA00		1	1 unit 1 unit	41B 41B
311A2321-1BA00	Multi-unit packaging					·		
	S00	S00/S0	2	3RA2921-1B		1	10 units	41B
	S0	S00/S0	2	3RA2921-1B		i	10 units	41B
	S2 <sup>2)</sup> S3 <sup>3)</sup>	S2 S3 <sup>3)</sup>		3RA2931-1A		1	5 units	41B
	\$307	\$397	•	3RA1941-1A		1	5 units	41B
3RA2931-1AA00								
	Connection between motor sta spring-type terminals	rter protector and soft starter		Spring-type terminals	8			
1000	Single-unit packaging							
A	S00	S00	<b>&gt;</b>	3RA2911-2GA00		1	1 unit	41B
	S0	S0	<b>&gt;</b>	3RA2921-2GA00		1	1 unit	41B
ARK								
3RA2921-2GA00								

- The link modules for motor starter protector to soft starter and motor starter protector to solid-state contactor cannot be used for 3RV2.21-4PA1., 3RV2.21-4FA1., 3RV2.31-4K.1., 3RV2.31-4R.1., 3RV2.32-4K.1., 3RV2.32-4R.1., 3RV27 and 3RV28 motor starter protectors/circuit breakers.
- 2) To assemble the feeder between a motor starter protector and a soft starter in size S2, the 3RA2932-1AC00 standard mounting rail adapter must be used.
- 3) It is only permissible to assemble the feeder between the motor starter protector and the soft starter in size S3 on a mounting plate.

#### Note:

Link modules can be used in

- Sizes S00 and S0 up to max. 32 A
- Size S2 up to max. 65 A

# Mounting accessories

	Actuating voltage of contactor	Size 3RT2 contactors	3RV2 motor starter protectors	SD	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
				d					
Hybrid link modul	es for motor starter prote	ctor to con	tactor <sup>1)</sup>						
	Mechanical and electrical cor protector with screw terminals terminals								
	Single-unit packaging								
FR	AC/DC AC <sup>2)</sup> /DC	S00 S0	S00 S0	<b>&gt;</b>	3RA2911-2FA00 3RA2921-2FA00		1 1	1 unit 1 unit	41B 41B
3RA2911-2FA00	Multi-unit packaging								
	AC/DC AC <sup>2)</sup> /DC	S00 S0	S00 S0	<b>&gt;</b>	3RA2911-2F 3RA2921-2F		1 1	10 units 10 units	41B 41B
3RA2921-2FA00									
3HA2921-2FA00	Spacers <sup>2)</sup>								
	For compensating the height	on AC contac	ctors						
453	Single-unit packaging Multi-unit packaging	S0 S0	S0 S0	2	3RA2911-1CA00 3RA2911-1C		1	1 unit 5 units	41B 41B
3RA2911-1CA00									

<sup>1)</sup> The hybrid link modules for motor starter protector to contactor cannot be used for 3RV2.21-4PA1., 3RV2.21-4FA1., 3RV27 and 3RV28 motor starter protectors/circuit breakers. They are suitable only for constructing direct-on-line starters.

 A spacer for height compensation on AC contactors size S0 is optionally available.

#### Note:

Hybrid link modules in sizes S00 and S0 can be used up to max.  $32\,\mathrm{A}.$ 

	For motor starter protectors/ circuit breakers Type		SD d	Article No.	Price per PU		PS*	PG
Motor feeder conne screw terminals	ectors for moto	r starter protectors/circuit breakers with						
		Adapters for motor starter protectors/circuit breakers Ambient temperature $t_{\rm u\ max.} = 60\ ^{\circ}{\rm C}$		Screw terminals	<b>(1)</b>			
	3RV2.2	Size S0, rated operational current $I_{\rm e}$ at AC-3/400 V: 25 A	5	3RT1926-4RD01		1	1 unit	41B
3RT1926-4RD01								
3RT1900-4RE01	3RV2.2	Motor feeder connectors for motor starter protectors/circuit breakers Size S0	5	3RT1900-4RE01		1	1 unit	41B

#### **Enclosures and front plates**


#### Overview

#### **Enclosures**


For stand-alone installation of 3RV20 to 3RV24 motor starter protectors size S00 ( $I_{\rm n \; max} =$  16 A), S0 ( $I_{\rm n \; max} =$  32 A) and S2 ( $I_{\rm n \; max} =$  65 A), cast aluminum enclosures for surface mounting and molded-plastic enclosures for flush mounting are available in various dimensions.

When installed in a molded-plastic enclosure the motor starter protectors have a rated operational voltage  $U_{\rm e}$  of 500 V.

The enclosures for surface mounting have the degree of protection IP55; the enclosures for flush mounting also comply with the degree of protection IP55 at the front (the flush-mounted section complies with IP20).



Enclosures for surface mounting



Enclosures (only for sizes S00 and S0)

All enclosures are equipped with N and PE terminals. There are two knock-out cable entries for cable glands at the top and two at the bottom; also on the rear corresponding cable entries are scored. There is a knockout on the top of the enclosure for indicator lights that are available as accessories.

The narrow enclosure can accommodate a motor starter protector without accessories, with transverse auxiliary switch and with lateral auxiliary switch. There is no provision for installing a motor starter protector with a signaling switch.

With size S00 to S2 circuit breakers the molded-plastic enclosures are equipped with a rotary operating mechanism.


The enclosures can be supplied with either a black rotary operating mechanism or with an EMERGENCY-STOP rotary operating mechanism with a red/yellow knob.

In the OFF setting, all rotary operating mechanisms can be locked with up to three padlocks.

#### Front plates

Motor starter protectors are frequently required to be actuated in any enclosure. Front plates equipped with a rotary operating mechanism for 3RV20 to 3RV24 motor starter protectors sizes S00 to S3 are available for this purpose.

A holder for the motor starter protectors size S00 and S0, into which the motor starter protectors can be snapped, is available for the front plates.



Front plate (including holder) for sizes S00 and S0

# Enclosures and front plates

	Version		Integrated terminals		For 3RV20 to 3RV24 motor starter protectors		Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
				mm	Size	d					
lolded-plastic	enclosures f			3							
_1	With rotary operating mechanism,	IP55	N and PE/ground	54 (for motor starter protector + lateral auxiliary switch)	S00, S0	<b>&gt;</b>	3RV1923-1CA00		1	1 unit	41E
RV1933-1DA00	lockable in 0 position			72 (for motor starter protector + lateral auxiliary switch <sup>2)</sup> + auxiliary release)	S00, S0	•	3RV1923-1DA00		1	1 unit	41E
				82 (for motor starter protector + lateral auxiliary switch <sup>2)</sup> + auxiliary release)	S2	2	3RV1933-1DA00		1	1 unit	41E
1	With EMERGENCY- STOP rotary	IP55	N and PE/ground	54 (for motor starter protector + lateral auxiliary switch)	S00, S0	•	3RV1923-1FA00		1	1 unit	41E
RV1923-1FA00,	operating mechanism, lockable in 0 position			72 (for motor starter protector + lateral auxiliary switch <sup>2)</sup> + auxiliary release)	S00, S0	•	3RV1923-1GA00		1	1 unit	41E
RV1933-1GA00				82 (for motor starter protector + lateral auxiliary switch <sup>2)</sup> + auxiliary release)	S2	2	3RV1933-1GA00		1	1 unit	41E
ast aluminun	n enclosures	for surf	ace mount	ing <sup>1)</sup>							
	With rotary operating mechanism, lockable in 0 position	IP65	PE <sup>3)</sup>	72 (for motor starter protector + lateral auxiliary switch <sup>2)</sup> + auxiliary release)	S00, S0	•	3RV1923-1DA01		1	1 unit	41E
V1923-1DA01	With EMERGENCY- STOP rotary operating mechanism, lockable in 0 position	IP65	PE <sup>3)</sup>	72 (for motor starter protector + lateral auxiliary switch <sup>2)</sup> + auxiliary release)	S00, S0	•	3RV1923-1GA01		1	1 unit	41E
olded-plastic	enclosures f	or flush	n mounting	J <sup>4)</sup>							
	With rotary operating mechanism, lockable in 0 position	IP55 (front side)	N and PE/ground	72 (for motor starter protector + lateral auxiliary switch <sup>2)</sup> + auxiliary release)	S00, S0	2	3RV1923-2DA00		1	1 unit	41E
RV1923-2DA00	With EMERGENCY- STOP rotary operating mechanism, lockable in 0 position	IP55 (front side)	N and PE/ground	72 (for motor starter protector + lateral auxiliary switch <sup>2)</sup> + auxiliary release)	S00, S0	2	3RV1923-2GA00		1	1 unit	41E

<sup>1)</sup> The rear cable glands cannot be used on 3RV2.11-...2. and 3RV2.21-...2. devices with spring-type terminals.

<sup>2)</sup> Only valid for lateral auxiliary switches with two auxiliary contacts.

<sup>&</sup>lt;sup>3)</sup> If required, an additional N terminal can be mounted (e.g. 8WA1011-1BG11).

Not suitable for 3RV2.11-...2. and 3RV2.21-...2. devices with spring-type terminals.

# SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers

Accessories

# **Enclosures and front plates**

	Version	Degree of protection	For 3RV20 to 3RV24 motor starter protectors	SD	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
			Size	d					
Front plates									
	Molded-plastic front plates with rooperating mechanism, lockable in 0 position	otary IP55 (front side)	S00 to S3	•	3RV1923-4B		1	1 unit	41E
	For actuation of 3RV2 motor starter protectors in any enclosure								
3RV1923-4B +	Molded-plastic front plates with EMERGENCY-STOP rotary operation mechanism, red/yellow, lockable in 0 position	IP55 ing (front side)	S00 to S3	2	3RV1923-4E		1	1 unit	41E
3RV1923-4G	EMERGENCY-STOP actuation of 3RV2 motor starter protectors in any enclosure	,							
	Holders for front plates		S00, S0	<b>&gt;</b>	3RV1923-4G		1	1 unit	41E
	Holder is mounted on front plate, mo starter protector with and without accessories is snapped in.	otor							
	Version	Rated control supply voltage $U_s$	For 3RV20 to 3RV24 motor starter protectors	SD	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
		V	Size	d					
Indicator lights								·	_
	Indicator lights For all enclosures and front plates  • With LED lamp for versions 110 120 V, with glow lamp for versions 220 500 V  • With colored lenses red, green,	110 120 220 240 380 415 480 500	S00 to S3	5 5 5 5	3RV1903-5B 3RV1903-5C 3RV1903-5E 3RV1903-5G		1 1 1	1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E
3RV1903-5B	yellow-orange and clear								

3RV29 infeed system

#### Overview

The 3RV29 infeed system is a convenient means of energy supply and distribution for a group of several motor starter protectors or complete load feeders with screw or spring-type terminals in sizes S00 and S0. Motor starter protectors or load feeders with a rated current of maximum 32 A each can be used. 3RV21, 3RV27 and 3RV28 motor starter protectors/circuit breakers cannot be deployed in this system.

The system is based on a basic module complete with a lateral incoming unit (three-phase busbar with infeed). This infeed with spring-type terminals is mounted on the right or left, depending on the version, and can be supplied with a maximum conductor cross-section of 25 mm² (with end sleeve). A basic module has two sockets onto each of which a motor starter protector can be snapped.


Expansion modules (three-phase busbars for system expansion) are available for extending the system. The individual modules are connected through an expansion plug.

The electrical connection between the three-phase busbars and the motor starter protectors is implemented through plug-in connectors. The complete system can be mounted on a TH 35

standard mounting rail to IEC 60715, and can be expanded as required up to a maximum current carrying capacity of 63 A.

The system is mounted extremely quickly and easily thanks to the simple plug-in technique. Thanks to the lateral infeed, the system also saves space in the control cabinet. The additional height required for the infeed unit is only 30 mm. The alternative infeed possibilities on each side offer a high degree of flexibility for configuring the control cabinet: Infeed on left-hand or right-hand side as well as infeed on one side and outfeed on the other side to supply further loads are all possible. A terminal block with spring-type connections in combination with a standard mounting rail enables the integration of not only SIRIUS motor starter protectors but also single-phase, 2-phase and 3-phase components such as 5SY miniature circuit breakers or SIRIUS relay components.

The 3RV29 infeed system is approved in accordance with IEC to 500 V. It is also UL-approved and authorized for "Self-Protected Combination Motor Controller" (Type E starter) as well as for Type F starter (Type E starter + contactor).



SIRIUS 3RV29 infeed systems

#### 3RV29 infeed system

#### 1) Three-phase busbars with infeed

A three-phase busbar with infeed unit is required for connecting the incoming supply. These modules comprise one infeed module and two sockets which each accept one motor starter protector. A choice of two versions with infeed on the left or right is available. The infeed is connected to spring-type terminals. They permit an infeed with conductor cross-sections of up to 25 mm² with end sleeve. An end cover is supplied with each module.

#### 2 Three-phase busbars for system expansion

The three-phase busbars for system expansion support expansion of the system. There is a choice of modules with two or three sockets. The system can be expanded as required up to a maximum current carrying capacity of 63 A. An expansion plug is supplied with each module.

#### 3 a Expansion plug

The expansion plug is used for electrical connection of adjacent three-phase busbars. The current carrying capacity of this plug equals 63 A. One expansion plug is supplied with each three-phase busbar for system expansion. Additional expansion plugs are therefore only required as spare parts.

#### ③b Extra-wide expansion plug

The wide expansion plug makes the electrical connection between two three-phase busbars, thus performing the same function as the 3RV2917-5BA00 expansion plug; the electrical characteristics (e.g. a current carrying capacity of 63 A) are identical.

The 3RV2917-5E expansion plug is 10 mm wider than the 3RV2917-5BA00 expansion plug, hence in the plugged state there is a distance of 10 mm between the connected three-phase busbars. This distance can be used to lay the auxiliary current and control current wiring ("wiring duct"). The motor starter protector and contactor can be wired from underneath, which means that the complete cable duct above the system can be omitted.

#### (4) End cover

The end cover is used to cover the three-phase busbar at the open end of the system. This cover is therefore only required once for each system. An end cover is supplied with each three-phase busbar system with infeed. Further end covers are therefore only required as spare parts.

#### **5) Terminal block for device infeed**

A new addition to the system is a connector for outfeeding to a device slot within a module. This offers the option not only of connecting three-phase loads to the system, but also of integrating single-phase loads into the infeed system.

#### 6 Plug-in connector

The plug-in connector is used for the electrical connection between the three-phase busbar and the 3RV2 motor starter protector. These plug-in connectors are available for screw or spring-type terminals.

#### (7) Contactor base

Load feeders can be assembled in the system using the S00 and S0 contactor base. The contactor bases are suitable for contactors sizes S00 and S0 with spring-type and screw terminals and are simply snapped onto the three-phase busbars. Direct-on-line starters and reversing starters are possible. One contactor base is required for direct-on-line starters and two are required for reversing starters.

To assemble load feeders for reversing starters, the contactor bases can be arranged alongside each other (90 mm overall width). In this case the mechanical interlocking of the contactors is possible. The S0 contactor bases are also suitable for soft starters size S00 and S0 with screw terminal.

The infeed system is designed for mounting onto a TH 35 standard mounting rail with 7.5 mm overall depth. This standard mounting rail gives the contactor base a stable mounting surface to sit on. If standard mounting rails with a depth of 15 mm are used, the spacer connected to the bottom of the contactor base must be knocked out and plugged into the standard mounting rail mating piece, which is also located on the underside. Then the contactor base also has a stable mounting surface. When standard mounting rails with a depth of 7.5 mm are used, the spacer has no function and can be removed.

The link modules are used for direct start load feeders, in which case the use of a contactor base is not absolutely necessary. Motor starter protector and contactor assemblies can then be directly snapped onto the sockets of the three-phase busbars. For feeders of sizes S00 and S0, the corresponding 3RA1921-1...., 3RA2911-2...., 3RA2921-1.... or 3RA2921-2.... link modules should generally be used.

#### ® Terminal block

The 3RV2917-5D terminal block enables the integration of not only SIRIUS motor starter protectors but also single-phase, 2-phase and 3-phase components. The three phases can be fed out of the system using the terminal block; which means that single-phase loads can also be integrated in the system. The terminal block is plugged into the slot of the expansion plug and thus enables outfeeding from the middle or end of the infeed system. The terminal block can be rotated through 180° and be locked to the support modules of the infeed system. In addition, the 45 mm wide TH 35 3RV1917-7B standard mounting rail option for screwing onto the support plate facilitates plugging the single-phase, two-phase and three-phase components onto the infeed system.

3RV29 infeed system

# Technical specifications

#### More information

Manual "SIRIUS – SIRIUS 3RV2 Motor Starter Protectors", see https://support.industry.siemens.com/cs/ww/en/view/60279172

General data					
Туре					3RV29.7
Size					S00, S0
Standards					
• IEC 60947-2					✓
• IEC 60947-4-1					✓
• UL 508/UL 609	47-4-1				✓
Rated current $I_{\rm r}$	1			Α	63
Permissible rate	ed current at i	nside temperature	of control cabinet		
Motor starter protectors	Size	Rated current	Inside temperature of control cabinet		
• 3RV2.11	S00	14 A	60 °C	%	100
		> 14 16 A	40 °C 60 °C	%	100 87
• 3RV2.21	S0	16 A	60 °C	%	100
		> 16 25 A	40 °C 60 °C	%	100 87
		> 25 32 A	40 °C	%	87
Permissible amb	bient tempera	ture			
• Storage/transp	ort			°C	-50 +80
<ul> <li>Operation</li> </ul>				°C	–20 +60
Rated operation	al voltage <i>U</i> e				
<ul> <li>Acc. to IEC</li> </ul>		10 % overvolta	ge	V AC	500
		5 % overvoltag	е	V AC	525
Acc. to UL/CSA				V AC	600
Rated frequency				Hz	50/60
Rated impulse v		age <i>U<sub>imp</sub></i>		kV	6
Short-circuit str					Corresponds to the mounted motor starter protector or load feeder
Degree of protect	ction acc. to If	EC 60529			IP20 (In the terminal compartment of the infeed without connected IP00 conductor)
Touch protectio	n acc. to IEC 6	60529			Finger-safe

Conductor cross-sections				
Туре		Three-phase busbar with infeed 3RV2917-1A, 3RV2917-1E	Terminal block 3RV2917-5D	Terminal block for device infeed 3RV2917-5FA00
Conductor cross-sections (min./max.)				
Solid or stranded	mm <sup>2</sup>	4 25	1.5 6	1 10
• Finely stranded with end sleeve	$\rm mm^2$	4 25	1.5 4	1 6
• Finely stranded without end sleeve	mm <sup>2</sup>	6 25	1.5 6	

10 ... 3

AWG

-- No

• AWG cables

✓ Yes

18 ... 8

15 ... 10

# SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers

# 3RV29 infeed system

Only 25 mineral system									
Selection and ordering	ig data								
	Туре	Version	For 3RV20, 3RV23, 3RV24 motor starter protectors Size	SD	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
Three-phase busbars	with infeed		0.20						
3RV2917-1A	Three-phase busbars with infeed incl. 3RV2917-6A end cover	For 2 motor starter protectors with screw or spring-type terminals  • With infeed on the left  • With infeed on the right	S00, S0 S00, S0	2 2	3RV2917-1A 3RV2917-1E		1	1 unit 1 unit	41E 41E
Three-phase busbars	for system expansion	on							
dia caia			\$00, \$0 \$00, \$0	2	3RV2917-4A 3RV2917-4B		1	1 unit 1 unit	41E 41E
3RV2917-4A Plug-in connectors									
3RV2917-5AA00	Plug-in connectors to make contact with motor starter protectors	<ul><li>For spring-type terminals</li><li>Single-unit packaging</li><li>Multi-unit packaging</li></ul>	S00 <sup>1)</sup> S0 <sup>2)</sup> S00 <sup>1)</sup> S0 <sup>2)</sup>	2 2 2 2	Spring-type terminals 3RV2917-5AA00 3RV2927-5AA00 3RV2917-5A 3RV2927-5A	8	1 1 1	1 unit 1 unit 10 units 10 units	41E 41E 41E 41E
		For screw terminals			Screw terminals	<b>+</b>			
3RV2917-5CA00		<ul><li>Single-unit packaging</li><li>Multi-unit packaging</li></ul>	S00 <sup>1)</sup> S0 <sup>2)</sup> S00 <sup>1)</sup> S0 <sup>2)</sup>	2 2 2 2	3RV2917-5CA00 3RV1927-5AA00 3RV2917-5C 3RV1927-5A		1 1 1	1 unit 1 unit 10 units 10 units	41E 41E 41E 41E
1) $I > 14$ A, please note der	rating.		<sup>2)</sup> I > 16	A, ple	ase note derating.				
	Туре	Version	For contactors	SD	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
Comtostante			Size	d					
Contactor bases	Contactor bases for mounting direct-on-line or reversing starters	Single-unit packaging	S00 S00, S0	2 2	3RV2917-7AA00 3RV2927-7AA00		1	1 unit 1 unit	41E 41E
3RV2927-7AA00									

# 3RV29 infeed system

	Туре	Version	SD	Article No.	Price per PU	PU	PS*	PG
					perro	(UNIT, SET, M)		
			d					
Terminal blocks								
3RV2917-5D	<b>Terminal blocks</b> for integration of single-phase, two-phase and three-phase components	Single-unit packaging	2	3RV2917-5D		1	1 unit	41E
TH 35 standard moun	ting rails, width 45 mm							
	TH 35 standard mounting rails acc. to IEC 60715, width 45 mm For mounting onto three-phase busbars	Single-unit packaging	2	3RV1917-7B		1	1 unit	41E
3RV1917-7B								
Extra-wide expansion				ADV0042 25			4 4	
	Extra-wide expansion plugs As accessory	Single-unit packaging	2	3RV2917-5E		1	1 unit	41E
3RV2917-5E Expansion plugs								
Expansion plags	<b>Expansion plugs</b> <sup>1)</sup> As spare part	Single-unit packaging	2	3RV2917-5BA00		1	1 unit	41E
3RV2917-5BA00								
End covers	End covers <sup>2</sup> ) As spare part	Multi-unit packaging	2	3RV2917-6A		100	10 units	41E
3RV2917-6A								
Terminal blocks for d	evice infeed							
3RV2917-5FA00	Terminal blocks for device infeed	Single-unit packaging	2	3RV2917-5FA00		1	1 unit	41E

The expansion plug is included in the scope of supply of the 3RV2917-4. three-phase busbars for system expansion.
 The end cover is included in the scope of supply of the 3RV2917-1. three-phase busbars with infeed system.

SIRIUS 3RV1 Motor Starter Protectors/Circuit Breakers


## For fuse monitoring

#### Technical specifications

See pages 7/10, 7/12, 7/14, 7/18, 7/19 and 7/22

#### Selection and ordering data

#### Without auxiliary switches



#### Note:

The auxiliary switch required for signaling must be ordered separately.

#### Accessories

Accessories								
	Version	Contacts	SD	Screw terminals	<b>+</b>	PU (UNIT, SET, M)	PS*	PG
			d	Article No.	Price per PU			
Mountable aux	(iliary switches (essential accessories)							
00 00	<b>Transverse auxiliary switches</b> With screw terminals, mountable on front	1 NO + 1 NC	•	3RV2901-1E		1	1 unit	41E
3RV2901-1E								
	Lateral auxiliary switches With screw terminals, mountable on the left	1 NO + 1 NC	•	3RV2901-1A		1	1 unit	41E
3RV2901-1A								

For distance protection

# Technical specifications

See page 7/23

# Selection and ordering data

## Voltage transformer circuit breakers with transverse auxiliary switches (1 CO)

	Rated current	Thermal overload releases	Instanta- neous overcurrent release	Auxiliary switch integrated in the motor starter protector, transverse	Short-circuit breaking capacity at 400 V AC	SD	Screw terminals	<b>+</b>	PU (UNIT, SET, M)	PS*	PG
	$I_{n}$	4	<i>I</i> >		$I_{ m CU}$		Article No.	Price per PU			
·	Α	Α	Α		kA	d					
Size S00											
3RV1611-1.G14	1.4 2.5 3	1.4 2.5 3	6 10.5 20	1 CO 1 CO 1 CO	50 50 50	5	3RV1611-1AG14 3RV1611-1CG14 3RV1611-1DG14		1 1 1	1 unit 1 unit 1 unit	41E 41E 41E

# Accessories

3RV2901-1A

	Version	Contacts	SD	Screw terminals	<b>(1)</b>	PU (UNIT, SET, M)	PS*	PG
			d	Article No.	Price per PU			
Mountable aux	xiliary switches for other signaling pur	poses						
	<b>Lateral auxiliary switches</b> With screw terminals, mountable on the left	1 NO + 1 NC	•	3RV2901-1A		1	1 unit	41E

SIRIUS 3RV1 Molded Case Motor Starter Protectors up to 800 A

#### General data

#### Overview

#### More information

Home page, see www.siemens.com/sirius-circuit-breaker



SIRIUS 3RV1063-7AL10 molded case motor starter protector

The 3RV10 and 3RV13 molded case motor starter protectors for up to 800 A are compact, current-limiting motor starter protectors which can be used above all in motor feeders for special voltages of 440 V, 480 V, 550 V and 690 V. They are used for switching and protecting three-phase motors and other loads with rated currents up to 800 A.

#### Note:

For motor feeders above 100 A and at 400 V and 500 V, the 3VL molded case motor starter protectors must be used, see Catalog LV 10.

#### Type of construction

The molded case motor starter protectors are available in 4 widths:

- 3RV1353 width 90 mm, max. rated current 32 A at 550 V AC suitable for three-phase motors up to 22 kW
- 3RV1.6. width 105 mm, max. rated current 250 A at 690 V AC suitable for three-phase motors up to 160 kW
- 3RV1.7. width 140 mm, max. rated current 630 A at 690 V AC suitable for three-phase motors up to 315 kW
- 3RV1.83 width 210 mm, max. rated current 800 A at 690 V AC suitable for three-phase motors up to 500 kW

The 3RV1 molded case motor starter protectors for up to 800 A can be mounted in horizontal, vertical or lying arrangement directly on a mounting plate or mounting rail. Their rated data are adversely affected as the result.

The phase barriers for better insulation between the phases are included in the scope of supply, and it is essential to use them.

The motor starter protectors can be supplied through top and bottom terminals without impairing their function, enabling them to be installed in any type of switchgear without any further steps

#### Connection methods

The 3RV1 molded case motor starter protectors up to 800 A are suitable solely for screw connection.



#### Screw terminals

The terminals are indicated in the corresponding tables by the symbols shown on orange backgrounds.

#### Article No. scheme

Product versions		Article number				
Molded case motor starter	protectors	3RV1 🗆 🗆 🗆 —				
Type of motor starter protector circuit breaker	or/ e. g. 0 = for motor protection					
Rated current	e. g. 6 = 100 A					
Breaking capacity	e. g. 3 = standard switching capacity					
Setting range for overload release	e. g. 7A = 40 100 A					
Trip class (CLASS)	e.g. L = CLASS 10A, 10, 20, 30					
Connection methods	e. g. 1 = screw terminals					
With or without auxiliary swite	ch e. g. 0 = without					
Special versions						
Example		3RV1 0 6 3 -	7 A L	1 0		

#### Note:

The Article No. scheme shows an overview of product versions for better understanding of the logic behind the article numbers.

For your orders please use the article numbers quoted in the selection and ordering data.

# Motor Starter Protectors/Circuit Breakers SIRIUS 3RV1 Molded Case Motor Starter Protectors up to 800 A

General data

#### Benefits

- High short-circuit breaking capacity in the feeder
- Optimum usability in motor feeders for the special voltages 440 V, 480 V, 550 V and 690 V
- Compact design

- The releases are available both in purely magnetic (up to 32 A) and in solid-state versions (100 A to 800 A).
- Available for motor or starter protection (short-circuit protection alone)

#### Application

#### Operating conditions

The 3RV1 molded case motor starter protectors for up to 800 A can be operated at ambient temperatures between -25  $^{\circ}$ C and +70  $^{\circ}$ C. They can be used according to IEC 60721-2-1 in the most difficult environmental conditions with a hot and damp climate.

Since operational currents, starting currents and current peaks are different even for motors with identical power ratings due to the inrush current, the motor ratings in the selection tables are only guide values. The specific rated and start up data of the motor to be protected is always paramount to the choice of the most suitable molded case motor starter protectors.

The 3RV1 molded case motor starter protectors up to 800 A have not been tested for use with frequency converters. The possibility of premature tripping in such applications cannot therefore be ruled out.

#### Possible uses

The 3RV1 molded case motor starter protectors for up to 800 A are suitable as switching and protection devices for motors. The following versions are available:

- For motor protection;
  - the overload and short-circuit releases are designed for optimized protection and direct-on-line starting of three-phase AC squirrel-cage motors. The motor starter protectors have an electronic release which not only provides short-circuit and overload protection but is also sensitive to phase failure and phase asymmetry and offers protection in the event of rotor blockage.
- For starter combinations;
  - these molded case motor starter protectors are used for short-circuit protection in combinations of circuit breaker, motor contactor and overload relay. They are equipped with a purely magnetic release (up to 32 A) or a solid-state release (100 A to 800 A).

#### Standards and specifications

The overcurrent releases for motor protection comply with IEC 60947-4-1. Isolating features are also compliant with IEC 60947-2.

The 3RV1 molded case motor starter protectors comply in addition with IEC 60068-2-6 (shock and vibration strength) and are certified for the specifications of the major marine classification societies:

- RINA
- Det Norske Veritas
- Bureau Veritas
- Lloyds Register of Shipping
- Germanischer Lloyd
- · American Bureau of Shipping

# Use of SIRIUS protection devices in conjunction with IE3/IE4 motors

#### Note:

For the use of 3RV1 motor starter protectors/circuit breakers in conjunction with highly energy-efficient IE3/IE4 motors, please observe the information on dimensioning and configuring, see Application Manual.

For more information, see Preface on page 7.

# SIRIUS 3RV1 Molded Case Motor Starter Protectors up to 800 A

# General data

#### Technical specifications

#### More information

Configuration Manual "SIRIUS Configuration – Selection Data for Fuseless Load Feeders", see https://support.industry.siemens.com/cs/ww/en/view/40625241 Molded Case Circuit Breakers", see https://support.industry.siemens.com/cs/ww/en/view/35681461

General data										
Туре		3RV1063	3RV1073	3RV1083	3RV1353	3RV1363	3RV1364	3RV1373	3RV1374	3RV138
Dimensions										
•w = 1   [ ]	mm	105	140	210	90	105	105	140	140	210
• H	mm	205	205	268	130	205	205	205	205	268 159
Standard	mm	139	139 7-2, EN 609	159	102	139	139	139	139	159
Motor protection		√	-2, LN 009	41-2						
Starter combinations					1					
Rated current I <sub>n</sub>	A	160	400	630	160	250		400, 630		630, 800
Number of poles		3	100	000	100	200		400, 000		000, 000
Rated operational voltage U <sub>e</sub> 50 60 Hz AC	V	690								
Rated impulse withstand voltage $U_{\text{imp}}$	V	8								
Rated insulation voltage U <sub>i</sub>	V	1 000			800	1 000				
Test voltage at industrial frequency	V	3 500			3 000	3 500				
for 1 min	•	0 000			0 000	0 000				
Rated ultimate short-circuit breaking capacity $I_{cu}$										
• At 220/230 V AC, 50 60 Hz	kA	200			120	200				
• At 380/415 V AC, 50 60 Hz	kA	120		100	85	120	200	120	200	100
• At 440 V AC, 50 60 Hz	kA	100		80	75	100	180	100	180	80
• At 500 V AC, 50 60 Hz	kA	85		65	50	85	150	85	150	65
• At 550 V AC, 50 60 Hz	kA			00	35		150	00	150	0.0
• At 690 V AC, 50 60 Hz	kA	70		30	10	70	80	70	80	30
Rated service short-circuit breaking	N/1	70		30	10	70	00	70	00	30
capacity $I_{cs}$ (% of $I_{cu}$ )										
• At 220/230 V AC, 50 60 Hz	%	100		75	100					75
• At 380/415 V AC, 50 60 Hz	%	100		75		100				75
• At 440 V AC, 50 60 Hz	%	100		75		100				75
• At 500 V AC, 50 60 Hz	%	100		75		100		100 <sup>1)</sup> /75 <sup>2)</sup>	100	75
• At 690 V AC, 50 60 Hz	%	100		75		100		100 <sup>1)</sup> /50 <sup>2)</sup>	100	75
Rated short-circuit making capacity (415 V)	kA	264		220	187	264	440	264	440	220
Break time (415 V at I <sub>cu</sub> )	ms	5	6	7	3	5		6		7
Category (IEC 60947-2)		Α	B (400 A), A (630 A)	В	А			B (400 A), A (630 A)		В
Isolating features		/	(,					(		
Trip class CLASS		10A, 10, 2	20, 30							
Releases		. , ,								
Magnetic type					1					
• Electronic (motor protection)		1			3)					
• Electronic (starter combinations)						1				
Permissible ambient temperature										
Operation	°C	-25 +70	) <sup>4)</sup>							
• Storage	°C	-40 +70								
Mechanical endurance										
Operating cycles		20 000			25 000	20 000				
Operating cycles per hour		240	120		240			120		
Electrical endurance										
Operating cycles		8 000	7 000	5 000	8 000			7 000		5 000
Operating cycles per hour (415 V AC)		120	60		120			60		
/ Has this function				1)	io applica fa	000/4070	701140			

<sup>✓</sup> Has this function

<sup>--</sup> Does not have this function

<sup>1)</sup> Value applies for 3RV1373-7GN10 molded case motor starter protectors.

 $<sup>^{\</sup>rm 2)}$  Value applies for 3RV1373-7JN10 molded case motor starter protectors.

<sup>3)</sup> For overload protection of the motors, appropriate overload relays must be used.

<sup>4)</sup> From 50 °C, derating applies in some cases.

# Motor Starter Protectors/Circuit Breakers SIRIUS 3RV1 Molded Case Motor Starter Protectors up to 800 A

General data

Main circuit terminals						
Туре		3RV1353	3RV1.6.	3RV1.7.	3RV1083-7JL10, 3RV1383-7JN10	3RV1383-7KN10
Terminal dimensions						
Described by the second of the						
Front-accessible standard terminals						
Busbars/cable lug						
Number	Unit(s)	11			2	
Dimensions						
• W	mm	20	25	35	40	50
• D • H	mm mm	5 7.5	8 9.5	10 11	5 12	
Lock hasp diameter	mm	6.5	8.5	10.5	7	
Front-extended terminals						
Busbars						
Number	Unit(s)	1		2		
Dimensions						
• W	mm	20		30	40	50
● D ● Lock hasp diameter	mm mm	4 8.5	10 10	7 11	5	5 14
Cable lug		0.0	10			1-7
Number	Unit(s)	1		2		
Dimensions	(-)	·		_		
• W	mm	20		30	40	50
Lock hasp diameter	mm	8.5	10	11		14
Front-extended cable terminals for copper cable						
Busbars, flexible						
Number	Unit(s)	1				
Dimensions W x D x N						
• W	mm	13	15.5	24		
<ul><li>D</li><li>N (= number of laminations)</li></ul>	mm mm	0.5 10	0.8	1		
Cable lug, flexible						
Number	Unit(s)	1 or 2				
Dimensions						
• For 1 unit	mm <sup>2</sup> mm <sup>2</sup>	1 70	2.5 120	16 240		
• For 2 units	mm <sup>2</sup>	1 50	2.5 95	16 150		
Cable lug, rigid						
Number	Unit(s)	1		1 or 2		
Dimensions	2		0.5	40 00-		
<ul><li>For 1 unit</li><li>For 2 units (for outside mounting)</li></ul>	mm <sup>2</sup> mm <sup>2</sup>	1 95	2.5 185	16 300 120 240		
Rear terminals	111111			,20 240		
Busbars						
Number	Unit(s)	1		2		
Dimensions	-:(0)					
• W	mm	20		30	40	50
• D	mm	4	10	7 11	5	
<ul> <li>Lock hasp diameter</li> </ul>	mm	8.5		11	14	

SIRIUS 3RV1 Molded Case Motor Starter Protectors up to 800 A

# General data

Auxiliary switches		
Туре		3RV1991-1.A0
Rated operational current I <sub>e</sub>		
• At 250 V AC/DC		
<ul> <li>At AC-14 (utilization category according to IEC 60947-5-1)</li> <li>Supply voltage 125 V</li> <li>Supply voltage 250 V</li> </ul>	A A	6 5
<ul> <li>At DC-13 (utilization category according to IEC 60947-5-1)</li> <li>Supply voltage 125 V</li> <li>Supply voltage 250 V</li> </ul>	A A	0.3 0.15
• At 24 V DC		
- Supply voltage 24 V	mA	≥ 0.75
- Supply voltage 5 V	mA	≥1


Auxiliary releases					
		Power cons	umption during p	oick-up	
Molded case motor starter protectors		3RV1353		3RV1.6., 3R	V1.7., 3RV1.83
Version		AC	DC	AC	DC
Undervoltage releases		3RV1952-1A	.0	3RV1982-1 <i>A</i>	<b>\.</b> 0
• 24 30 V AC/DC • 110 127 V AC/110 125 V DC • 220 240 V AC/220 250 V DC		1.5 VA 2 VA 2.5 VA	1.5 W 2 CO 2.5 W	6 VA 6 VA 6 VA	3 W 3 W 3 W
Opening times	ms	15	15	≤ 25	≤ 15
Shunt releases		3RV1952-1E	.0	3RV1982-1E	.0
• 24 30 V AC/DC • 110 127 V AC/110 125 V DC • 220 240 V AC/220 250 V DC		50 VA 50 VA 50 VA	50 W 50 W 50 W	150 VA 150 VA 150 VA	150 W 150 W 150 W
Opening times	ms	15	15	15	15

SIRIUS 3RV1 Molded Case Motor Starter Protectors up to 800 A

**IE3/IE4 ready** For motor protection

# Selection and ordering data

# CLASS 10A, 10, 20, 30; without auxiliary switch



#### With electronic releases



Standa	ard sw	vitching/	ı capacity,	adj	ustable	short-circuit a	and overlo	oad release, TU 4

Ü	100	40 100	600 1 300	120	20	3RV1063-7AL10	1	1 unit	41E
	160	64 160	960 2 080	120	20	3RV1063-7CL10	1	1 unit	41E
	200	80 200	1 200 2 600	120	20	3RV1063-7DL10	1	1 unit	41E
	400	160 400	2 400 5 200	120	20	3RV1073-7GL10	1	1 unit	41E
	000	050 000	0.700 0.400	400	00	0D)/4000 7 II 40		4	445
	630	252 630	3 780 8 190	100	20	3RV1083-7JL10	1	1 unit	41E
p									

3RV10.3-7.L10

TU = trip unit (release)


Further accessories can be ordered separately (see "Accessories" page 7/69 onwards).

SIRIUS 3RV1 Molded Case Motor Starter Protectors up to 800 A

For starter combinations IE3/IE4 ready

#### Selection and ordering data

## Without auxiliary switches



## With magnetic releases



3RV1353-6.P10

Stand	ard switching	r capacity, non-adju	ıstable short-	circuit rele	ase, TU 1					
1	Without	13	85	20	3RV1353-6AP10		1			
1.6	Without	21	85	20	3RV1353-6BP10		1			
2	Without	26	85	20	3RV1353-6CP10		1			
3.2	Without	42	85	20	3RV1353-6DP10		1			
4	Without	52	85	20	3RV1353-6EP10		1			
5	Without	65	85	20	3RV1353-6FP10		1			
6.5	Without	85	85	20	3RV1353-6GP10		1			
8.5	Without	111	85	20	3RV1353-6HP10		1			
12.5	Without	163	85	20	3RV1353-6JP10		1			
Standard switching capacity, adjustable short-circuit release, TU 2										
20	Without	120 240	85	20	3RV1353-6LM10		1			
32	Without	192 384	85	20	3RV1353-6MM10		1			

#### With electronic release



al and an and	
2	

3RV1	37	.N10	

562							
lard switching	capacity, adjustable	short-circu	ıit release,	TU 3			
Without Without Without	100 1 000 160 1 600 250 2 500	120 120 120	20 20 20	3RV1363-7AN10 3RV1363-7CN10 3RV1363-7EN10	1 1 1	1 unit 1 unit 1 unit	41E 41E 41E
Without Without	400 4 000 630 6 300	120 120	20 20	3RV1373-7GN10 3RV1373-7JN10	1	1 unit 1 unit	41E 41E
Without Without	630 6 300 800 8 000	100 100	20 20	3RV1383-7JN10 3RV1383-7KN10	1 1	1 unit 1 unit	41E 41E
ased switching	g capacity, adjustabl	TU 3					
Without Without Without Without	100 1 000 160 1 600 250 2 500 400 4 000	200 200 200 200	20 20 20 20	3RV1364-7AN10 3RV1364-7CN10 3RV1364-7EN10 3RV1374-7GN10	1 1 1	1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E
	Without	Seed switching capacity, adjustable	Without         100 1 000         120           Without         160 1 600         120           Without         160 1 600         120           Without         250 2 500         120           Without         400 4 000         120           Without         630 6 300         120           Without         630 6 300         100           Without         800 8 000         100           ased switching capacity, adjustable short-circ           Without         100 1 000         200           Without         160 1 600         200           Without         250 2 500         200	Hard switching capacity, adjustable short-circuit release,           Without         100 1 000         120         20           Without         160 1 600         120         20           Without         250 2 500         120         20           Without         400 4 000         120         20           Without         630 6 300         120         20           Without         630 6 300         100         20           Without         800 8 000         100         20           ased switching capacity, adjustable short-circuit release,           Without         100 1 000         200         20           Without         160 1 600         200         20           Without         250 2 500         200         20	Without   100   1 000   120   20   3RV1363-7AN10	Mithout   100   1 000   120   20   3RV1363-7AN10   1	Without   100   1 000   120   20   3RV1363-7AN10   1   1 unit   1 unit   Without   250   2 500   120   20   3RV1363-7EN10   1   1 unit   1 unit   1 unit   2 unit

TU = trip unit (release)

Further accessories can be ordered separately (see "Accessories" page 7/69 onwards).

# SIRIUS 3RV1 Molded Case Motor Starter Protectors/Circuit Breakers Accessories

Mountable accessories

Selection and orde	ering data									
	Туре	Version		For molded case motor starter protectors	SD	Screw terminals	<b>⊕</b>	PU (UNIT, SET, M)	PS*	PG
					d	Article No.	Price per PU			
Auxiliary switches										
13/12/149	<b>Auxiliary switches</b> For mounting on the front	1 signaling sv + 1 tripped si (250 V AC/DC	ignal	3RV1353, 3RV1.6.	20	3RV1991-1AA0		1	1 unit	41E
		3 signaling sy + 1 tripped si (250 V AC/DC		3RV1.83	20	3RV1991-1BA0		1	1 unit	41E
		3 signaling switches Off-On + 1 tripped signal (24 V DC)			20	3RV1991-1CA0		1	1 unit	41E
3RV1991-1AA0	Connection cables for auxiliary switches	Length 2 m, 6	6-pole	3RV1353, 3RV1.6.	20	3RV1991-1FA0		1	1 unit	41E
				3RV1.83						
	Туре	Rated control voltage $U_{\rm S}$ AC 50/60 Hz	l supply DC	For molded case motor starter protectors	SD	Screw terminals	<b>(+)</b>	PU (UNIT, SET, M)	PS*	PG
		V	V		d	Article No.	Price per PU			
Auxiliary releases										
17/19/10	Undervoltage releases For mounting on the front	220 240	24 30 110 125 220 250	3RV1353	20 20 20	3RV1952-1AA0 3RV1952-1AD0 3RV1952-1AE0		1 1 1	1 unit 1 unit 1 unit	41E 41E 41E
		24 30 110 127 220 240	24 30 110 125 220 250	3RV1.6.  3RV1.83	20 20 20	3RV1982-1AA0 3RV1982-1AD0 3RV1982-1AF0		1 1 1	1 unit 1 unit 1 unit	41E 41E 41E
3RV1952-1AA0	Shunt releases	24 30	24 30	3RV1353	20	3RV1952-1EA0		1	1 unit	41E
00000	For mounting on the front		110 125 220 250		20 20	3RV1952-1ED0 3RV1952-1EF0		1	1 unit 1 unit	41E 41E
		24 30 110 127 220 240	24 30 110 125 220 250	3RV1.6.  3RV1.83	20 20 20	3RV1982-1EA0 3RV1982-1ED0 3RV1982-1EF0		1 1 1	1 unit 1 unit 1 unit	41E 41E 41E
3RV1952-1EA0	Connection cables for	Length 2 m		3RV1353,	20	3RV1992-1FA0		1	1 unit	41E
	undervoltage and shunt releases			3RV1.6.  3RV1.83	۷	011V 1992-1FAU		1	i uiiit	41L

3RV1.83

# SIRIUS 3RV1 Molded Case Motor Starter Protectors/Circuit Breakers Accessories

Rotary operating mechanisms, mounting accessories

Selection and orde	ring data								
	Version		For molded case motor starter protectors	SD	Screw terminals	<b>(1)</b>	PU (UNIT, SET, M)	PS*	PG
				d	Article No.	Price per PU			
Rotary operating m	echanisms								
Tau o o o o o o o o o o o o o o o o o o o	Lever-type rotary operating mechanisms	with adjustable distance, with lock/door interlocking (padlocks are not included in scope of supply)	3RV1353 3RV1.6., 3RV1.7. 3RV1.83	20 20 20	3RV1956-0BA0 3RV1976-0BA0 3RV1986-0BA0		1 1 1	1 unit 1 unit 1 unit	41E 41E 41E
3RV19.6-0BA0									
DOM THE STATE OF T	Motorized operating mechanisms	With stored energy mechanism, 220 250 V AC/DC	3RV1.6., 3RV1.7. 3RV1.83	20 20	3RV1976-3AP3 3RV1986-3AP3		1	1 unit 1 unit	41E 41E
3RV19.6-3AP3									
Connections	Connections	Front-extended (1 set = 6 units)	3RV1353 3RV1.6. 3RV1.7. 3RV1.83-7J.10 3RV1.83-7KN10	20 20 20 20 20 20	3RV1955-1AA0 3RV1965-1BA0 3RV1975-1CA0 3RV1985-1DA0 3RV1985-1EA0		1 1 1 1	1 unit 1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E 41E
3RV1975-1CA0		Rear (1 set = 3 units)	3RV1353 3RV1.6. 3RV1.7. 3RV1.83	20 20 20 20 20	3RV1955-3AA0 3RV1965-3AA0 3RV1975-3AA0 3RV1985-3AA0		1 1 1 1	1 unit 1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E
3RV1955-3AA0									
3RV1975-2AA0	Cable terminals	Front-extended (1 set = 6 units)	3RV1353 3RV1.6. 3RV1.77G.10 3RV1.73-7JN10	20 20 20 20 20	3RV1955-2AA0 3RV1965-2BA0 3RV1975-2CA0 3RV1975-2DA0		1 1 1 1	1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E

# **Overload Relays**

General data

## Overview

#### More information

Home page, see http://www.siemens.com/sirius-overloadrelays Industry Mall, see

- www.siemens.com/product?3RU2
- www.siemens.com/product?3RB3
- www.siemens.com/product?3RB2

#### Configuration Manuals, see

- "SIRIUS Configuration Selection Data for Fuseless Load Feeders", https://support.industry.siemens.com/cs/ww/en/view/40625241
- "Configuring SIRIUS Innovations Selection Data for Fuseless and Fused Load Feeders", https://support.industry.siemens.com/cs/ww/en/view/39714188












	and with any man			***	000000	
Features	3RU21	3RB30/3RB31	3RB20/3RB21	3RB22/3RB23	3RB24	Benefits
General data						
Sizes	S00 S3	S00 S3	S6 S12	S00 S12	S00 S12	Are coordinated with the dimensions, connections and technical characteristics of the other devices in the SIRIUS modular system (contactors, etc.,)
						Permit the mounting of slim and compact load feeders in widths of 45 mm (S00, S0), 55 mm (S2), 70 mm (S3), 120 mm (S6) and 145 mm (S10/S12); this does not include the current measuring modules for the 3RB22 to 3RB24 evaluation modules sizes S00 to S3
						Simplify configuration
Seamless current range	0.11 100 A	0.1 115 A	50 630 A	0.3 630 A (up to 820 A) <sup>1)</sup>	0.3 630 A (up to 820 A) <sup>1)</sup>	<ul> <li>Allows easy and consistent configuration with one series of overload relays (for small to large loads)</li> </ul>
Protection functio	ns					
Tripping due to overload	✓	<b>√</b>	<b>√</b>	✓	✓	Provides optimum inverse-time delayed protection of loads against excessive temperature rises due to overload
Tripping due to phase asymmetry	✓	✓	<b>✓</b>	✓	✓	<ul> <li>Provides optimum inverse-time delayed protection of loads against excessive temperature rises due to phase asymmetry</li> </ul>
Tripping due to phase failure	✓	✓	✓	✓	✓	<ul> <li>Minimizes heating of three-phase motors during phase failure</li> </ul>
Protection of single-phase loads	✓			✓	✓	<ul> <li>Enables the protection of single-phase loads</li> </ul>
Tripping due to overtemperature by integrated	2)	2)	2)	✓	✓	Provides optimum temperature-dependent protection of loads against excessive temperature rises, e.g. for stator-critical motors or in the event of insufficient coolant flow, contamination of the motor surface or long starting or braking operations
thermistor motor protection function						Eliminates the need for additional special equipment     Saves space in the control cabinet
						'
Tripping due to		1	,	/	✓	<ul><li>Reduces wiring outlay and costs</li><li>Provides optimum protection of loads</li></ul>
ground fault by		(only 3RB31)	(only 3RB21)	•	•	against high-resistance short circuits or ground faults due to moisture, condensed water, damage to the insulation material, etc.
internal ground-fault detection (can be activated)						Eliminates the need for additional special equipment
,						<ul> <li>Saves space in the control cabinet</li> </ul>
						<ul> <li>Reduces wiring outlay and costs</li> </ul>

- ✓ Available
- -- Not available

- Motor currents up to 820 A can be recorded and evaluated by a current measuring module, e.g. 3RB2906-2BG1 (0.3 to 3 A), in combination with a 3UF1868-3GA00 (820 A/1 A) series transformer. For 3UF18 transformers see page 10/22.
- $^{\rm 2)}$  The SIRIUS 3RN thermistor motor protection devices can be used to provide additional temperature-dependent protection.

## **Overload Relays**

#### General data



- ✓ Available
- -- Not available

## General data




	and one on	000000		******	000000	
Features	3RU21	3RB30/3RB31	3RB20/3RB21	3RB22/3RB23	3RB24	Benefits
Design of load fee	eders					
Short-circuit strength up to 100 kA at 690 V (in conjunction with the corresponding fuses or the corresponding motor starter protector)	<b>,</b>	<b>,</b>	<b>,</b>	<b>V</b>	<b>,</b>	<ul> <li>Provides optimum protection of the loads and operating personnel in the event of short circuits due to insulation faults or faulty switching operations</li> </ul>
Electrical and	✓	✓	1	<b>√</b> 1)	<b>✓</b> 1)	<ul> <li>Simplifies configuration</li> </ul>
mechanical matching to						<ul> <li>Reduces wiring outlay and costs</li> </ul>
3RT contactors						<ul> <li>Enables stand-alone installation as well as space-saving direct mounting</li> </ul>
Straight-through		(CO, CO)	<b>√</b> (S6)	(COO CO)	(COO CC)	Reduces the contact resistance (only one
transformers for main circuit <sup>2)</sup>		(S2, S3)	(56)	(S00 S6)	(S00 S6)	point of contact)  • Saves wiring costs (easy, no need for tools,
(in this case the						and fast)
cables are routed through the feed-						Saves material costs
through openings of the overload relay and connected directly to the box terminals of the contactor)						Reduces installation costs
Spring-type	<b>/</b>	<b>/</b>				<ul> <li>Enables fast connections</li> </ul>
connection system for main circuit <sup>2)</sup>	(S00, S0)	(S00, S0)				<ul> <li>Permits vibration-resistant connections</li> </ul>
ioi main onoun						<ul> <li>Enables maintenance-free connections</li> </ul>
Spring-type	✓	✓	✓	✓	✓	<ul> <li>Enables fast connections</li> </ul>
connection system for auxiliary						<ul> <li>Permits vibration-resistant connections</li> </ul>
circuits <sup>2)</sup>						<ul> <li>Enables maintenance-free connections</li> </ul>
Full starter functionality through IO-Link				-	<b>√</b>	Enables in combination with the SIRIUS 3RT contactors the assembly of communication-capable motor starters (direct-on-line, reversing and star-delta (wye-delta) starting)
Starter function					✓	<ul> <li>Integration of feeders via IO-Link in the control system up to 630 A or 820 A</li> </ul>

<sup>✓</sup> Available

<sup>--</sup> Not available

 <sup>1)</sup> Exception: up to size S3, only stand-alone installation is possible.
 2) Alternatively available for screw terminals.

## General data



Internal power supply

Supplied from an

external source via IO-Link

 Eliminates the need for configuration and connecting an additional control circuit

• Eliminates the need for configuration and

connecting an additional control circuit

<sup>✓</sup> Available

<sup>--</sup> Not available

<sup>1)</sup> SIRIUS 3RU11 and 3RU21 thermal overload relays use a bimetal contactor and therefore do not require a control supply voltage.

## General data



	the art are	ecccc.		*****	200000	
Features	3RU21	3RB30/3RB31	3RB20/3RB21	3RB22/3RB23	3RB24	Benefits
Other features (co	ontinued)					
Overload warning		-		<b>✓</b>	<b>/</b>	<ul> <li>Indicates imminent tripping of the relay directly on the device due to overload, phase asymmetry or phase failure through flickering of the LEDs or in the case of the 3RB24 as a signal through IO-Link</li> </ul>
						<ul> <li>Allows the imminent tripping of the relay to be signaled</li> </ul>
						<ul> <li>Allows measures to be taken in time in the event of inverse-time delayed overloading of the load for an extended period over the current limit</li> </ul>
						• Eliminates the need for an additional device
						<ul> <li>Saves space in the control cabinet</li> </ul>
						<ul> <li>Reduces wiring outlay and costs</li> </ul>
Analog output				<b>/</b>	✓	<ul> <li>Allows the output of an analog output signal for actuating moving-coil instruments, feeding programmable logic controllers or transfer to bus systems</li> </ul>
						<ul> <li>Eliminates the need for an additional measuring transducer and signal converter</li> </ul>
						<ul> <li>Saves space in the control cabinet</li> </ul>
						<ul> <li>Reduces wiring outlay and costs</li> </ul>

- ✓ Available
- -- Not available

## General data

## Overview of overload relays - matching contactors

Overview of o	verioaa re	eiays – m	accning co	viitactors							
	Overload	Current	Current		s (type, size, rating						
	relays	measure- ment	range	3RT201.	3RT202.	3RT203.		3RT105.	3RT106.		3TF68/3TF69
	Туре		А	S00 3/4/5.5/7.5	S0 5.5/7.5/11/15/18.5	S2 15/18.5/22/ 30/37	S3 37/45/55	S6 55/75/90	S10 110/132/160	S12 200/250	14 375/450
SIRIUS 3RU21	thermal o	verload re	elays			30/37					
اعلما	3RU211		0.11 16	1							
	3RU212	Integrated			✓						
0 0	3RU213	Integrated		-		✓					
00000	3RU214	Integrated	28 100				1				
3RU21											
SIRIUS 3RB30	electronic	overload	l relays <sup>1)</sup>								
	3RB301	Integrated		1							
Manage Committee of the	3RB302	Integrated			1						
© •	3RB303 3RB304	Integrated Integrated	12.5 80			✓	 ✓				
cocco	3HD3U4	integrated	32 115				•				
3RB30											
SIRIUS 3RB31	electronic	overload	l relays <sup>1)</sup>								
	3RB311	Integrated		1							
Married Co.	3RB312	Integrated			<b>✓</b>						
(C) (F) (C)	3RB313 3RB314	Integrated Integrated	12.5 80			<b>√</b> 	 •				
cocces .	3ND314	integrated	32 113				•				
3RB31											
SIRIUS 3RB20	electronic	overload	l relays <sup>1)</sup>								
0.0.0	3RB205	Integrated						✓			
The same of the sa	3RB206	Integrated							✓	✓	1
	3HB201 +	integrated	630 820								1
3RB20											
SIRIUS 3RB21	electronic	overload	l relays <sup>1)</sup>								
9.0.0	3RB215	Integrated						1			
CECK!	3RB216	Integrated							✓	1	✓
States.	3RB211 + 3UF18	Integrated	630 820								✓
3RB21	00.10										
SIRIUS 3RB22	to 3RB24	electronic	c overload	relavs <sup>1)</sup>		_				_	
	3RB2283/	3RB2906		1	1						
000000	3RB2383/ 3RB2483+	3RB2906	10 100	✓	✓	✓	✓				
ATTACKS AND ADDRESS OF THE PARTY OF THE PART	011221001	3RB2956			✓	✓	✓	✓			
		3RB2966							✓	<b>√</b>	<i>J</i>
		+ 3UF18	630 820								✓
(a)											
3RB22, 3RB23											
3HB22, 3HB23											
escel 1											
## @ @ @ @ @ @ @ @ @ @ @ @ @ @ @ @ @ @											
500000											
3RB24											
					4)						

- ✓ Can be used
- -- Cannot be used

- 1) "Technical specifications" for the use of overload relays with trip class ≥ CLASS 20E can be found in "Short-circuit protection with fuses for motor feeders" in the Configuration Manuals:

   "Configuring SIRIUS Innovations Selection Data for Fuseless and Fused Load Feeders",

   "SIRIUS Configuration Selection Data for Fuseless Load Feeders".

General data

## Connection methods

## 3RU2 thermal overload relays

- Sizes S00 and S0:
  - Main and auxiliary circuit: Either screw or spring-type terminals
- Sizes S2 and S3:
  - Main circuit: Screw terminals with box terminal
  - Auxiliary circuit: Either screw or spring-type terminals

## 3RB3 electronic overload relays

- Sizes S00 and S0:
- Main and auxiliary circuit: Either screw or spring-type terminals
- Sizes S2 and S3:
- Main circuit: Screw terminals with box terminal or as straight-through transformer
- Auxiliary circuit: Either screw or spring-type terminals

#### 3RB2 electronic overload relays

3RB20 and 3RB21 overload relays:

- - Main circuit: With busbar connection or as straight-through transformer
  - Auxiliary circuit: Either screw or spring-type terminals
- Sizes S10/S12:
  - Main circuit: With busbar connection
  - Auxiliary circuit: Either screw or spring-type terminals

## 3RB22 to 3RB24 evaluation modules:

• Screw or spring-type terminals

## 3RB29 current measuring modules:

- Up to size S3: Straight-through transformers
- As from size S6:
  - Main circuit: With busbar connection
  - Auxiliary circuit: Either screw or spring-type terminals

Screw terminals Spring-type terminals

Busbar connections 00

Straight-through transformers

The various terminals and straight-through transformers are indicated in the corresponding tables by the symbols shown on orange backgrounds.

## SIRIUS 3RU2 Thermal Overload Relays

## 3RU2 for standard applications

## Overview

## More information


Home page, see http://www.siemens.com/sirius-overloadrelays Industry Mall, see www.siemens.com/product?3RU2

Conversion tool, e.g. from 3RU11 to 3RU21, see www.siemens.com/sirius/conversion-tool

Application Manual "SIRIUS Controls with IE3/IE4 Motors", see https://support.industry.siemens.com/cs/ww/en/view/94770820

Manual "SIRIUS - SIRIUS 3RU Thermal Overload Relays / SIRIUS 3RB Electronic Overload Relays\*, see http://support.automation.siemens.com/WW/view/en/60298164

Characteristics and certificates, see https://support.industry.siemens.com/cs/ww/en/ps/16271



- 1 Stand-alone assembly support for 3RU2 and 3RB3
- 2 3RU21 thermal overload relay Sizes S00 to S3


## Mountable accessories

- 3 Module for remote RESET
- (4) Cable release with holder for RESET
- (5) Sealable cover
- 6 Mechanical RESET
- 7 Pushbutton

Mountable accessories for 3RU thermal overload relay

# Overload Relays SIRIUS 3RU2 Thermal Overload Relays

## 3RU2 for standard applications



- 1 Switch position indicator and TEST function of the wiring: Indicates a trip and enables the wiring test.
- (2) Motor current setting: Setting the device to the rated motor current is easy with the large rotary knob.
- Connecting terminals:
   Depending on the device version, the connecting terminals are screw terminals or spring-type terminals for the the main and auxiliary circuits.
- STOP button: If the STOP button is pressed, the NC contact is opened. This switches off the contactor downstream. The NC contact is closed again when the button is released.
- 5 Selector switch for manual/automatic RESET and RESET button: With this switch you can choose between manual and automatic RESET. A device set to manual RESET can be reset locally by pressing the RESET button. A remote RESET is possible using the RESET modules (accessories), which are independent of size.
- 6 Connection for mounting onto contactors:
  Optimally adapted in electrical, mechanical and design terms to the contactors. The overload relay can be connected directly to the contactor using these pins. Stand-alone installation is possible as an alternative (in conjunction with a terminal bracket for stand-alone installation)

A sealable transparent cover can be optionally mounted (accessory). It secures the motor current setting against adjustment.

3RU21 thermal overload relays up to 100 A have been designed to provide current-dependent protection for loads with normal starting against impermissibly high temperature rises due to overload or phase failure.

An overload or phase failure results in an increase of the motor current beyond the set rated motor current. Via heating elements, this current rise heats up the bimetal strips inside the device which then bend and as a result trigger the auxiliary contacts by means of a tripping mechanism. The auxiliary contacts then switch off the load by means of a contactor. The break time depends on the ratio between the tripping current and the current setting  $I_{\rm e}$  and is stored in the form of a long-term stable tripping characteristic curve, see Characteristic curves.

The "tripped" status is signaled by means of a switch position indicator. The relay is reset manually or automatically after a recovery time has elapsed.

The 3RU2 thermal overload relays are suitable for operation with frequency converters.

The devices are manufactured in accordance with environmental guidelines and contain environmentally friendly and reusable materials. They comply with all important worldwide standards and approvals.

#### Use in hazardous areas

The 3RU2 overload relays are certified in accordance with the European explosion protection directive (ATEX) and the international explosion protection standard (IECEx), see Certificates.

SIRIUS 3RU2136-4.B0 thermal overload relay

## Article No. scheme

Product versions		Article number	
Thermal overload relays		3RU2	
Device type	e. g. 1 = CLASS 10, 1 NO + 1 NC		
Size, rated operational current and power	e. g. 16 = 16 A (7.5 kW) for size S00		
Setting range for overload release	e. g. 0A = 0.11 0.16 A		
Connection methods	e.g. B = screw terminals		
Installation type	e. g. 0 = mounting on contactor		
Example		3RU2 1 1 6 - 0 A B 0	

## Note:

The Article No. scheme shows an overview of product versions for better understanding of the logic behind the article numbers.

For your orders please use the article numbers quoted in the selection and ordering data.

## SIRIUS 3RU2 Thermal Overload Relays

## 3RU2 for standard applications

#### Benefits

The most important features and benefits of the 3RU21 thermal overload relays are listed in the overview table (see "General Data", page 7/71 onwards).

## Application

## Industries

The 3RU21 thermal overload relays are suitable for customers from all industries who want to guarantee optimum inverse-time delayed protection of their electrical loads (e.g. motors) under normal starting conditions (CLASS 10, 10A).

#### Application

The 3RU21 thermal overload relays have been designed for the protection of three-phase and single-phase AC and DC motors.

If single-phase AC or DC loads are to be protected by the 3RU21 thermal overload relays, all three bimetal strips must be heated. For this purpose, all main current paths of the relay must be connected in series.

#### Ambient conditions

3RU21 thermal overload relays compensate temperature in the temperature range from –40 °C to +60 °C according to IEC 60947-4-1. At temperatures from +60 °C to +70 °C, the upper set value of the setting range has to be reduced by a specific factor in accordance with the table below.

#### Use of SIRIUS protection devices in conjunction with IE3/IE4 motors

#### Note:

For the use of 3RU21 thermal overload relays in conjunction with highly energy-efficient IE3/IE4 motors, please observe the information on dimensioning and configuring. see Application Manual.

For more information, see Preface on page 7.

## Technical specifications

#### More information

System Manual "SIRIUS - System Overview", see

Configuration Manual "Configuring SIRIUS Innovations – Selection Data for Fuseless and Fused Load Feeders", see https://support.industry.siemens.com/cs/ww/en/view/39714188

Manual "SIRIUS - SIRIUS 3RU Thermal Overload Relays / SIRIUS 3RB Electronic Overload Relays", se

https://support.industry.siemens.com/cs/ww/en/view/60298164

Technical specifications, see

https://support.industry.siemens.com/cs/ww/en/ps/16270/td

The following technical information is intended to provide an initial overview of the various types of device and functions.

Type Size		<b>3RU2116</b> S00	<b>3RU2126</b> S0	<b>3RU2136</b> S2	<b>3RU2146</b> S3			
Dimensions (W x H x D) (overload relay with stand-alone installation support)				-	-			
<ul><li>Screw terminals</li><li>Spring-type terminals</li></ul>	mm mm	45 x 89 x 80 45 x 102 x 79	45 x 97 x 95 45 x 114 x 95	55 x 105 x 117 55 x 105 x 117	70 x 106 x 124 70 x 106 x 124			
General data								
Tripping in the event of		Overload and phase	e failure					
Trip class acc. to IEC 60947-4-1	Class	10		10, 10A				
Phase failure sensitivity		Yes						
Overload warning		No						
Reset and recovery								
Reset options after tripping		Manual, Automatic and Remote RESET (Remote RESET in conjunction with the appropriate accessory)						
<ul><li>Recovery time</li><li>For automatic RESET</li><li>For manual RESET</li><li>For remote RESET</li></ul>	min. min. min.	Depends on the strength of the tripping current and characteristic Depends on the strength of the tripping current and characteristic Depends on the strength of the tripping current and characteristic						
Features								
Display of operating state on device		Yes, by means of TE	EST function/switch p	oosition indicator slide	е			
TEST function		Yes						
RESET button		Yes						
STOP button		Yes						
Protection of motors in hazardous environments								
<ul> <li>according to European Directive 2014/34/EU (ATEX)</li> </ul>		DMT 98 ATEX G 00	1 ស II (2) GD					
according to international standard IECEx		IECEx BVS 15.0046 see https://support.		m/cs/ww/en/ps/16270	/cert			

# Overload Relays SIRIUS 3RU2 Thermal Overload Relays

## 3RU2 for standard applications

Туре		3RU2116	3RU2126	3RU2136	3RU2146				
Size 📮 📮		S00	S0	S2	S3				
Dimensions (W x H x D) (overload relay with stand-alone installation	•								
support) • Screw terminals	mm	45 x 89 x 80	45 x 97 x 95	55 x 105 x 117	70 x 106 x 124				
Spring-type terminals	mm	45 x 102 x 79	45 x 114 x 95	55 x 105 x 117	70 x 106 x 124				
General data (continued)									
Ambient temperature									
Storage/transport	°C	-55 +80							
Operation	°C	-40 +70							
Temperature compensation	°C	Up to +60							
Permissible rated current at									
- Temperature inside control cabinet 60 °C	%		tion is required abov	e +60 °C)					
- Temperature inside control cabinet 70 °C	%	87							
Repeat terminals									
Coil repeat terminals		Yes	Not required						
Auxiliary contact repeat terminal		Yes	Not required						
Degree of protection acc. to IEC 60529		IP20		- IP20 (front side)					
					ise additional terminal r degree of protection				
Touch protection acc. to IEC 60529		Finger-safe		COVERS for Highe	r degree or protection				
Shock resistance with sine acc. to IEC 60068-2-27	<i>g</i> /ms		15/11 (auxiliary contacts 95/96 and 97/98: 8 <i>g</i> /11 ms)						
Electromagnetic compatibility (EMC)	9/1110	10/11 (daxillar y ool	114010 00,00 4114 017	00. 0 g, 11 maj					
Interference immunity		Not relevant							
Emitted interference		Not relevant							
Resistance to extreme climates – air humidity	%	90							
Installation altitude above sea level	m	Up to 2 000							
Mounting position		contactors and star	nd-alone installation of 10 % must be imation:	ounting positions for n . For mounting position plemented.					
		135° 135	I <sub>e</sub> x 1,1 90°	7 <sub>e</sub> x 1,1 90°					
		Contactor + overloop $0^{\circ}$ $I_{e} \times 1,1$	22,5° 22,5°						
Type of mounting			contactor or stand-a mounting onto star	lone installation with t dard mounting rail.	erminal support,				

## SIRIUS 3RU2 Thermal Overload Relays

## 3RU2 for standard applications

Туре		3RU2116	3RU2126	3RU2136	3RU2146		
Size		S00	S0	S2	S3		
Main circuit							
<b>Rated insulation voltage </b> <i>U</i> <sub>i</sub> (pollution degree 3)	V	690			1000		
Rated impulse withstand voltage $U_{\text{imp}}$	kV	6			8		
Rated operational voltage <i>U</i> <sub>e</sub>	٧	690					
Type of current							
Direct current		Yes					
Alternating current		Yes, frequency rar	nge up to 400 Hz				
Current setting	А	0.11 0.16	1.8 2.5	11 16	28 40		
	А	up to 11 16	up to 34 40	up to 70 80	up to 80 100		
Power loss per unit (max.)	W	4.1 6.3	6.2 7.5	8 14	12 16.5		
Short-circuit protection							
With fuse without contactor		See "Selection and	d ordering data", pa	ges 7/84 7/87			
With fuse and contactor		"Short-Circuit Protesee Configuration		otor Starter Protecto	ors for Motor Feeders"		
Protective separation between main and auxiliary current paths Acc. to IEC 60947-1		3					
Screw terminals or ring terminal lug connections	V	440	690: Setting range ≤ 25 A	690			
Spring-type terminals	V	440	440: Setting range > 25 A	690			
Conductor cross-sections of main circuit							
Connection type		Screw term	Screw terminals				
Terminal screw		M3, Pozidriv size 2	M4, Pozidriv size 2	M6, Pozidriv size 2	4 mm Allen screw		
Operating devices	mm	Ø 5 6	Ø 5 6	Ø 5 6	4 mm Allen screw		
Prescribed tightening torque	Nm	0.8 1.2	2 2.5	3 4.5	4.5 6		
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected							
Solid or stranded	mm <sup>2</sup>	2 x (0.5 1.5) <sup>1)</sup> , 2 x (0.75 2.5) <sup>1)</sup> , max. 2 x 4	2 x (1 2.5) <sup>1)</sup> 2 x (2.5 10) <sup>1</sup> )	2 x (2.5 35) <sup>1)</sup> , 1 x (2.5 50) <sup>1)</sup>	2 x (2.5 16) <sup>1)</sup> , 2 x (10 50) <sup>1)</sup> , 1 x (10 70) <sup>1)</sup>		
• Finely stranded with end sleeve (DIN 46228-1)	mm <sup>2</sup>	$2 \times (0.5 \dots 1.5)^{1)}$ $2 \times (0.75 \dots 2.5)^{1)}$	2 x (1 2.5) <sup>1)</sup> , 2 x (2.5 6) <sup>1)</sup> ; max 1 x 10	2 x (1 25) <sup>1)</sup> , 1 x (1 35) <sup>1)</sup>	2 x (2.5 35) <sup>1)</sup> , 1 x (2.5 50) <sup>1)</sup>		
AWG cables, solid or stranded	AWG	2 x (20 16) <sup>1)</sup> , 2 x (18 14) <sup>1)</sup> , 2 x 12	2 x (16 12) <sup>1)</sup> , 2 x (14 8) <sup>1)</sup>	2 x (18 2) <sup>1)</sup> , 1 x (18 1) <sup>1)</sup>	2 x (10 1/0) <sup>1)</sup> , 1 x (10 2/0) <sup>1)</sup>		
Removable box terminals <sup>2)</sup>							
With copper bars <sup>3)</sup>	mm				2 x 12 x 4		
With cable lugs <sup>4)</sup>							
- Terminal screw					M6		
- Prescribed tightening torque	Nm				4.5 6		
- Usable ring terminal lugs	mm	-	-		d <sub>2</sub> = min. 6.3 d3 = max. 19		
1201_127							

<u> </u>	ם ע						
Connection type		Spring-typ	e terminals				
Operating devices	mm	$3.0 \times 0.5$ and $3.5 \times 0.5$					
Conductor cross-sections (min./max.), 1 conductor can be connected							
<ul> <li>Solid or stranded</li> </ul>	mm <sup>2</sup>	1 x (0.5 4)	1 x (1 10)				
<ul> <li>Finely stranded without end sleeve</li> </ul>	mm <sup>2</sup>	1 x (0.5 2.5)	1 x (1 6)				
<ul> <li>Finely stranded with end sleeve (DIN 46228-1)</li> </ul>	mm <sup>2</sup>	1 x (0.5 2.5)	1 x (1 6)				
<ul> <li>AWG cables, solid or stranded</li> </ul>	AWG	1 x (20 12)	1 x (18 8)				

If two different conductor cross-sections are connected to one clamping point, both cross-sections must be in the range specified.
 Cable lug and busbar connection possible after removing the box terminals.

 <sup>3)</sup> If bars larger than 12 mm x 10 mm are connected, a 3RT2946-4EA2 cover is needed to maintain the required phase clearance, see page 7/89.
 4) When conductors larger than 25 mm² are connected, the 3RT2946-4EA2 cover is needed to maintain the required phase clearance, see page 7/89.

# Overload Relays SIRIUS 3RU2 Thermal Overload Relays

## 3RU2 for standard applications

Туре		3RU2116	3RU2126	3RU2136	3RU2146			
Size		S00	SO	S2	S3			
Auxiliary circuit								
Number of NO contacts		1						
Number of NC contacts		1						
Auxiliary contacts – assignment		1 NO for the signal "tripped"; 1 NC for disconnecting the contactor						
Rated insulation voltage <i>U</i> i (pollution degree 3)	٧	690						
Rated impulse withstand voltage <i>U</i> <sub>imp</sub>	kV	6						
Contact rating of the auxiliary contacts								
<ul> <li>NC, NO contact with alternating current AC-15, rated operational current I<sub>e</sub> at U<sub>e</sub> <ul> <li>24 V</li> <li>120 V</li> <li>125 V</li> </ul> </li> </ul>	A A A	3 3 3						
- 230 V	A	2						
- 400 V - 600 V	A A	1 0.75						
- 690 V	A	0.75						
<ul> <li>NC, NO contacts with DC current DC-13, rated operational current I<sub>e</sub> at U<sub>e</sub></li> <li>24 V</li> <li>110 V</li> <li>125 V</li> </ul>	A A A	1 0.22 0.22						
- 220 V	A	0.11						
<ul> <li>Contact reliability (suitability for PLC control; 17 V, 5 mA)</li> </ul>		Yes						
Short-circuit protection								
With fuse Operational class gG Quick	A A	6 10						
With miniature circuit breaker (C characteristic)	Α	6 (up to $I_k \le 0.5$	5 kA; <i>U</i> ≤ 260 V)					
Permissible operational voltage for protective separation between auxiliary current paths Acc. to IEC 60947-1	V	440						
CSA, UL, UR rated data								
Auxiliary circuit – switching capacity		B600, R300						
Conductor cross-sections for auxiliary circuit								
Connection type		Screw to	erminals					
Terminal screw		M3, Pozidriv si	ze 2					
Operating devices	mm	Ø 5 6						
Prescribed tightening torque	Nm	0.8 1.2						
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected								
Solid or stranded	$mm^2$		<sup>1)</sup> , 2 x (0.75 2.5) <sup>1</sup>					
<ul> <li>Finely stranded with end sleeve (DIN 46228-1)</li> </ul>	mm <sup>2</sup>		<sup>1)</sup> , 2 x (0.75 2.5) <sup>1</sup>	)				
AWG cables, solid or stranded	AWG	2 x (20 16) <sup>1)</sup>	, 2 x (18 14) <sup>1)</sup>					
Connection type		Spring-ty	ype terminals					
Operating devices	mm	3.0 x 0.5 and 3	.5 x 0.5					
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected								
	mm <sup>2</sup>	2 x (0.5 2.5)						
1 or 2 conductors can be connected	mm <sup>2</sup> mm <sup>2</sup>	2 x (0.5 2.5) 2 x (0.5 2.5)						
1 or 2 conductors can be connected  Solid or stranded								

<sup>1)</sup> If two different conductor cross-sections are connected to one clamping point, both cross-sections must be in the range specified.

## SIRIUS 3RU2 Thermal Overload Relays

3RU2 for standard applications IE3/IE4 ready

## Selection and ordering data

## 3RU21 thermal overload relays for mounting onto contactor 1), sizes S00 and S0, CLASS 10

Features and technical specifications:

- Connection methods
   Main and auxiliary circuit: Either screw or spring-type
   terminals
- Overload and phase failure protection
- Auxiliary contacts 1 NO + 1 NC
- · Manual and automatic RESET

- Switch position indicator
- TEST function
- STOP button
- Sealable covers (optional accessory)

 $\begin{array}{ll} PU \text{ (UNIT, SET, M)} = 1 \\ PS^* & = 1 \text{ unit} \\ PG & = 41F \end{array}$ 







3RU2116-4AC0



3RU2126-4FB0



3RU2126-4AC0

Size contac- tor	Trip class	Rated power for three-phase motors, rated value <sup>2)</sup>	Current setting value of the inverse-time delayed overload release	Short-circuit protection with fuse, type of coordination "2", operational class gG <sup>3)</sup>	SD	Screw terminals	SD SD	Spring-type terminals	
	Class	kW	Α	A	d	Article No.	Price per PU d	Article No.	Price per PU
Size S	00								
S00	10 10 10 10	0.04 0.06 0.06 0.09	0.11 0.16 0.14 0.2 0.18 0.25 0.22 0.32	0.5 1 1 1.6	<b>* * * *</b>	3RU2116-0AB0 3RU2116-0BB0 3RU2116-0CB0 3RU2116-0DB0	5 5 5 5	3RU2116-0AC0 3RU2116-0BC0 3RU2116-0CC0 3RU2116-0DC0	
	10 10 10 10	0.09 0.12 0.18 0.18	0.28 0.4 0.35 0.5 0.45 0.63 0.55 0.8	2 2 2 4	<b>* * *</b>	3RU2116-0EB0 3RU2116-0FB0 3RU2116-0GB0 3RU2116-0HB0	5 5 5 5	3RU2116-0EC0 3RU2116-0FC0 3RU2116-0GC0 3RU2116-0HC0	
	10 10 10 10	0.25 0.37 0.55 0.75	0.7 1 0.9 1.25 1.1 1.6 1.4 2	4 4 6 6	<b>A A A</b>	3RU2116-0JB0 3RU2116-0KB0 3RU2116-1AB0 3RU2116-1BB0	5 5 5 5	3RU2116-0JC0 3RU2116-0KC0 3RU2116-1AC0 3RU2116-1BC0	
	10 10 10 10	0.75 1.1 1.5 1.5	1.8 2.5 2.2 3.2 2.8 4 3.5 5	10 10 16 20	<b>* * *</b>	3RU2116-1CB0 3RU2116-1DB0 3RU2116-1EB0 3RU2116-1FB0	5 5 5 5	3RU2116-1CC0 3RU2116-1DC0 3RU2116-1EC0 3RU2116-1FC0	
	10 10 10 10	2.2 3 4 5.5	4.5 6.3 5.5 8 7 10 9 12.5	20 25 35 35	* * * *	3RU2116-1GB0 3RU2116-1HB0 3RU2116-1JB0 3RU2116-1KB0	5 5 5 5	3RU2116-1GC0 3RU2116-1HC0 3RU2116-1JC0 3RU2116-1KC0	
	10	7.5	11 16	40	<b>&gt;</b>	3RU2116-4AB0	5	3RU2116-4AC0	
Size S	0								
S0	10 10 10 10	0.75 1.1 1.5 1.5	1.8 2.5 2.2 3.2 2.8 4 3.5 5	10 10 16 20	<b>A A A</b>	3RU2126-1CB0 3RU2126-1DB0 3RU2126-1EB0 3RU2126-1FB0	5 5 5 5	3RU2126-1CC0 3RU2126-1DC0 3RU2126-1EC0 3RU2126-1FC0	
	10 10 10 10	2.2 3 4 5.5	4.5 6.3 5.5 8 7 10 9 12.5	20 25 35 35	<b>A A A</b>	3RU2126-1GB0 3RU2126-1HB0 3RU2126-1JB0 3RU2126-1KB0	5 5 5 5	3RU2126-1GC0 3RU2126-1HC0 3RU2126-1JC0 3RU2126-1KC0	
	10 10 10 10	7.5 7.5 11 11	11 16 14 20 17 22 20 25	40 50 63 63	<b>A A A</b>	3RU2126-4AB0 3RU2126-4BB0 3RU2126-4CB0 3RU2126-4DB0	<b>*</b> * * * * * * * * * * * * * * * * * *	3RU2126-4AC0 3RU2126-4BC0 3RU2126-4CC0 3RU2126-4DC0	
	10 10 10 10	15 15 18.5 18.5	23 28 27 32 30 36 34 40	63 80 80 80	<b>*</b> * *	3RU2126-4NB0 3RU2126-4EB0 3RU2126-4PB0 3RU2126-4FB0	<b>*</b>	3RU2126-4NC0 3RU2126-4EC0 3RU2126-4PC0 3RU2126-4FC0	

With the appropriate terminal supports (see "Accessories", page 7/88), the 3RU2 overload relays for mounting on contactors can also be installed as stand-alone units.

Overload relays in size S2, see page 7/85.

<sup>2)</sup> Guide value for 4-pole standard motors at 50 Hz 400 V AC. The actual starting and rated data of the motor to be protected must be considered when selecting the units.

<sup>3)</sup> Maximum protection by fuse only for overload relays, type of coordination "2". For fuse values in connection with contactors, see Configuration Manual.

# Overload Relays SIRIUS 3RU2 Thermal Overload Relays

**IE3/IE4 ready** 3RU2 for standard applications

## 3RU21 thermal overload relays for mounting onto contactor<sup>1)</sup>, sizes S2 and S3, CLASS 10 or 10A

Features and technical specifications:

- · Connection methods
  - Main circuit: Screw terminals with box terminal
  - Auxiliary circuit: Either screw or spring-type terminals
- Overload and phase failure protection
- Auxiliary contacts 1 NO + 1 NC
- Manual and automatic RESET
- · Switch position indicator

- TEST function
- STOP button
- Sealable covers (optional accessory)

 $\begin{array}{ll} PU \text{ (UNIT, SET, M)} = 1 \\ PS^* & = 1 \text{ unit} \\ PG & = 41F \end{array}$ 







3RU2136-4.D0



3RU2146-4.B0



3RU2146-4.D0

Size contac- tor	Trip class	Rated power for three-phase motors, rated value <sup>2)</sup>	Current setting value of the inverse-time delayed overload release	Short-circuit protection with fuse, type of coordination "2", operational class gG <sup>3)</sup>	SD	Screw terminals	<b>(1)</b>	SD	Spring-type terminals (on auxiliary current side)
	Class	kW	A	A	d	Article No.	Price per PU	d	Article No. Price per PU
Size S	2								
S2	10 10 10 10 10 10 10 10 10 10 10 10A	7.5 7.5 11 15 18.5 22 22 30 30 37	11 16 14 20 18 25 22 32 28 40 36 45 40 50 47 57 56 65 62 73 70 80	40 50 63 80 80 100 100 100 125 160	5 5 5 5 5 6	3RU2136-4AB0 3RU2136-4BB0 3RU2136-4DB0 3RU2136-4EB0 3RU2136-4FB0 3RU2136-4GB0 3RU2136-4QB0 3RU2136-4QB0 3RU2136-4JB0 3RU2136-4JB0 3RU2136-4KB0 3RU2136-4RB0		5 5 5 5 ••••••••••••••••••••••••••••••	3RU2136-4AD0 3RU2136-4BD0 3RU2136-4DD0 3RU2136-4ED0 3RU2136-4FD0 3RU2136-4HD0 3RU2136-4QD0 3RU2136-4JD0 3RU2136-4JD0 3RU2136-4HD0 3RU2136-4HD0
Size S	3 NEW								
S3	10 10 10 10 10 10	18.5 22 30 37 45 45	28 40 36 50 45 63 57 75 70 90 80 100 <sup>4)</sup>	80 125 125 160 160 200	1 1 1 1 1	3RU2146-4FB0 3RU2146-4HB0 3RU2146-4JB0 3RU2146-4KB0 3RU2146-4LB0 3RU2146-4MB0		5 5 1 1 1	3RU2146-4FD0 3RU2146-4HD0 3RU2146-4JD0 3RU2146-4KD0 3RU2146-4LD0 3RU2146-4MD0

With the appropriate terminal supports (see "Accessories", page 7/88), the 3RU2 overload relays for mounting on contactors can also be installed as stand-alone units.

<sup>2)</sup> Guide value for 4-pole standard motors at 50 Hz 400 V AC. The actual starting and rated data of the motor to be protected must be considered when selecting the units.

<sup>3)</sup> Maximum protection by fuse only for overload relays, type of coordination "2". For fuse values in connection with contactors, see Configuration Manual.

<sup>&</sup>lt;sup>4)</sup> For overload relays > 100 A, see 3RB2 electronic overload relays, page 7/102 onwards.

## SIRIUS 3RU2 Thermal Overload Relays

## 3RU2 for standard applications | IE3/IE4 ready

## 3RU21 thermal overload relays for stand-alone installation, sizes S00 and S0, CLASS 10

Features and technical specifications:

- Connection methods
   Main and auxiliary circuit: Either screw or spring-type
   terminals
- Overload and phase failure protection
- Auxiliary contacts 1 NO + 1 NC
- Manual and automatic RESET

- Switch position indicator
- TEST function
- STOP button
- Sealable covers (optional accessory)

 $\begin{array}{ll} PU \text{ (UNIT, SET, M)} = 1 \\ PS^* & = 1 \text{ unit} \\ PG & = 41F \end{array}$ 







2DL12116 C



3RU2126-..B1



3BU2126- C

Size contac- tor		Rated power for three-phase motors, rated value <sup>1)</sup>	Current setting value of the inverse-time delayed overload release	Short-circuit protection with fuse, type of coordination "2", operational class gG <sup>2</sup> )	SD	Screw terminals	<b>(1)</b>	SD	Spring-type terminals	
	Class	kW	Α	A	d	Article No.	Price per PU	d	Article No.	Price per PU
Size S	00									
S00	10 10 10 10	0.04 0.06 0.06 0.09	0.11 0.16 0.14 0.2 0.18 0.25 0.22 0.32	0.5 1 1 1.6	5 5 5 5	3RU2116-0AB1 3RU2116-0BB1 3RU2116-0CB1 3RU2116-0DB1		5 5 5 5	3RU2116-0AC1 3RU2116-0BC1 3RU2116-0CC1 3RU2116-0DC1	
	10 10 10 10	0.09 0.12 0.18 0.18	0.28 0.4 0.35 0.5 0.45 0.63 0.55 0.8	2 2 2 4	5 5 5 5	3RU2116-0EB1 3RU2116-0FB1 3RU2116-0GB1 3RU2116-0HB1		5 5 5 5	3RU2116-0EC1 3RU2116-0FC1 3RU2116-0GC1 3RU2116-0HC1	
	10 10 10 10	0.25 0.37 0.55 0.75	0.7 1 0.9 1.25 1.1 1.6 1.4 2	4 4 6 6	5 5 5 5	3RU2116-0JB1 3RU2116-0KB1 3RU2116-1AB1 3RU2116-1BB1		5 5 5 5	3RU2116-0JC1 3RU2116-0KC1 3RU2116-1AC1 3RU2116-1BC1	
	10 10 10 10	0.75 1.1 1.5 1.5	1.8 2.5 2.2 3.2 2.8 4 3.5 5	10 10 16 20	5 5 5 5	3RU2116-1CB1 3RU2116-1DB1 3RU2116-1EB1 3RU2116-1FB1		5 5 5 5	3RU2116-1CC1 3RU2116-1DC1 3RU2116-1EC1 3RU2116-1FC1	
	10 10 10 10	2.2 3 4 5.5	4.5 6.3 5.5 8 7 10 9 12.5	20 25 35 35	5 5 5 5	3RU2116-1GB1 3RU2116-1HB1 3RU2116-1JB1 3RU2116-1KB1		5 5 5 5	3RU2116-1GC1 3RU2116-1HC1 3RU2116-1JC1 3RU2116-1KC1	
	10	7.5	11 16	40	5	3RU2116-4AB1		5	3RU2116-4AC1	
Size S	0									
S0	10 10 10	7.5 11 11	14 20 17 22 20 25	50 63 63	5 5 5	3RU2126-4BB1 3RU2126-4CB1 3RU2126-4DB1		5 5 5	3RU2126-4BC1 3RU2126-4CC1 3RU2126-4DC1	
1)	10 10 10 10	15 15 18.5 18.5	23 28 27 32 30 36 34 40	63 80 80 80	5 5 5 5	3RU2126-4NB1 3RU2126-4EB1 3RU2126-4PB1 3RU2126-4FB1		5 5 5 5	3RU2126-4NC1 3RU2126-4EC1 3RU2126-4PC1 3RU2126-4FC1	

<sup>&</sup>lt;sup>1)</sup> Guide value for 4-pole standard motors at 50 Hz 400 V AC. The actual starting and rated data of the motor to be protected must be considered when selecting the units.

<sup>2)</sup> Maximum protection by fuse only for overload relays, type of coordination "2". For fuse values in connection with contactors, see Configuration Manual.

# Overload Relays SIRIUS 3RU2 Thermal Overload Relays

IE3/IE4 ready 3RU2 for standard applications

## 3RU21 thermal overload relays for stand-alone installation, sizes S2 and S3, CLASS 10 or 10A

Features and technical specifications:

- Connection methods
  - Main circuit: Screw terminals with box terminal
  - Auxiliary circuit: Either screw or spring-type terminals
- Auxiliary contacts 1 NO + 1 NC
- Manual and automatic RESET
- · Switch position indicator

- TEST function
- STOP button
- Sealable covers (optional accessory)

 $\begin{array}{ll} PU \text{ (UNIT, SET, M)} = 1 \\ PS^* & = 1 \text{ unit} \\ PG & = 41F \end{array}$ 







3RU2136-..D1



3RU2146-..B1



3RU2146-..D1

Size contac- tor	Trip class	Rated power for three-phase motors, rated value <sup>1)</sup>	Current setting value of the inverse-time delayed overload release	Short-circuit protection with fuse, type of coordination "2", operational class gG <sup>2)</sup>	SD	Screw terminals	<b>+</b>	SD	Spring-type terminals	<u> </u>
	CLASS	kW	А	A	d	Article No.	Price per PU		Article No.	Price per PU
Size S	2									
S2	10 10 10 10 10 10 10 10A 10A	15 18.5 22 22 30 30 37 37	22 32 28 40 36 45 40 50 47 57 54 65 62 73 70 80	80 80 100 100 100 125 160 160	5 5 5	3RU2136-4EB1 3RU2136-4FB1 3RU2136-4GB1 3RU2136-4UB1 3RU2136-4UB1 3RU2136-4JB1 3RU2136-4KB1 3RU2136-4RB1		5 5 • •	3RU2136-4ED1 3RU2136-4FD1 3RU2136-4GD1 3RU2136-4HD1 3RU2136-4QD1 3RU2136-4JD1 3RU2136-4KD1 3RU2136-4RD1	
Size S	3 NEW									
S3	10 10 10 10	30 37 45 45	45 63 57 75 70 90 80 100 <sup>3)</sup>	125 160 160 200	1 1 1 1	3RU2146-4JB1 3RU2146-4KB1 3RU2146-4LB1 3RU2146-4MB1		5 5 5 X	3RU2146-4JD1 3RU2146-4KD1 3RU2146-4LD1 3RU2146-4MD1	

<sup>1)</sup> Guide value for 4-pole standard motors at 50 Hz 400 V AC. The actual starting and rated data of the motor to be protected must be considered when selecting the units.

Maximum protection by fuse only for overload relays, type of coordination "2". For fuse values in connection with contactors, see Configuration Manual.

<sup>3)</sup> For overload relays > 100 A, see 3RB2 electronic overload relays, page 7/102 onwards.

## SIRIUS 3RU2 Thermal Overload Relays

## Accessories

## Overview

The following optional accessories are available for the 3RU21 thermal overload relays:

- Size-specific terminal support for stand-alone installation, in sizes S00 and S0 also with spring-type terminals
- Mechanical RESET (for all sizes)
- Cable release for resetting devices which are difficult to access (for all sizes)
- Electrical remote RESET module in three voltage variants (for all sizes)
- Sealable cover (for all sizes)
- Terminal covers for devices with screw terminals (box terminals) and ring terminal lug connections

Selection and	ordering data								
	Version	Size		SD	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
				d					
Terminal suppo	orts for stand-alone installation								
	Terminal supports for overload relays with screw terminals				Screw terminals	<b>+</b>			
***	For separate mounting of the overload relays; screw and snap-on mounting onto standard mounting	9 S0		<b>&gt;</b>	3RU2916-3AA01 3RU2926-3AA01		1 1	1 unit 1 unit	41F 41F
270.0	rail	S2		<b>&gt;</b>	3RU2936-3AA01		1	1 unit	411
RU2916-3AA01		S3	NEW	1	3RU2946-3AA01		1	1 unit	41
	Terminal supports for overload relays with spring-type terminals				Spring-type terminals	8			
	For separate mounting of the overload relays;	S00		5	3RU2916-3AC01		1	1 unit	411
	screw and snap-on mounting onto standard mounting	9 S0		5	3RU2926-3AC01		1	1 unit	411
BRU2926-3AA01									
300									
RU2936-3AA01									
RU2946-3AA01									
RU2916-3AC01									
BRU2926-3AC01									
Mechanical RE	SET								
and the same	Resetting plungers, holders and formers	S00 .	S3	▶	3RU2900-1A		1	1 unit	41F
<i>J</i> P:	Pushbuttons with extended stroke (12 mm), IP65, Ø 22 mm	S00 .	S3	•	3SU1200-0FB10-0AA0		1	1 unit	41.
	Extension plungers For compensation of the distance between the pushbutton and the unlatching button of the relay	S00 .	S3	•	3SU1900-0KG10-0AA0		1	1 unit	41.
3RU2900-1A with pushbutton and									

extension plunger

# Overload Relays SIRIUS 3RU2 Thermal Overload Relays

									Accesso	ories
	Version			Size		Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
Cable releases	with holder for RESET				d					
<b>9</b>	For Ø 6.5 mm holes in the max. control panel thickr • Length 400 mm • Length 600 mm	e control panel;		S00 S3 S00 S3		3RU2900-1B 3RU2900-1C		1 1	1 unit 1 unit	41F 41F
3RU2900-1.										
	note RESET, electrica									
	Operating range 0.85 power consumption 80 V ON period 0.2 4 s, switching frequency 60/h • 24 30 V AC/DC • 110 127 V AC/DC	A AC, 70 W DC,		S00 S3 S00 S3		3RU1900-2AB71 3RU1900-2AF71		1	1 unit 1 unit	41F 41F
3RU1900-2A.71	• 220 250 V AC/DC			S00 S3	2	3RU1900-2AM71		1	1 unit	41F
Sealable covers	For covering the setting I	knobs		S00 S3	<b>&gt;</b>	3RV2908-0P		100	10 units	41E
3RV2908-0P Terminal covers	6									
	Covers for devices with (box terminals) Additional touch protection terminals		he box			Screw terminals	<b>+</b>			
3RT2936-4EA2	Main current level			S2 S3 <b>NEW</b>		3RT2936-4EA2 3RT2946-4EA2		1	1 unit 1 unit	41B 41B
General access	sories									
	Version	Size	Color	For overload relays	SD	Article No.	Pric per P		PS*	PG
Tools for opening	ng spring-type termin	als								-
						Spring-type terminals	O			
3RA2908-1A	Screwdrivers For all SIRIUS devices with spring- type terminals	Length approx. 200 mm, 3.0 mm x 0.5 mm	Titanium gray/ black, partially insulated	Main and auxiliary circuit connectio 3RU2		3RA2908-1A		1	1 unit	41B
Blank labels	Unit labeling plates <sup>1)</sup>	20 mm x 7 mm	Pastel	3RU2	20	3RT1900-1SB20		100	340 units	41B
	For SIRIUS devices	20 mm x 7 mm	turquoise Titanium gray	3RU2	20	3RT2900-1SB20		100	340 units	41B
01429b	Adhesive inscription labels <sup>1)</sup>	19 mm x 6 mm	Pastel turquoise	3RU2	15	3RT1900-1SB60		100	3 060 units	41B
3RT1900-1SB20	For SIRIUS devices	19 mm x 6 mm	Zinc yello	w 3RU2	15	3RT1900-1SD60		100	3 060 units	41B
3RT2900-1SB20										
1) PC labeling syste of unit labeling pl murrplastik Syste (see page 16/20)		1								

<sup>\*</sup> You can order this quantity or a multiple thereof. Illustrations are approximate.

## SIRIUS 3RB3 Electronic Overload Relays

## 3RB30, 3RB31 for standard applications

## Overview

## More information


Home page, see http://www.siemens.com/sirius-overloadrelays Industry Mall, see www.siemens.com/product?3RB3

Conversion tool, e.g. from 3RB20/3RB211 to 3RB30/3RB31, see www.siemens.com/sirius/conversion-tool

Application Manual "SIRIUS Controls with IE3/IE4 Motors", see https://support.industry.siemens.com/cs/ww/en/view/94770820

Manual "SIRIUS - SIRIUS 3RU Thermal Overload Relays / SIRIUS 3RB Electronic Overload Relays", see https://support.industry.siemens.com/cs/ww/en/view/60298164

Characteristics and certificates, see https://support.industry.siemens.com/cs/ww/en/ps/16276



- 1 Stand-alone assembly support for 3RU2 and 3RB3
- ② 3RB30, 3RB31 electronic overload relay, sizes S00 to S3


Mountable accessories

- 3 Cable release with holder for RESET
- 4 Sealable cover
- Mechanical RESET
- 6 Pushbutton

Mountable accessories for 3RB30 and 3RB31 electronic overload relays

# Overload Relays SIRIUS 3RB3 Electronic Overload Relays

## 3RB30, 3RB31 for standard applications



- 1 Switch position indicator and TEST function of the wiring: Indicates a trip and enables the wiring test.
- Trip class setting/internal ground-fault detection (only 3RB31): Using the rotary switch you can set the required trip class and activate the internal ground-fault detection dependent on the start-up conditions.
- 3 Solid-state test (device test): Enables a test of all important device components and functions.
- Connecting terminals (removable joint block for auxiliary circuits): Depending on the device version, the terminals for screw and spring-type connection are configured for the main and auxiliary circuit.
- (5) Selector switch for manual/automatic RESET: With the slide switch you can choose between manual and automatic RESET.
- (6) Motor current setting: Setting the device to the rated motor current is easy with the large rotary knob.
- 7 A device set to manual RESET can be reset locally by pressing the RESET button. On 3RB31 overload relays an electrical remote RESET is integrated.
- 8 Connection for mounting onto contactors:
  Optimally adapted in electrical, mechanical and design terms to the contactors 3RT2. The overload relay can be connected directly using these connection pins. Stand-alone installation is possible as an alternative (in conjunction with a terminal support for stand-alone installation).

A sealable transparent cover can be optionally mounted (accessory). It secures the motor current setting against adjustment.

SIRIUS 3RB3133-4.B0 electronic overload relay

The 3RB30/3RB31 electronic overload relays up to 115 A with internal power supply have been designed for current-dependent protection of loads with normal and heavy starting, and to protect against excessive temperature rises due to overload, phase asymmetry or phase failure. An overload, phase asymmetry or phase failure result in an increase of the motor current beyond the set rated motor current. This current rise is detected by the current transformers integrated into the devices and evaluated by corresponding solid-state circuits which then output a pulse to the auxiliary contacts. The auxiliary contacts then switch off the load by means of a contactor. The break time depends on the ratio between the tripping current and the current setting  $I_{\rm e}$  and is stored in the form of a long-term stable tripping characteristic curve, (see Characteristic curves).

In addition to inverse-time delayed protection of loads against excessive temperature rises due to overload, phase asymmetry and phase failure, the 3RB31 electronic overload relays also allow internal ground-fault detection (not possible in conjunction with contactor assemblies for wye-delta starting). This provides protection of loads against high-resistance short circuits due to damage to the insulation material, moisture, condensed water etc.

The "tripped" status is signaled by means of a switch position indicator. The relay is reset manually or automatically after the recovery time has elapsed.

The 3RB3 electronic overload relays are suitable for operation with frequency converters.

The devices are manufactured in accordance with environmental guidelines and contain environmentally friendly and reusable materials. They comply with all important worldwide standards and approvals.

3RB20 and 3RB21 overload relays in sizes S6 to S10/S12, see page 7/109 onwards.

## Use in hazardous areas

The 3RB30/3RB31 electronic overload relays are suitable for the overload protection of motors with the following types of protection:

- 🚱 II (2) G [Ex e] [Ex d] [Ex px]
- 🐼 II (2) D [Ex t] [Ex p]

EC type test certificate for Group II, Category (2) G/D exists. It has the number PTB 09 ATEX 3001.

## SIRIUS 3RB3 Electronic Overload Relays

## 3RB30, 3RB31 for standard applications

#### Article No. scheme

Product versions		Article number
Electronic overload relays		3RB3 🗆 🗆 🗕 🗆 🗆 🗆
Device type	e. g. 0 = standard device, with internal supply, for three-phase loads	
Size, rated operational current and power	e. g. 1 = 16 A (7.5 kW) for size S00	
Version of the automatic RESET, electrical remote RESET	e. g. 6 = switchable between manual/auto RESET	
Trip class (CLASS)	e. g. 1 = CLASS 10E	
Setting range of the overload release	e.g. R = 0.1 0.4 A	
Connection methods	e.g. B = screw terminals for main and auxiliary circuits	
Installation type	e. g. 0 = mounting on contactor	
Example		3RB3 0 1 6 - 1 R B 0

#### Note:


The Article No. scheme shows an overview of product versions for better understanding of the logic behind the article numbers.

For your orders please use the article numbers quoted in the selection and ordering data.

#### Benefits

The most important features and benefits of the 3RB30/3RB31 electronic overload relays are listed in the overview table (see "General Data" page 7/71 onwards).

## Advantages through energy efficiency



Overview of the energy management process

We offer you a unique portfolio for industrial energy management, using an energy management system that helps to optimally define your energy needs. We split up our industrial energy management into three phases – identify, evaluate, and realize – and we support you with the appropriate hardware and software solutions in every process phase.

The innovative products of the SIRIUS industrial controls portfolio can also make a substantial contribution to a plant's energy efficiency (see www.siemens.com/sirius/energysaving).

3RB30/3RB31 electronic overload relays contribute to energy efficiency throughout the plant as follows:

- Reduced inherent power loss
- Less heating of the control cabinet
- Smaller control cabinet air conditioners can be used

## Application

## Industries

The 3RB30/3RB31 electronic overload relays are suitable for customers from all industries who want to guarantee optimum inverse-time delayed protection of their electrical loads (e.g. motors) under normal and heavy starting conditions (CLASS 5E to 30E), minimize project completion times, inventories and energy consumption, and optimize plant availability and maintenance management.

## Application

The 3RB30/3RB31 electronic overload relays have been designed for the protection of three-phase motors in sinusoidal 50/60 Hz voltage networks. The relays are not suitable for the protection of single-phase AC or DC loads.

The 3RU21 thermal overload relay or the 3RB22/3RB23/3RB24 electronic overload relay can be used for single-phase AC loads. For DC loads we recommend the 3RU21 thermal overload relay.

## Ambient conditions

The devices are insensitive to external influences such as shocks, corrosive ambient conditions, ageing and temperature fluctuations.

For the temperature range from -25 °C to +60 °C, the 3RB30/3RB31 electronic overload relays compensate the temperature in accordance with IEC 60947-4-1.

## Use of SIRIUS protection devices in conjunction with IE3/IE4 motors

#### Note:

For the use of 3RB30/3RB31 electronic overload relays in conjunction with highly energy-efficient IE3/IE4 motors, please observe the information on dimensioning and configuring, see Application Manual.

For more information, see Preface on page 7.

## **Overload Relays** SIRIUS 3RB3 Electronic Overload Relays

3RB30, 3RB31 for standard applications

## Technical specifications

## More information

System Manual "SIRIUS – System Overview", see https://support.industry.siemens.com/cs/ww/en/view/60311318

Configuration Manual "Configuring SIRIUS Innovations – Selection Data for Fuseless and Fused Load Feeders", see https://support.industry.siemens.com/cs/ww/en/view/39714188

Manual "SIRIUS - SIRIUS 3RU Thermal Overload Relays / SIRIUS 3RB Electronic Overload Relays", see https://support.industry.siemens.com/cs/ww/en/view/60298164

Technical specifications, see

https://support.industry.siemens.com/cs/ww/en/ps/16276/td

The following technical information is intended to provide an initial overview of the various types of device and functions.

Туре		3RB3016, 3RB3113	3RB3026, 3RB3123		3RB3046, 3RB3143
Size	₫	S00	S0	S2	S3
Dimensions (W x H x D) (overload relay with stand-alone installation support)	*				
Screw terminals	mm	45 x 89 x 80	45 x 97 x 94	55 x 105 x 117	70 x 106 x 124
Spring-type terminals	mm	45 x 102 x 80	45 x 116 x 95	55 x 105 x 117	70 x 106 x 124
General data					
Tripping in the event of		Overload, phase failu + ground fault (for 3F	ure and phase asymm RB31 only)	netry	
Trip class acc. to IEC 60947-4-1	CLASS	3RB30: 10E, 20E; 3RB31: 5E, 10E, 20E	or 30E adjustable		
Phase failure sensitivity		Yes			
Reset and recovery					
Reset options after tripping		Manual and automat electrical remote RES	tic RESET, 3RB31 has SET (24 V DC)	an integrated connec	tion for
Recovery time					
- For automatic RESET		Approx. 3 min			
- For manual RESET		Immediately			
- For remote RESET		Immediately			
Features					
Display of operating state on device		Yes, by means of sw	itch position indicator	slide	
TEST function		Yes, test of electronic wiring of control circu	cs by pressing the TES uit by actuating the sw	ST button/test of auxili vitch position indicator	ary contacts and slide/self-monitoring
RESET button		Yes			
STOP button		No			
Protection and operation of explosion-proof motors					
EC type-examination certificate number according to directive 2014/34/EU (ATEX)		PTB 09 ATEX 3001  (x) II (2) G [Ex e] [Ex (x) II (2) G [Ex t] [Ex (x) II (2) G		oo kaaylan kiinyy 105013	227
Ambient temperatures		see milps://support.ii	idustry.sierrieris.com/	55/WW/eH/VIEW/405913	021
Storage/transport	°C	-40 +80			
Operation	°C	-25 +60			
Temperature compensation	°C	+60			
Permissible rated current at	C	+00			
- Temperature inside control cabinet 60 °C	%	100			
- Temperature inside control cabinet 60 °C	%	On request			
Repeat terminals	/0	Cirroquost			
Coil repeat terminals		Yes	Not required		
Auxiliary contact repeat terminal		Yes	Not required		
Degree of protection acc. to IEC 60529		100	ractioquilou		
Screw terminals/spring-type terminals		IP20			e additional terminal degree of protection)
Straight-through transformers				IP20	,
Touch protection acc. to IEC 60529		Finger-safe		Finger-safe, for vertice front	cal contact from the
Shock resistance with sine acc. to IEC 60068-2-27	<i>g</i> /ms	15/11 (signaling contact 97 position: 9 g/11 ms)	7/98 in "Tripped"	15/11 (signaling contact 97 position: 8 g/11 ms)	'/98 in "Tripped"

## SIRIUS 3RB3 Electronic Overload Relays

## 3RB30, 3RB31 for standard applications

Type	1	3RB3016, 3RB3113	3RB3026, 3RB3123	3RB3036, 3RB3133	3RB3046, 3RB3143			
Size	₫	S00	S0	S2	S3			
Dimensions (W x H x D) (overload relay with stand-alone installation support)								
Screw terminals	mm	45 x 89 x 80	45 x 97 x 94	55 x 105 x 117	70 x 106 x 124			
Spring-type terminals	mm	45 x 102 x 80	45 x 116 x 95	55 x 105 x 117	70 x 106 x 124			
General data (continued)								
Electromagnetic compatibility (EMC) – Interference immunity								
Conductor-related interference								
- Burst acc. to IEC 61000-4-4 (corresponds to degree of severity 3)	kV	2 (power ports), 1 (s	2 (power ports), 1 (signal port)					
- Surge acc. to IEC 61000-4-5 (corresponds to degree of severity 3)	kV	2 (line to earth), 1 (line	ne to line)					
Electrostatic discharge according to IEC 61000-4-2 (corresponds to degree of severity 3)	kV	8 (air discharge), 6 (	contact discharge)					
<ul> <li>Field-related interference acc. to IEC 61000-4-3 (corresponds to degree of severity 3)</li> </ul>	V/m	10						
Electromagnetic compatibility (EMC) - Emitted interferen	псе	Degree of severity B	acc. to EN 55011 (CI	SPR 11) and EN 5502	2 (CISPR 22)			
Resistance to extreme climates – air humidity	%	95						
Installation altitude above sea level	m	Up to 2 000						
Mounting position		Any						
Type of mounting		Direct mounting/stan	d-alone installation w	ith terminal support				

Туре		3RB3016, 3RB3113	3RB3026, 3RB3123	3RB3036, 3RB3133	3RB3046, 3RB3143		
Size		S00	S0	S2	S3		
Main circuit							
Rated insulation voltage <i>U</i> <sub>i</sub> (pollution degree 3)	V	690		690 1 000 with straight- through transformer	1000		
Rated impulse withstand voltage U <sub>imp</sub>	kV	6		6 8 with straight- through transformer	8		
Rated operational voltage $\emph{U}_{ m e}$	V	690		690 1 000 with straight- through transformer	1000		
Type of current							
Direct current		No					
Alternating current		Yes, 50/60 Hz $\pm$ 5 %					
Current setting	A A	0.1 0.4 up to 4 16	0.1 0.4 up to 10 40	12.5 50 and 20 80	12.5 50 and 32 115		
Heavy starting		see Manual	10 40	20 00	JZ 11J		
Power loss per unit (max.)	W	0.1 1.1	0.1 4.5	0.5 4.6	0.9 4.6		
Short-circuit protection							
With fuse without contactor		See "Selection and o	rdering data", pages	7/97 7/99			
With fuse and contactor		"Short-Circuit Protection with Fuses/Motor Starter Protectors for Motor Feeders" see Configuration Manual.					
Protective separation between main and auxiliary current paths acc. to IEC 60947-1 (pollution degree 2)							
For systems with grounded neutral point	V	690					
For systems with ungrounded neutral point	V	600					

## **Overload Relays** SIRIUS 3RB3 Electronic Overload Relays

## 3RB30, 3RB31 for standard applications

Туре		3RB3016, 3RB3113	3RB3026, 3RB3123	3RB3036, 3RB3133	3BB3046, 3BB3143
Size		S00	S0	S2	S3
Conductor cross-sections of main circuit					
Connection type		Screw termina	als		Screw terminals with box terminal
Terminal screw		M3, Pozidriv size 2	M4, Pozidriv size 2		4 mm Allen screw
Operating devices	mm	Ø 5 6	Ø 5 6		4 mm Allen screw
Prescribed tightening torque	Nm	0.8 1.2	2 2.5		4.5 6
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected					
Solid or stranded	mm <sup>2</sup>	$2 \times (0.5 \dots 1.5)^{1)}$ $2 \times (0.75 \dots 2.5)^{1)}$ , $2 \times (0.5 \dots 4)^{1)}$	2 x (1 2.5) <sup>1)</sup> , 2 x (2.5 10) <sup>†)</sup>	1 × (1 50) <sup>1)</sup> , 2 × (1 35) <sup>1)</sup>	2 × (2.5 16) <sup>1)</sup> , 2 × (10 50) <sup>1)</sup> , 1 × (10 70) <sup>1)</sup>
• Finely stranded with end sleeve (DIN 46228-1)	mm <sup>2</sup>	2 x (0.5 1.5) <sup>1)</sup> 2 x (0.75 2.5) <sup>1)</sup>	2 x (1 2.5) <sup>1)</sup> , 2 x (2.5 6) <sup>1)</sup> , max 1 x 10	2 x (1 25) <sup>1)</sup> , 1 x (1 35) <sup>1)</sup>	2 x (2.5 35) <sup>1)</sup> , 1 x (2.5 50) <sup>1)</sup>
AWG cables, solid or stranded	AWG	2 x (20 16) <sup>1)</sup> , 2 x (18 14) <sup>1)</sup> , 2 x 12	2 x (16 12) <sup>1)</sup> , 2 x (14 8) <sup>1)</sup>	2 x (18 2) <sup>1)</sup> , 1 x (18 1) <sup>1)</sup>	2 x (10 1/0) <sup>1)</sup> , 1 x (10 2/0) <sup>1)</sup>
Removable box terminals <sup>2)</sup>					
• With copper bars <sup>3)</sup>	mm				2 x 12 x 4
With cable lugs <sup>4)</sup>					
- Terminal screw					M6
- Prescribed tightening torque	Nm				4.5 6
- Usable ring terminal lugs	mm	-	-		$d_2 = min. 6.3$ $d_3 = max. 19$
Connection type		Spring-type to	erminals		
Operating devices	mm	3.0 x 0.5 and 3.5 x 0	.5		
Conductor cross-sections (min./max.), 1 conductor can be connected					
Solid or stranded	mm <sup>2</sup>	1 x (0.5 4)	1 x (1 10)		
Finely stranded without end sleeve	mm <sup>2</sup>	1 x (0.5 2.5)	1 x (1 6)		
• Finely stranded with end sleeve (DIN 46228-1)	$\text{mm}^2$	1 x (0.5 2.5)	1 x (1 6)		
AWG cables, solid or stranded	AWG	1 x (20 12)	1 x (18 8)		
Connection type		Straight-throu	igh transformers		
Diameter of opening	mm			15	18

<sup>1)</sup> If two different conductor cross-sections are connected to one clamping point, both cross-sections must be in the range specified.

<sup>2)</sup> Cable lug and busbar connection possible after removing the box terminals.

 <sup>3)</sup> If bars larger than 12 mm x 10 mm are connected, a 3RT2946-4EA2 cover is needed to maintain the required phase clearance, see page 7/101.
 4) When conductors larger than 25 mm² are connected, the 3RT2946-4EA2 cover is needed to maintain the required phase clearance, see page 7/101.

## SIRIUS 3RB3 Electronic Overload Relays

## 3RB30, 3RB31 for standard applications

					-
Туре		3RB3016, 3RB3113	3RB3026, 3RB3123	3RB3036, 3RB3133	3RB3046, 3RB3143
Size		S00	S0	S2	S3
Auxiliary circuit					
Number of NO contacts		1			
Number of NC contacts		1			
Auxiliary contacts – assignment		1 NO for the signal "1 1 NC for disconnection			
Rated insulation voltage <i>U</i> <sub>i</sub> (pollution degree 3)	V	300			
Rated impulse withstand voltage U <sub>imp</sub>	kV	4			
Auxiliary contacts – contact rating					
<ul> <li>NC, NO contact with alternating current AC-14/AC-15, rated operational current I<sub>e</sub> at U<sub>e</sub> <ul> <li>24 V</li> <li>120 V</li> <li>125 V</li> <li>250 V</li> </ul> </li> <li>NC, NO contacts with DC current DC-13, rated operational current I<sub>e</sub> at U<sub>e</sub> <ul> <li>24 V</li> <li>60 V</li> <li>110 V</li> <li>125 V</li> <li>250 V</li> </ul> </li> <li>Conventional thermal current I<sub>th</sub></li> <li>Contact reliability</li> </ul>	444444444444444444444444444444444444444	4 4 4 4 3 2 0.55 0.3 0.3 0.11 5 Yes			
(suitability for PLC control; 17 V, 5 mA)  Short-circuit protection					
With fuse, operational class gG	А	6			
Ground-fault protection (only 3RB31)			s to sinusoidal residu	al currents at 50/60 H	<u>Z</u> .
$ullet$ Tripping value $I_{\scriptscriptstyle \Lambda}$		$> 0.75 \times I_{\text{motor}}$			
• Operating range <i>I</i>			$g < I_{motor} < 3.5 \times upp$	er current setting	
• Response time $t_{\text{trip}}$ (in steady-state condition)	S	< 1			
Integrated electrical remote RESET (only 3RB31)					
Connecting terminals A3, A4		24 V DC, max. 200 n	nA for approx. 20 ms,	then < 10 mA	
Protective separation between auxiliary current paths acc. to IEC 60947-1	V	300			

Туре		3RB3016, 3RB3113	3RB3026, 3RB3123	3RB3036, 3RB3133	3RB3046, 3RB3143
Size		S00	S0	S2	S3
CSA, UL, UR rated data					
Auxiliary circuit – switching capacity		B600, R300			
Conductor cross-sections for auxiliary circuit					
Connection type		Screw termina	ıls		
Terminal screw		M3, Pozidriv size 2			
Operating devices	mm	Ø 5 6			
Prescribed tightening torque	Nm	0.8 1.2			
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected					
Solid or stranded	mm <sup>2</sup>	$1 \times (0.5 \dots 4)^{1)}, 2 \times (0.5 \dots 4)^{1}$	0.5 2.5) <sup>1)</sup>		
• Finely stranded with end sleeve (DIN 46228-1)	$mm^2$	$1 \times (0.5 \dots 2.5)^{1)}, 2 \times$	(0.5 1.5) <sup>1)</sup>		
AWG cables, solid or stranded	AWG	2 × (20 14)			
Connection type		Spring-type te	rminals		
Operating devices	mm	3.0 x 0.5			
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected					
Solid or stranded	$\mathrm{mm}^2$	2 × (0.25 1.5)			
• Finely stranded without end sleeve	$\text{mm}^2$	2 × (0.25 1.5)			
• Finely stranded with end sleeve (DIN 46228-1)	mm <sup>2</sup>	2 × (0.25 1.5)			
<ul> <li>AWG cables, solid or stranded</li> </ul>	AWG	2 × (24 16)			

<sup>1)</sup> If two different conductor cross-sections are connected to one clamping point, both cross-sections must be in the range specified.

## **Overload Relays** SIRIUS 3RB3 Electronic Overload Relays

IE3/IE4 ready 3RB30, 3RB31 for standard applications

## Selection and ordering data

## 3RB30 electronic overload relays, CLASS 10E

Features and technical specifications:

- Connection methods
  - Sizes S00 and S0:
    - Main and auxiliary circuit: Either screw or spring-type terminals
  - Sizes S2 and S3:
  - Main circuit: Screw terminals with box terminal or as straight-through transformer,
  - Auxiliary circuit: Either screw or spring-type terminals
- Overload protection, phase failure protection and asymmetry
- Internal power supply
- Auxiliary contacts 1 NO + 1 NC
- · Manual and automatic RESET
- Switch position indicator
- TEST function and self-monitoring
- Sealable covers (optional accessory)

PU (UNIT, SET, M) = 1 PS<sup>\*</sup> = 1 unit PG = 41G













Size

contactor

Size S00 S00

Rated power for three-phase

motors rated value<sup>1)</sup>

Current setting value of the inverse-time delayed overload

Short-circuit protection with fuse, type of coordination "2", operational class gG2)

SD

Screw terminals

⊕ SD Price per PU d Article No.

2

Spring-type terminals

Price per PU

K	۷	۷	
			Ī

Devices for mounting onto contactor

0.04 0.09	0.1 0.4	4
0.12 0.37	0.32 1.25	6
0.55 1.5	1 4	20
1.1 5.5	3 12	25
2.2 7.5	4 16	25

b.

	3HB3016-1HB0
<b>&gt;</b>	3RB3016-1NB0
<b>&gt;</b>	3RB3016-1PB0
<b>&gt;</b>	3RB3016-1SB0
▶	3RB3016-1TB0

Article No

3RB3016-1RE0 3RB3016-1NE0 2

3RB3016-1PE0 3RB3016-1SE0 3RB3016-1TE0

## Size S0

#### Devices for mounting onto contactor3)

0.04 0.09	0.1 0.4	4	
0.12 0.37	0.32 1.25	6	
0.55 1.5	1 4	20	
1.1 5.5	3 12	25	
3 11	6 25	50	
5.5 18.5	10 40	50	

<b>&gt;</b>	3RB3026-1RB0
<b>&gt;</b>	3RB3026-1NB0
▶	3RB3026-1PB0
▶	3RB3026-1SB0
<b>&gt;</b>	3RB3026-1QB0
<b>&gt;</b>	3RB3026-1VB0

2	3RB3026-1RE0
2	3RB3026-1NE0
2	3RB3026-1PE0
2	3RB3026-1SE0
2	3RB3026-1QE0

3RB3026-1VE0

#### Size S2

## Devices with screw terminals (main current side) and

for mounting	onto contactor
7.5 22	12.5 50

7.5 22	12.5 50
11 37	20 80

250		
250		

315

>	3RB3036-1UB0 3RB3036-1WB0

3RB3046-1UB0

3RB3046-1XB0

#### Devices with straight-through transformer for stand-alone installation

.5 22	12.5 50	250
1 37	20 80	250

<b>&gt;</b>	3RB3036-1UW1
<b>&gt;</b>	3RB3036-1WW1

3RB3036-1UX1
3RB3036-1WX1

## Devices with screw terminals (main current side) and for mounting onto contactor<sup>3)</sup>

ioi illoulitilig	Unito Comación
7.5 22	12.5 50
40 5 55	00 115

Devices with	straight-through	transformer for stand-	alone
18.5 55	32 115	315	

12.5 50	200
32 115	315

<sup>3</sup>RB3046-1UW1 3RB3046-1XW1

	3RB3046-1UW1 3RB3046-1XW1		3RB3046-1UX1 3RB3046-1XX1
3) With t	he appropriate terminal support	s (see	e "Accessories", page 7/100),

3RB3046-1UD0

3RB3046-1XD0

For reliable operational current, note derating information, see Manual.

these overload relays can also be installed as stand-alone units.

installation 7.5 ... 22

18.5 ... 55

<sup>1)</sup> Guide value for 4-pole standard motors at 50 Hz 400 V AC. The actual starting and rated data of the motor to be protected must be considered when selecting the units.

Maximum protection by fuse only for overload relays, type of coordination "2".

For fuse values in connection with contactors, see Configuration Manual.

Note:

## SIRIUS 3RB3 Electronic Overload Relays

## 3RB30, 3RB31 for standard applications IE3/IE4 ready

## 3RB30 electronic overload relays, CLASS 20E

Features and technical specifications:

- · Connection methods
- Sizes S00 and S0:
  - Main and auxiliary circuit: Either screw or spring-type terminals
- Sizes S2 and S3:
  - Main circuit: Screw terminals with box terminal or as straight-through transformer,
- Auxiliary circuit: Either screw or spring-type terminals
- Overload protection, phase failure protection and asymmetry protection
- Internal power supply
- Auxiliary contacts 1 NO + 1 NC
- Manual and automatic RESET
- Switch position indicator
- · TEST function and self-monitoring
- Sealable covers (optional accessory)

PU (UNIT, SET, M) = 1 PS\* = 1 unit = 41G













3RB3016	5-2.BC
Size	Ra

contactor

Rated power for three-phase motors rated value 1)

the inverse-time delayed overload release

Current setting value of Short-circuit protection with fuse, type of coordination "2", operational class gG<sup>2)</sup> SD Screw terminals

⊕ SD Price

Spring-type terminals

kW

Article No.

per PU

Article No. Price per PU

Size	S00	
S00		

Devices for	mounting	onto	contactor3)
0.04 0.09	0.1	0.4	4

0.04 0.09	0.1 0.4	4
0.12 0.37	0.32 1.25	6
0.55 1.5	1 4	20
1.1 5.5	3 12	25
2.2 7.5	4 16	25

3RB3016-2RB0 3RB3016-2NB0 3RB3016-2PB0 3RB3016-2SB0 3RB3016-2TB0

2 3RB3016-2RE0 3RB3016-2NE0 2 3RB3016-2PE0 2 2 3RB3016-2SE0 3RB3016-2TE0

## Devices for mounting anto contactor3

Devices ioi	mounting onto contac	lui '
0.04 0.09	0.1 0.4	4
0.12 0.37	0.32 1.25	6
0.55 1.5	1 4	20
1.1 5.5	3 12	25
3 11	6 25	50
5.5 18.5	10 40	50

3RB3026-2RB0 3RB3026-2NB0 3RB3026-2PB0 3RB3026-2SB0 3RB3026-2QB0 3RB3026-2VB0

2 3RB3026-2RE0 2 3RB3026-2NE0 2 3RB3026-2PF0 2 3RB3026-2SE0 2 3RB3026-2QE0 3RB3026-2VE0

## Devices with screw terminals (main current side) and

ior mounting	onto contactor-
7.5 22	12.5 50
11 37	20 80

3RB3036-2WB0

3RB3036-2UB0 3RB3036-2UD0

3RB3036-2WD0

3RB3036-2UX1

3RB3036-2WX1

#### Devices with straight-through transformer for stand-alone installation

11 37	20 80	250	
11 37	20 60	230	

11 37	20 80	250	
NEW			
Devices wi	ith screw terminals ( ng onto contactor <sup>3)</sup>	main current side) and	1

7.5 22	12.5 50	200	X 3RB3046-2UB0	
18.5 55	32 115	315	X 3RB3046-2XB0	

250

250

Χ	3RB3046-2XB0

3RB3046-2UW1

3RB3046-2XW1

Χ

3RB3036-2UW1

3RB3036-2WW1

3RB3046-2UD0 Χ 3RB3046-2XD0

3RB3046-2UX1

3RB3046-2XX1

#### Devices with straight-through transformer for stand-alone installation

7.5 22	12.5 50	200	
18.5 55	32 115	315	
Guide value for 4-pole star	ndard motors at 50	Hz 400 V AC. The actual	

Χ

Χ

<sup>3)</sup> With the appropriate terminal supports (see "Accessories", page 7/100), these overload relays can also be installed as stand-alone units.

starting and rated data of the motor to be protected must be considered when selecting the units 2) Maximum protection by fuse only for overload relays,

type of coordination \*2'.
For fuse values in connection with contactors, see Configuration Manual.

## **Overload Relays** SIRIUS 3RB3 Electronic Overload Relays

## IE3/IE4 ready 3RB30, 3RB31 for standard applications

## 3RB31 electronic overload relays, CLASS 5E, 10E, 20E or 30E (adjustable)

Features and technical specifications:

- · Connection methods
  - Sizes S00 and S0:
    - Main and auxiliary circuit: Either screw or spring-type terminals
  - Sizes S2 and S3:
  - Main circuit: Screw terminals with box terminal or as straight-through transformer,
  - Auxiliary circuit: Either screw or spring-type terminals
- Overload protection, phase failure protection and asymmetry protection
- Internal ground-fault detection (activatable)

- Internal power supply
- Auxiliary contacts 1 NO + 1 NC
- Manual and automatic RESET
- Electrical remote RESET integrated
- Switch position indicator
- TEST function and self-monitoring
- Sealable covers (optional accessory)

PU (UNIT, SET, M) = 1 PS\* = 1 unit РG = 41G













odo	1	13-4	ı	$\Box$

contactor

3RB3123-4VB0

Rated power for

three-phase motors, rated value<sup>1)</sup>

Current setting value Short-circuit protection SD with fuse, type of coordination "2" operational class gG<sup>2)</sup> of the inverse-time delayed overload

**Screw terminals** Price per PU Article No.

Spring-type terminals Article No. Price per PU

	kW	Α	Α
Size S00			
S00	Devices for	r mounting onto	o contactor <sup>3)</sup>

Devices ioi	mounting onto contactor	•	
0.04 0.09	0.1 0.4	4	
0.12 0.37	0.32 1.25	6	
0.55 1.5	1 4	20	
1.1 5.5	3 12	25	
2.2 7.5	4 16	25	

▶	3RB3113-4RB0	2	3RB3113-4RE0
▶	3RB3113-4NB0	2	3RB3113-4NE0
▶	3RB3113-4PB0	2	3RB3113-4PE0
▶	3RB3113-4SB0	2	3RB3113-4SE0
<b>&gt;</b>	3RB3113-4TB0	2	3RB3113-4TE0

Size S0			
S0	Devices for m	ounting onto conta	ctor <sup>3)</sup>
	0.04 0.09	0.1 0.4	4
	0.12 0.37	0.32 1.25	6

0.04 0.09	0.1 0.4	4
0.12 0.37	0.32 1.25	6
0.55 1.5	1 4	20
1.1 5.5	3 12	25
3 11	6 25	50
5.5 18.5	10 40	50

▶	3RB3123-4RB0
▶	3RB3123-4NB0
▶	3RB3123-4PB0
▶	3RB3123-4SB0
<b>&gt;</b>	3RB3123-4QB0
<b>&gt;</b>	3RB3123-4VB0

2	3RB3123-4RE0
2	3RB3123-4NE0
2	3RB3123-4PE0
2	3RB3123-4SE0
2	3RB3123-4QE0

3RB3123-4VE0

## Devices with screw terminals (main current side) and for mounting onto contactor $^{3)}$ S2

7.5 22	12.5 50
11 37	20 80

250	
250	

3RB3133-4UB0
3RB3133-4WB0

3RB3133-4UD0 3RB3133-4WD0

#### Devices with straight-through transformer for stand-alone installation

7.5 22	12.5 50	250	
11 37	20 80	250	

<b>&gt;</b>	3RB3133-4UW1
<b>&gt;</b>	3RB3133-4WW1

3RB3143-4UW1

3RB3143-4XW1

Χ

Χ

<b></b>	3RB3133-4UX1
<b></b>	3RB3133-4WX1

3RB3143-4UD0

3RB3143-4XD0

3RB3143-4UX1

3RB3143-4XX1

S3

## Devices with screw terminals (main current side) and for mounting onto contactor<sup>3)</sup>

7.5 22	12.5 50	200	X	3RB3143-4UB0
18.5 55	32 115	315	Χ	3RB3143-4XB0

200

#### Devices with straight-through transformer for stand-alone installation

	18.5 55	32 115	315	
1) Guide valu	e for 4-pole standa	ard motors at 50 Hz	400 V AC. The actual	4

12.5 ... 50

Χ

Χ

Χ

7.5 ... 22

when selecting the units.

<sup>2)</sup> Maximum protection by fuse only for overload relays, type of coordination "2".

For fuse values in connection with contactors, see Configuration Manual. 3) With the appropriate terminal supports (see "Accessories", page 7/100), these overload relays can also be installed as stand-alone units.

<sup>\*</sup> You can order this quantity or a multiple thereof. Illustrations are approximate

## SIRIUS 3RB3 Electronic Overload Relays

## Accessories

## Overview

The following optional accessories are available for the 3RB30/3RB31 electronic overload relays:

- Size-specific terminal support for stand-alone installation, in sizes \$00 and \$0 also with spring-type terminals
- Mechanical RESET (for all sizes)
- Cable release for resetting devices which are difficult to access (for all sizes)
- Sealable cover (for all sizes)

## S

Selection and	ordering data								
	Version	Size	Š	SD	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
			(	d					
Terminal suppo	orts for stand-alone installation								
	Terminal supports for overload relays with screw terminals				Screw terminals	<b>⊕</b>			
200	For separate mounting of the overload relays;	S00	I	<b>&gt;</b>	3RU2916-3AA01		1	1 unit	41F
	screw and snap-on mounting onto standard mounting rail	S0	- 1	<b>&gt;</b>	3RU2926-3AA01		1	1 unit	41F
100		S2	I	>	3RU2936-3AA01		1	1 unit	41F
3RU2916-3AA01		S3	NEW	1	3RU2946-3AA01		1	1 unit	41F
	Terminal supports for overload relays with spring-type terminals				Spring-type terminals	$\stackrel{\infty}{\mathbb{H}}$			
000	For separate mounting of the overload relays;	S00	Į.	5	3RU2916-3AC01		1	1 unit	41F
	screw and snap-on mounting onto standard mounting rail		ţ	5	3RU2926-3AC01		1	1 unit	41F
3RU2926-3AA01									
222									
3RU2936-3AA01									
<b>100</b>									
3RU2946-3AA01									
100 A									

S00 ... S3


888	1		
7		1	
		h	

3RU2916-3AC01



3RU2926-3AC01

Mechanical RE	SET
and the	Resetting plungers, holders and formers
<b>/</b> **	Pushbuttons with extended stroke (12 mm), IP65, Ø 22 mm
	Extension plungers For compensation of the distance between a pushbutton and the unlatching button of the relay
3RB3980-0A with pushbutton and extension	



plungers

# Overload Relays SIRIUS 3RB3 Electronic Overload Relays

									Access	ories
	Version			Size	SD	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
Cable releases	with holder for RESI	ĒΤ								
яſ	For Ø 6.5 mm holes in t max. control panel thic									
	• Length 400 mm	KIIC33 O IIIIII		S00 S3	<b></b>	3RB3980-0B		1	1 unit	41F
	• Length 600 mm			S00 S3	•	3RB3980-0C		1	1 unit	41F
3RB3980-0.										
Sealable cover	For covering the setting	g knobs		S00 S3	<b>&gt;</b>	3RB3984-0		1	1 unit	41F
3RB3984-0										
Terminal cover										
=1=1=	Covers for devices wi (box terminals) Additional touch protect terminals					Screw terminals	<b>+</b>			
3RT2936-4EA2	Main current level			S2 S3 <b>NEW</b>	2	3RT2936-4EA2 3RT2946-4EA2		1 1	1 unit 1 unit	41B 41B
General acces	sories							_		
	Version	Size	Color	For overload relays	SD	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
Tools for open	ing spring-type termi	nals			d					
						Spring-type terminals	$\stackrel{\circ}{\square}$			
Silver	Screwdrivers	Length, approx.	Titanium	Main and	2	3RA2908-1A	Ш	1	1 unit	41B
3RA2908-1A	For all SIRIUS devices with spring-type terminals		gray/	auxiliary circuit connection: 3RB3					, dinic	5
Blank labels										
	<b>Unit labeling plates</b> 1) For SIRIUS devices	20 mm x 7 mm	Pastel turquoise	3RB3	20	3RT1900-1SB20		100	340 units	41B
		20 mm x 7 mm	Titanium gray	3RB3	20	3RT2900-1SB20		100	340 units	41B
11429b	Adhesive inscription labels <sup>1)</sup>	19 mm x 6 mm	Pastel turquoise	3RU2	15	3RT1900-1SB60		100	3 060 units	41B
3RT1900-1SB20	For SIRIUS devices	19 mm x 6 mm	Zinc yellow	3RU2	15	3RT1900-1SD60		100	3 060 units	41B
3RT2900-1SB20	iem for individual inscripti	on	yonow							

PC labeling system for individual inscriptior of unit labeling plates available from: murrplastik Systemtechnik GmbH (see page 16/20).

## SIRIUS 3RB2 Electronic Overload Relays

## 3RB20, 3RB21 for standard applications

## Overview


## More information

Home page, see http://www.siemens.com/sirius-overloadrelays Industry Mall, see www.siemens.com/product?3RB2

Application Manual "SIRIUS Controls with IE3/IE4 Motors", see https://support.industry.siemens.com/cs/ww/en/view/94770820

Manual "SIRIUS - SIRIUS 3RU Thermal Overload Relays / SIRIUS 3RB Electronic Overload Relays", see https://support.industry.siemens.com/cs/ww/en/view/60298164

Characteristics and certificates, see https://support.industry.siemens.com/cs/ww/en/ps/16278



1 3RB2 overload relay Sizes S6 to S10/S12


Mountable accessories

- (2) Terminal cover
- 3 Box terminals
- 4) Cable release with holder for RESET
- (5) Sealable cover
- 6 Mechanical RESET
- 7 Pushbutton

Mountable accessories for 3RB2 electronic overload relays (sizes S6 to S10/S12)

# Overload Relays SIRIUS 3RB2 Electronic Overload Relays

## 3RB20, 3RB21 for standard applications



- (1) Switch position indicator and TEST function of the wiring: Indicates a trip and enables the wiring test.
- 2 Trip class setting/internal ground-fault detection (only 3RB21): Using the rotary switch you can set the required trip class and activate the internal ground-fault detection dependent on the start-up conditions.
- Solid-state test (device test): Enables a test of all important device components and functions.
- 4 Connecting terminals (removable terminal block for auxiliary circuits): The generously sized terminals permit connection of two conductors with different cross-sections for the main and auxiliary circuits. The auxiliary circuit can be connected with screw terminals and alternatively with spring-type terminals.
- (5) Selector switch for manual/automatic RESET: With the slide switch you can choose between manual and automatic RESET.
- Motor current setting: Setting the device to the rated motor current is easy with the large rotary knob.
- A device set to manual RESET can be reset locally by pressing the RESET button. On the 3RB21 overload relay a solid-state remote RESET is integrated.
- 8 Connection for mounting onto contactors:
  Optimally adapted in electrical, mechanical and design terms to the contactors 3RT1. These connecting pins can be used for direct mounting of the overload relay to the contactor. Stand-alone installation is possible as an alternative (partly in conjunction with a terminal bracket for stand-alone installation).

SIRIUS 3RB2153-4FW2 electronic overload relay

The 3RB20 and 3RB21 electronic overload relays up to 630 A with internal power supply have been designed for current-dependent protection of loads with normal and heavy starting (see Manual) against excessive temperature rises due to overload, phase asymmetry or phase failure.

An overload, phase asymmetry or phase failure result in an increase of the motor current beyond the set rated motor current. This current rise is detected by the current transformers integrated into the devices and evaluated by corresponding solid-state circuits which then output a pulse to the auxiliary contacts. The auxiliary contacts then switch off the load by means of a contactor. The break time depends on the ratio between the tripping current and the current setting  $I_{\rm e}$  and is stored in the form of a long-term stable tripping characteristic curve, see Characteristic curves.

In addition to inverse-time delayed protection of loads against excessive temperature rises due to overload, phase asymmetry and phase failure, the 3RB21 electronic overload relays also allow internal ground-fault detection (not possible in conjunction with contactor assemblies for star-delta (wye-delta) starting). This provides protection of loads against high-resistance short circuits due to damage to the insulation material, moisture, condensed water etc.

The "tripped" status is signaled by means of a switch position indicator. The relay is reset manually or automatically after the recovery time has elapsed.

The 3RB2 electronic overload relays are suitable for operation with frequency converters, see Manual.

The devices are manufactured in accordance with environmental guidelines and contain environmentally friendly and reusable materials. They comply with all important worldwide standards and approvals.

For 3RB30 and 3RB31 overload relay sizes S00 to S3, see page 7/97 onwards.

#### Use in hazardous areas

The 3RB20/3RB21 electronic overload relays are suitable for the overload protection of motors with the following types of protection:

- 🚱 II (2) G [Ex e] [Ex d] [Ex px]
- 😥 II (2) D [Ex t] [Ex p]

EC type test certificate for Group II, Category (2) G/D exists. It has the number PTB 06 ATEX 3001.

## SIRIUS 3RB2 Electronic Overload Relays

## 3RB20, 3RB21 for standard applications

#### Article No. scheme

Product versions		Article number
Electronic overload relays		3RB2 🗆 🗆 🗆 — 🗆 🗆 🗆
Device type	e. g. 0 = standard device, with internal supply, for three-phase loads	
Size, rated operational current and power	e. g. 5 = 200 A (90 kW) for size S6	
Version of the automatic RESET, electrical remote RESET	e. g. 6 = switchable between manual/auto RESET	
Trip class (CLASS)	e. g. 1 = CLASS 10E	
Setting range of the overload release	e.g. F = 5 200 A	
Connection methods	e.g. C = busbar connections main circuit; screw terminals auxiliary circuit	
Installation type	e. g. 2 = mounting on contactor and stand-alone installation	
Example		3RB2 0 5 6 - 1 F C 2

## Note:

The Article No. scheme shows an overview of product versions for better understanding of the logic behind the article numbers.

For your orders please use the article numbers quoted in the selection and ordering data.

## Benefits

The most important features and benefits of the 3RB20/3RB21 electronic overload relays are listed in the overview table (see "General Data", page 7/71 onwards)

## Application

#### Industries

The 3RB20 and 3RB21 electronic overload relays are suitable for customers from all industries who want to guarantee optimum inverse-time delayed protection of their electrical loads (e.g. motors) under normal and heavy starting conditions (CLASS 5E to 30E), minimize project completion times, inventories and energy consumption, and optimize plant availability and maintenance management.

## Application

The 3RB20 and 3RB21 electronic overload relays have been designed for the protection of three-phase motors in sinusoidal 50/60 Hz voltage networks. The relays are not suitable for the protection of single-phase AC or DC loads.

The 3RU21 thermal overload relays or the 3RB22 to 3RB24 electronic overload relays can be used for single-phase AC loads. For DC loads we recommend the 3RU21 thermal overload relay.

#### Ambient conditions

The devices are insensitive to external influences such as shocks, corrosive ambient conditions, ageing and temperature fluctuations.

For the temperature range from -25 C to +60 °C, the 3RB20 and 3RB21 electronic overload relays compensate the temperature in accordance with IEC 60947-4-1.

For the 3RB20 and 3RB21 electronic overload relays with the sizes S6, S10 and S12, the upper set value of the setting range must be reduced for ambient temperatures > 50 °C by a certain factor.

## Use of SIRIUS protection devices in conjunction with IE3/IE4 motors

#### Note:

For the use of 3RB20 and 3RB21 electronic overload relays in conjunction with highly energy-efficient IE3/IE4 motors, please observe the information on dimensioning and configuring, see Application Manual.

For more information, see Preface on page 7.

## **Overload Relays** SIRIUS 3RB2 Electronic Overload Relays

3RB20, 3RB21 for standard applications

## Technical specifications

## More information

Configuration Manual "Configuring SIRIUS Innovations – Selection Data for Fuseless and Fused Load Feeders", see https://support.industry.siemens.com/cs/ww/en/view/39714188

Manual "SIRIUS – SIRIUS 3RU Thermal Overload Relays / SIRIUS 3RB Electronic Overload Relays", see https://support.industry.siemens.com/cs/ww/en/view/60298164

Technical specifications, see https://support.industry.siemens.com/cs/ww/en/ps/16278

The following technical information is intended to provide an initial overview of the various types of device and functions.

Type		3RB2056, 3RB2153	3RB2066, 3RB2163
Size I II		S6	S10/S12
Dimensions (W x H x D) (overload relay with stand-alone installation support)	mm	120 x 119 x 155	145 x 147 x 156
General data			
Tripping in the event of		Overload, phase failure and phase asymmetry + ground fault (for 3RB21 only)	
Trip class acc. to IEC 60947-4-1 CLASS		3RB20: 10E or 20E; 3RB21: 5E, 10E, 20E and 30E adjustable	
Phase failure sensitivity		Yes	
Overload warning		No	
Reset and recovery			
Reset options after tripping		3RB20: Manual and automatic RESET; 3RB21: Manual, Automatic and Remote RESET	
Recovery time			
- For automatic RESET		Approx. 3 min	
- For manual RESET	Immediately		
- For remote RESET		Immediately	
Features			
Display of operating state on device		Yes, by means of switch position indicator slide	
TEST function			ing the TEST button/ test of auxiliary contacts actuating the switch position indicator slide/
RESET button		Yes	
STOP button	No		
Protection and operation of explosion-proof motors			
EC type-examination certificate number		PTB 06 ATEX 3001	
according to directive 2014/34/EU (ATEX)		(2) G [Ex e] [Ex d] [Ex px]	
		€ II (2) G [Ex t] [Ex p]	
		see https://support.industry.siemens	.com/cs/ww/en/view/23814648
Ambient temperatures			
Storage/transport	°C	-40 +80	
Operation	°C	-25 +60	
Temperature compensation	°C	+60	
Permissible rated current at			4)
- Temperature inside control cabinet 60 °C, stand-alone installation	%	100	100 or 90 <sup>1)</sup>
- Temperature inside control cabinet 60 °C, mounted on contactor	%	70	70
- Temperature inside control cabinet 70 °C	%	On request	
<b>Degree of protection</b> acc. to IEC 60529			
Screw terminals/busbar connections		<ul><li>IP20 (front side)</li><li>Terminal IP00 (use additional protection)</li></ul>	terminal covers for higher degree of
Straight-through transformers		IP20	

## SIRIUS 3RB2 Electronic Overload Relays

## 3RB20, 3RB21 for standard applications

Туре		3RB2056, 3RB2153	3RB2066, 3RB2163	
Size Dize		S6	S10/S12	
Dimensions (W x H x D) (overload relay with stand-alone installation support)	mm	120 x 119 x 155	145 x 147 x 156	
General data (continued)				
Touch protection acc. to IEC 60529				
Screw terminals/busbar connections		Finger-safe with terminal covers for ver	tical contact from the front	
Straight-through transformers		Finger-safe		
Shock resistance with sine acc. to IEC 60068-2-27	<i>g</i> /ms	15/11 (signaling contact 97/98 in positi	on "tripped": 4 g/ 11 ms	
Electromagnetic compatibility (EMC) – Interference immunity				
Conductor-related interference				
- Burst acc. to IEC 61000-4-4 (corresponds to degree of severity 3)		2 (power ports), 1 (signal port)		
- Surge acc. to IEC 61000-4-5 (corresponds to degree of severity 3)	kV	2 (line to earth), 1 (line to line)		
Electrostatic discharge according to IEC 61000-4-2 (corresponds to degree of severity 3)	kV	8 (air discharge), 6 (contact discharge	)	
Field-related interference acc. to IEC 61000-4-3 (corresponds to degree of severity 3)	V/m	10		
Electromagnetic compatibility (EMC) – Emitted interference		Degree of severity B acc. to EN 55011 (CISPR 11) and EN 55022 (CISPR 22)		
Resistance to extreme climates – air humidity	%	100		
Installation altitude above sea level	m	Up to 2 000		
Mounting position		Any		
Type of mounting		Direct mounting/stand-alone installation	n	

# Overload Relays SIRIUS 3RB2 Electronic Overload Relays

## 3RB20, 3RB21 for standard applications

Туре		3RB2056, 3RB2153	3RB2066, 3RB2163
Size		S6	S10/S12
Main circuit			
Rated insulation voltage U <sub>i</sub> (pollution degree 3)	V	1 000	
Rated impulse withstand voltage U <sub>imp</sub>	kV	8	
Rated operational voltage U <sub>e</sub>	V	1 000	
Type of current			
Direct current		No	
Alternating current		Yes, 50/60 Hz ± 5 %	
Current setting	А	50 200	55 250, 160 630
Power loss per unit (max.)	W	0.05	
Short-circuit protection			
With fuse without contactor		See "Selection and ordering data", p	pages 7/109 7/111
With fuse and contactor		"Short-Circuit Protection with Fuses/I	Motor Starter Protectors for Motor
		Feeders" see Configuration Manual.	
Protective separation between main and auxiliary current paths			
acc. to IEC 60947-1 (pollution degree 2)		000	
For systems with grounded neutral point	V	690	
For systems with ungrounded neutral point	V	600	
Conductor cross-sections of the main circuit			
Connection type		Screw terminals with box terminal	
Terminal screw	mm	4 mm Allen screw	5 mm Allen screw
Operating devices	mm	4 mm Allen screw	5 mm Allen screw
Prescribed tightening torque	Nm	1 12	20 22
Conductor cross-sections (min./max.), 1 or 2 conductors can be conr			
• Solid	mm <sup>2</sup>		
Finely stranded without end sleeve	mm <sup>2</sup>	With 3RT1955-4G box terminal:	2 × (50 185),
Thirty strainaga without one oldeve		$2 \times (1 \times \text{max. } 50, 1 \times \text{max. } 70),$	Front clamping point only:
		1 × (10 70);	1 × (70 240);
		With 3RT1956-4G box terminal: $2 \times (1 \times \text{max. } 95, 1 \times \text{max. } 120),$	Rear clamping point only: 1 × (120 185)
		1 × (10 120)	1 × (120 100)
• Finely stranded with end sleeve (DIN 46228-1)	$\text{mm}^2$	With 3RT1955-4G box terminal:	2 × (50 185),
		$2 \times (1 \times \text{max. } 50, 1 \times \text{max. } 70),$	Front clamping point only:
		1 × (10 70); With 3RT1956-4G box terminal:	1 × (70 240); Rear clamping point only:
		$2 \times (1 \times \text{max. } 95, 1 \times \text{max. } 120),$	1 × (120 185)
		1 × (10 120)	
• Stranded	$mm^2$	With 3RT1955 -4G box terminal:	2 × (70 240),
		2 × (max. 70), 1 × (16 70);	Front clamping point only: 1 × (95 300);
		With 3RT1956-4G box terminal:	Rear clamping point only:
		$2 \times (\text{max. } 120),$	1 × (120 240)
- ANNO - ships	A).4/O	1 × (16 120)	0 (0/0 500 : ")
AWG cables, solid or stranded	AWG	With 3RT1955-4G box terminal: $2 \times (\text{max. } 1/0)$ ,	2 × (2/0 500 kcmil), Front clamping point only:
		1 × (6 2/0);	1 × (3/0 600 kcmil);
		With 3RT1956-4G box terminal:	Rear clamping point only:
		2 × (max. 3/0), 1 × (6 250 kcmil)	1 × (250 kcmil 500 kcmil)
Ribbon cables (Number x Width x Thickness)	mm	With 3RT1955-4G box terminal:	$2 \times (20 \times 24 \times 0.5)$
Thibboil cables (Nulliber & Width & Thickness)	111111	$2 \times (6 \times 15.5 \times 0.8),$	$1 \times (6 \times 9 \times 0.8 \dots 20 \times 24 \times 0.5),$
		$1 \times (3 \times 9 \times 0.8 \dots 6 \times 15.5 \times 0.8);$	·
		With 3RT1956-4G box terminal: $2 \times (10 \times 15.5 \times 0.8)$ ,	
		$1 \times (3 \times 9 \times 0.8 \dots 10 \times 15.5 \times 0.8)$	
Connection type		oo Busbar connections	
T		M005	M40 00
Terminal screw	Nino	M8 × 25	M10 × 30
Prescribed tightening torque	Nm	10 14	14 24
Conductor cross-sections (min./max.)	ر و	10 051)	50 0402)
Finely stranded with cable lug	mm <sup>2</sup>	16 95 <sup>1)</sup>	50 240 <sup>2)</sup>
Stranded with cable lug	mm <sup>2</sup>	25 120 <sup>1)</sup>	70 240 <sup>2)</sup>
AWG cables, solid or stranded, with cable lug	AWG	4 250 kcmil	2/0 500 kcmil
With connecting bars (max. width)	mm	15	25
Connection type		Straight-through transforme	rs

When connecting cable lugs according to DIN 46235 with conductor cross-sections of 95 mm<sup>2</sup> and more, the 3RT1956-4EA1 terminal cover must be used to ensure phase clearance, see page 7/112.

When connecting cable lugs according to DIN 46234 for conductor cross-sections from 240 mm², as well as DIN 46235 for cable cross-sections from 185 mm², the 3RT1956-4EA1 terminal cover must be used to ensure phase clearance, see page 7/112.

## SIRIUS 3RB2 Electronic Overload Relays

## 3RB20, 3RB21 for standard applications

Туре		3RB2056, 3RB2153	3RB2066, 3RB2163
Size		S6	S10/S12
Auxiliary circuit			
Number of NO contacts		1	
Number of NC contacts		1	
Auxiliary contacts – assignment		1 NO for the signal "tripped"; 1 NC for disconnecting the contactor	
Rated insulation voltage <i>U</i> <sub>i</sub> (pollution degree 3)		300	
Rated impulse withstand voltage U <sub>imp</sub>	kV	4	
Auxiliary contacts – contact rating			
• NC contact with alternating current AC-14/AC-15, rated operational current $I_{\rm e}$ at $U_{\rm e}$ :	٨	4	
- 24 V - 120 V	A A	4	
- 125 V	Α	4	
- 250 V	Α	3	
<ul> <li>NO contact with alternating current AC-14/AC-15, rated operational current I<sub>e</sub> at U<sub>e</sub>:</li> <li>24 V</li> </ul>	А	4	
- 120 V	Â	4	
- 125 V	A	4	
250 V     NO contacts with DC current DC-13,  Part of Contacts with DC current DC-13,	А	3	
rated operational current $I_{\rm e}$ at $U_{\rm e}$ : - 24 V	А	2	
- 60 V	A	0.55	
- 110 V	A	0.3	
- 125 V - 250 V	A A	0.3 0.11	
$ullet$ Conventional thermal current $I_{ m th}$	Α	5	
Contact reliability (suitability for PLC control; 17 V, 5 mA)	, · ·	Yes	
Short-circuit protection		165	
With fuse, operational class gG	Α	6	
Ground-fault protection (only 3RB21)		The information refers to sinusoida	al residual currents at 50/60 Hz
			ar residuar currents at 50/60 Hz.
$ullet$ Tripping value $I_{\Delta}$		$> 0.75 \times I_{\text{motor}}$	E upper eugraph eatting
Operating range <i>I</i> Passages time <i>t</i> (in steady state condition)		Lower current setting $< I_{\text{motor}} < 3$ .	.5 × upper current setting
Response time t <sub>trip</sub> (in steady-state condition)	S	< 1	
Integrated electrical remote RESET (only 3RB21)		04.1/ DO 100 A 0.4.1//	
Connecting terminals A3, A4  Protective separation between auxiliary current paths acc. to IEC 60947-1	V	300 24 V DC, 100 mA, 2.4 W short-teri	m 
CSA, UL, UR rated data			
		P200 P200	
Auxiliary circuit – switching capacity		B300, R300	
Conductor cross-sections of the auxiliary circuit		0	
Connection type		Screw terminals	
Terminal screw		M3, Pozidriv size 2	
Operating devices	mm	Ø 5 6	
Prescribed tightening torque	Nm	0.8 1.2	
Conductor cross-sections (min./max.),			
1 or 2 conductors can be connected	2	1 (05 (1) 0 (05 (5.1)	
Solid and stranded		$1 \times (0.5 \dots 4)^{1)}, 2 \times (0.5 \dots 2.5)^{1)}$	
Finely stranded without end sleeve    Color   Col	mm <sup>2</sup>	. (0.5 0.5)1) - (5 1.4)	Y.
• Finely stranded with end sleeve (DIN 46228-1)		$1 \times (0.5 \dots 2.5)^{1)}, 2 \times (0.5 \dots 1.5)^{1}$	,
AWG cables, solid or stranded	AWG	2 × (20 14)	
Connection type		Spring-type terminals	
Operating devices	mm	3.0 x 0.5	
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected			
Solid and stranded	$\text{mm}^2$	2 × (0.25 1.5)	
• Finely stranded without end sleeve	$\text{mm}^2$		
• Finely stranded with end sleeve (DIN 46228-1)	mm <sup>2</sup>	2 × (0.25 1.5)	
AWG cables, solid or stranded		2 × (24 16)	
1) If two different conductor cross-sections are connected to one clamping		,	

<sup>1)</sup> If two different conductor cross-sections are connected to one clamping point, both cross-sections must be in the range specified.

IE3/IE4 ready 3RB20, 3RB21 for standard applications

#### Selection and ordering data

#### 3RB20 electronic overload relays for mounting onto contactors and stand-alone installation, CLASS 10E

Features and technical specifications:

- · Connection methods
  - Size S6
  - Main circuit: With busbar connection or as straight-through transformer,
  - Auxiliary circuit: Either screw or spring-type terminals
  - Sizes S10/S12:
  - Main circuit: With busbar connection.
  - Auxiliary circuit: Either screw or spring-type terminals
- · Overload protection, phase failure protection and asymmetry protection
- Internal power supply

- Auxiliary contacts 1 NO + 1 NC · Manual and automatic RESET
- Switch position indicator
- TEST function and self-monitoring

PU (UNIT, SET, M) = 1 = 1 unit PG = 41G





3RB2056-1FW2

	3RB2066-1MF2

Size contactor	Rated power for three-phase motors, rated value <sup>1)</sup>	Current setting value of the inverse-time delayed overload release	Short-circuit protection with fuse, type of coordination "2", operational class gG <sup>2)</sup>		Screw terminals (on auxiliary current side)	<b>+</b>	SD	Spring-type terminals (on auxiliary current side)	
	kW	A	A	d	Article No.	Price per PU	d	Article No.	Price per PU

#### Devices with busbar connection

for mounting onto contactor and stand-alone installation

22 ... 90 50 ... 200 3RB2056-1FC2 2 3RB2056-1FF2 Devices with straight-through transformer

for mounting onto contactor and stand-alone installation For mounting 22 ... 90 50 ... 200

onto S6 contactors with box terminals

3RB2056-1FW2

3RB2066-1GC2

3RB2066-1MC2

3RB2056-1FX2

3RB2066-1GF2

3RB2066-1MF2

#### Size S10/S12

#### Devices with busbar connection for mounting onto contactor and stand-alone installation

S10/S12	22 110	55 250	400
and size 14 (3TF68/ 3TF69) <sup>3)</sup>	90 450	160 630	800

<sup>1)</sup> Guide value for 4-pole standard motors at 50 Hz 400 V AC. The actual starting and rated data of the motor to be protected must be considered when selecting the units.

<sup>2)</sup> Maximum protection by fuse only for overload relays, type of coordination "2". For fuse values in connection with contactors, see Configuration Manual.

<sup>3)</sup> For 3TF68/3TF69 contactors, direct mounting is not possible.

### SIRIUS 3RB2 Electronic Overload Relays

#### 3RB20, 3RB21 for standard applications IE3/IE4 ready

#### 3RB20 electronic overload relays for mounting onto contactors and stand-alone installation, CLASS 20E

Features and technical specifications:

- · Connection methods
  - Size S6

Main circuit: With busbar connection or as straight-through

Auxiliary circuit: Either screw or spring-type terminals

- Sizes S10/S12:
  - Main circuit: With busbar connection,
- Auxiliary circuit: Either screw or spring-type terminals
- Overload protection, phase failure protection and asymmetry protection
- Internal power supply

- Auxiliary contacts 1 NO + 1 NC
- Manual and automatic RESET
- Switch position indicator
- TEST function and self-monitoring

PU (UNIT, SET, M) = 1 PS\* = 1 unit PG = 41G







3RB2056-1FW2

Size contactor	Rated power for three-phase motors rated value <sup>1)</sup>

Current setting value of the inverse-time delayed overload release

Short-circuit protection with fuse, type of coordina-tion "2", operational class gG<sup>2)</sup> Screw terminals (on auxiliary current side)



SD

Spring-type (on auxiliary current side)

Price per PU

3	~		

### Devices with busbar connection

for mounting onto contactor and stand-alone installation 22 ... 90 50 ... 200

Devices with straight-through transformer for mounting onto contactor and stand-alone installation

For mounting 22 ... 90 onto S6 contactors with

315 50 ... 200

3RB2056-2FC2

3RB2056-2FW2

3RB2066-2GC2

3RB2066-2MC2

Article No.

d

3RB2056-2FF2 2

Article No.

3RB2056-2FX2

3RB2066-2GF2

3RB2066-2MF2



#### Devices with busbar connection

#### for mounting onto contactor and stand-alone installation

•		
22 110	55 250	400
90 450	160 630	800

 $<sup>^{\</sup>rm 1)}$  Guide value for 4-pole standard motors at 50 Hz 400 V AC. The actual starting and rated data of the motor to be protected must be considered when selecting the units.

<sup>2)</sup> Maximum protection by fuse only for overload relays, type of coordination "2". For fuse values in connection with contactors, see Configuration Manual.

<sup>&</sup>lt;sup>3)</sup> For 3TF68/3TF69 contactors, direct mounting is not possible.

IE3/IE4 ready 3RB20, 3RB21 for standard applications

## 3RB21 electronic overload relays for mounting onto contactors and stand-alone installation, CLASS 5E, 10E, 20E and 30E adjustable

Features and technical specifications:

- · Connection methods
- Size S6
  - Main circuit: With busbar connection or as straight-through transformer,
  - Auxiliary circuit: Either screw or spring-type terminals
- Sizes S10/S12:
- Main circuit: With busbar connection,
- Auxiliary circuit: Either screw or spring-type terminals
- Overload protection, phase failure protection and asymmetry protection
- Internal ground-fault detection (activatable)

- Internal power supply
- Auxiliary contacts 1 NO + 1 NC
- · Manual and automatic RESET
- Electrical remote RESET integrated
- Switch position indicator
- TEST function and self-monitoring

PU (UNIT, SET, M) = 1 PS\* = 1 unit PG = 41G





3RB2153-4FX2

3RB2163-4MC2

Size contactor	Rated power for three-phase motors, rated value <sup>1)</sup>	Current setting value of the inverse-time delayed overload release	Short-circuit protection with fuse, type of coordination "2", operational class gG <sup>2)</sup>	SD	Screw terminals (on auxiliary current side)	<b>+</b>	SD	Spring-type terminals (on auxiliary current side)	8
	kW	Α	A	d	Article No.	Price per PU		Article No.	Price per PU

## Size S6

#### Devices with busbar connection

for mounting onto contactor and stand-alone installation
S6 22 ... 90 50 ... 200 315

Devices with straight-through transformer

Devices with straight-through transformer for mounting onto contactor and stand-alone installation

For mounting onto S6 contactors with box terminals

▶ 3RB2153-4FW2

3RB2153-4FX2

3RB2153-4FF2

## Size S10/S12<sup>2)</sup>

## Devices with busbar connection for mounting onto contactor and stand-alone installation

		arra otarra arorro	
	22 110	55 250	400
and size 14 (3TF68/ 3TF69) <sup>3)</sup>	90 450	160 630	800
3TF69) <sup>3)</sup>			

Ouide value for 4-pole standard motors at 50 Hz 400 V AC. The actual starting and rated data of the motor to be protected must be considered when selecting the units.

3RB2153-4FC2

3RB2163-4GF2 3RB2163-4MF2

<sup>2)</sup> Maximum protection by fuse only for overload relays, type of coordination "2". For fuse values in connection with contactors, see Configuration Manual.

<sup>3)</sup> For 3TF68/3TF69 contactors, direct mounting is not possible.

## SIRIUS 3RB2 Electronic Overload Relays

## Accessories for 3RB20, 3RB21

#### Overview

### Overload relays for standard applications

The following optional accessories are available for the 3RB20 and 3RB21 electronic overload relays:

• Mechanical RESET (for all sizes)

- Cable release for resetting devices which are difficult to access (for all sizes)
- Sealable cover (for all sizes)
- Terminal covers for sizes S6 to S10/S12
- Box terminal blocks for sizes S6 and S10/S12

		• 6	ox ter	minai diocks for sizes 56 ar	u 510/512		
Selection and ord	ering data						
	Version	Size	SD	Article No. Pri		PS*	PG
			d				
Mechanical RESE	Т						
<b></b>	Resetting plungers, holders and formers	S6 S10/S12	•	3RU1900-1A	1	1 unit	41F
	Pushbuttons with extended stroke (12 mm), IP65, Ø 22 mm	S6 S10/S12	•	3SU1200-0FB10-0AA0	1	1 unit	41J
	<b>Extension plungers</b> For compensation of the distance between a pushbutton and the unlatching button of the relay	S6 S10/S12	•	3SU1900-0KG10-0AA0	1	1 unit	41J
3RU1900-1A with pushbutton and extension plunger							
Cable releases wit	h holder for RESET						
<b>A</b>	For Ø 6.5 mm holes in the control panel; max. control panel thickness 8 mm	S6 S10/S12					
	<ul><li>Length 400 mm</li></ul>		<b>&gt;</b>	3RU1900-1B	1	1 unit	41F
3RU1900-1.	• Length 600 mm		•	3RU1900-1C	1	1 unit	41F
Sealable covers							
<b>0.</b> °0	For covering the setting knobs	S6 S10/S12	<b>&gt;</b>	3RB2984-0	1	10 units	41F
3RB2984-0							
Terminal covers							
Brokenston	Covers for cable lugs and busbar connections  • Length 100 mm	S6	<b>&gt;</b>	3RT1956-4EA1	1	1 unit	41B
	• Length 120 mm	S10/S12	•	3RT1966-4EA1	1	1 unit 1 unit	41B
SIEMENS	Covers for box terminals	010/012		01111300 4EA1		T GITIE	
	• Length 25 mm	S6	<b>&gt;</b>	3RT1956-4EA2	1	1 unit	41B
0DT10FC 4FA1	• Length 30 mm	S10/S12	<b>&gt;</b>	3RT1966-4EA2	1	1 unit	41B
3RT1956-4EA1	Covers for screw terminals	S6	<b>&gt;</b>	3RT1956-4EA3	1	1 unit	41B
SIEMENS MY NOW AGE	between contactor and overload relay, without box terminals (1 unit required per combination)	S10/S12	•	3RT1966-4EA3	1	1 unit	41B
3RT1956-4EA2							
Box terminal bloc					_		
/	For round and ribbon cables	41					
D n	• Up to 70 mm <sup>2</sup>	S6 <sup>1)</sup>	<b>•</b>	3RT1955-4G	1	1 unit	41B
	<ul> <li>Up to 120 mm<sup>2</sup></li> <li>Up to 240 mm<sup>2</sup></li> </ul>	S6 S10/S12	<b>&gt;</b>	3RT1956-4G 3RT1966-4G	1	1 unit 1 unit	41B 41B
3RT1954G							

 $<sup>^{1)}</sup>$  In the scope of supply for 3RT1054-1 contactors (55 kW).

## Accessories for 3RB20, 3RB21

#### General accessories

acriciai accesso										
	Version	Size	Color	For overload relays	SD	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
					d					
Tools for opening	g spring-type termin	als								
						Spring-type terminals	<u> </u>			
3RA2908-1A	Screwdrivers For all SIRIUS devices with spring-type terminals	Length approx. 200 mm, 3.0 mm x 0.5 mm	Titanium gray/ black, partially insulated	Main and auxiliary circuit connection: 3RB2	2	3RA2908-1A		1	1 unit	41B
Blank labels										
	Unit labeling plates <sup>1)</sup> For SIRIUS devices	20 mm x 7 mm	Pastel turquoise	3RB2	20	3RT1900-1SB20		100	340 units	41B
		20 mm x 7 mm	Titanium gray	3RB2	20	3RT2900-1SB20		100	340 units	41B
SBO_01429b	Adhesive inscription labels <sup>1)</sup> For SIRIUS devices	19 mm x 6 mm	Pastel turquoise	3RU2	15	3RT1900-1SB60		100	3 060 units	41B
3RT1900-1SB20	roi sinios devices	19 mm x 6 mm	Zinc yellow	3RU2	15	3RT1900-1SD60		100	3 060 units	41B
3RT2900-1SB20										

PC labeling system for individual inscription of unit labeling plates available from: murrplastik Systemtechnik GmbH (see page 16/20).


## SIRIUS 3RB2 Electronic Overload Relays

#### 3RB22, 3RB23 for high-feature applications

#### Overview

#### More information

Home page, see http://www.siemens.com/sirius-overloadrelays Industry Mall, see www.siemens.com/product?3RB2



- 3RB2985 function expansion module: Enables more functions to be added, e.g. internal ground-fault detection and/or an analog output with corresponding signals.
- 2 Motor current and trip class setting: Setting the device to the motor current and to the required trip class dependent on the start-up conditions is easy with the two rotary switches.
- Connecting terminals (removable joint block):
   The generously sized terminals permit connection of two conductors with different cross-sections for the auxiliary, control and sensor circuits. Connection is possible with screw connection and alternatively with spring-type connection.
- Test/RESET button:
   Enables testing of all important device components and functions, plus resetting of the device after a trip when manual RESET is selected.
- (5) Selector switch for manual/automatic RESET: With this switch you can choose between manual and automatic RESET.
- 6 Red LED "OVERLOAD": A continuous red light signals an active overload trip; a flickering red light signals an imminent trip (overload warning).
- (7) Red LED "THERMISTOR": A continuous red light signals an active thermistor trip.
- 8 Red LED "GND FAULT": A continuous red light signals a ground-fault tripping.
- Green LED "READY":
   A continuous green light signals that the device is working correctly.

SIRIUS 3RB22 and 3RB23 evaluation modules

The 3RB22 and 3RB23 electronic overload relays up to 630 A (up to 820 A possible in combination with a series transformer) are from a modular system and comprise an evaluation unit, a current measuring module and a connecting cable. The 3RB22 overload relays (with monostable auxiliary contacts) and the 3RB23 overload relays (with bistable auxiliary contacts) are supplied from an external voltage.

They have been designed for inverse-time delayed protection of loads with normal and heavy starting against excessive temperature rises due to overload, phase asymmetry or phase failure. An overload, phase asymmetry or phase failure result in an increase of the motor current beyond the set rated motor current.

Application Manual "SIRIUS Controls with IE3/IE4 Motors", see https://support.industry.siemens.com/cs/ww/en/view/94770820

Operating Instructions "3RB22, 3RB23 Electronic Overload Relays", see https://support.industry.siemens.com/cs/ww/en/view/21833251

Characteristics and certificates, see

https://support.industry.siemens.com/cs/ww/en/ps/16280

This current rise is detected by means of a current measuring module (see page 7/132) and electronically evaluated by the evaluation module which is connected to it. The evaluation electronics sends a signal to the auxiliary contacts. The auxiliary contacts then switch off the load by means of a contactor.

The break time depends on the ratio between the tripping current and current setting  $I_{\rm e}$  and is stored in the form of a long-term stable tripping characteristic curve (see Characteristic Curves). The "tripped" status is signaled by means of a continuous red "OVERLOAD" LED.

The LED indicates imminent tripping of the relay due to overload, phase asymmetry or phase failure by flickering when the limit current has been violated. In the case of the 3RB22 and 3RB23 overload relays this warning can also be issued through auxiliary contacts.

In addition to the described inverse-time delayed protection of loads against excessive temperature rises, the 3RB22 and 3RB23 electronic overload relays also allow direct temperature monitoring of the motor windings (full motor protection) by connection with broken-wire interlock of a PTC sensor circuit. With this temperature-dependent protection, the loads can be protected against overheating caused, for example, indirectly by reduced coolant flow and which cannot be detected by means of the current alone. In the event of overheating, the devices switch off the contactor, and thus the load, by means of the auxiliary contacts. The "tripped" status is signaled by means of a continuously illuminated "THERMISTOR" LED.

To protect the loads against high-resistance short circuits due to damage to the insulation, humidity, condensed water, etc., the 3RB22 and 3RB23 electronic overload relays offer the possibility of internal ground fault monitoring in conjunction with a function expansion module (for details, see Operating Instructions, not possible in conjunction with contactor assemblies for start-delta (wye-delta) starting). In the event of a ground fault the 3RB22 and 3RB23 relays trip instantaneously.

The "tripped" status is signaled by means of a continuous red "Ground Fault" LED. Signaling through auxiliary contacts is also possible.

After tripping due to overload, phase asymmetry, phase failure, thermistor or ground-fault tripping, the relay is reset manually or automatically after the recovery time has elapsed.

In conjunction with a function expansion module, the motor current measured by the microprocessor can be output in the form of a DC 4 mA to 20 mA analog signal for operating rotary coil instruments or for feeding into analog inputs of programmable logic controllers.

#### 3RB22, 3RB23 for high-feature applications

With an additional AS-Interface analog module the current values can also be transferred over the AS-i bus system.

The 3RB2 electronic overload relays are suitable for operation with frequency converters.

The devices are manufactured in accordance with environmental guidelines and contain environmentally friendly and reusable materials. They comply with all important worldwide standards and approvals.

#### Use in hazardous areas

The 3RB22 electronic overload relays (monostable) with the 3RB29 current measuring module are suitable for the overload protection of explosion-proof motors.

EC type test certificate for category (2) G/D exists. It has the number PTB 05 ATEX 3022.

#### Article No. scheme

Product versions		Article number
Electronic overload relays		3RB2 🗆 🗆 – 🗆 🗆 🗆
Device type	e. g. 2 = monostable device for high-feature applications, supplied from external source, for three-phase loads	
Size, rated operational current and power	e. g. 8 = irrespective of size and current	
Version of the automatic RESET, electrical remote RESET	e. g. 3 = switchable between manual/auto RESET, with integral electrical remote RESET	•
Trip class (CLASS)	e. g. 4 = CLASS 5E, 10E, 20E, 30E (adjustable)	
Setting range of the overload release	e.g. A = none specified	
Connection methods	e.g. A = screw terminals for auxiliary, control and main circuits	
Installation type	e. g. 1 = stand-alone installation	
Example		3RB2 2 8 3 - 4 A A 1

#### Note:


The Article No. scheme shows an overview of product versions for better understanding of the logic behind the article numbers.

For your orders please use the article numbers quoted in the selection and ordering data.

#### Benefits

The most important features and benefits of the 3RB22 and 3RB23 electronic overload relays are listed in the overview table, (see "General Data", page 7/71 onwards).

#### Advantages through energy efficiency



Overview of the energy management process

We offer you a unique portfolio for industrial energy management, using an energy management system that helps to optimally define your energy needs. We split up our industrial energy management into three phases – identify, evaluate, and realize – and we support you with the appropriate hardware and software solutions in every process phase.

The innovative products of the SIRIUS industrial controls portfolio can also make a substantial contribution to a plant's energy efficiency, see www.siemens.com/sirius/energysaving.

3RB22 and 3RB23 electronic overload relays contribute to energy efficiency throughout the plant as follows:

- Reduced inherent power loss
- Less heating of the control cabinet
- Smaller control cabinet air conditioners can be used

#### Application

#### Industries

The 3RB22/3RB23 electronic overload relays are suitable for customers from all industries who want to guarantee optimum inverse-time delayed and temperature-dependent protection of their electrical loads (e. g. motors) under normal and heavy starting conditions (CLASS 5 to CLASS 30), minimize project completion times, inventories and power consumption, and optimize plant availability and maintenance management.

#### Application

The 3RB22 and 3RB23 devices have been designed for the protection of three-phase asynchronous and single-phase AC motors

If single-phase AC motors are to be protected by the 3RB22 and 3RB23 electronic overload relays, the main current paths of the current measuring modules must be series-connected. For circuit diagrams see Operating Instructions.

#### **Ambient conditions**

The devices are insensitive to external influences such as shocks, corrosive ambient conditions, ageing and temperature fluctuations.

For the temperature range from -25  $^{\circ}$ C to +60  $^{\circ}$ C, the 3RB22 and 3RB23 electronic overload relays compensate the temperature in accordance with IEC 60947-4-1.

Configuration notes for use of the devices below  $-25^{\circ}\text{C}$  or above  $+60^{\circ}\text{C}$  on request.

## Use of SIRIUS protection devices in conjunction with IE3/IE4 motors

### Note:

For the use of 3RB22 and 3RB23 electronic overload relays in conjunction with highly energy-efficient IE3/IE4 motors, please observe the information on dimensioning and configuring, see Application Manual.

For more information, see Preface on page 7.

### SIRIUS 3RB2 Electronic Overload Relays

## 3RB22, 3RB23 for high-feature applications

#### Technical specifications

#### More information

Application Manual "SIRIUS Controls with IE3/IE4 Motors", see https://support.industry.siemens.com/cs/ww/en/view/94770820

Configuration Manual "Configuring SIRIUS Innovations – Selection Data for Fuseless and Fused Load Feeders", see https://support.industry.siemens.com/cs/ww/en/view/39714188

Operating Instructions "3RB22, 3RB23 Electronic Overload Relays", see https://support.industry.siemens.com/cs/ww/en/view/21833251

Technical specifications, see

https://support.industry.siemens.com/cs/ww/en/ps/16280/td

The following technical information is intended to provide an initial overview of the various types of device and functions.

Type – Overload relay: evaluation modules		3RB2283-4A.1 3RB2383-4A.1
Size contactor		S00 S10/S12
Dimensions of evaluation modules	mm	45 x 111 x 95
(W x H x D)		
General data		
Tripping in the event of		Overload, phase failure and phase asymmetry (> 40 % according to NEMA), + ground fault (with corresponding function expansion module) and activation of the thermistor motor protection (with closed PTC sensor circuit)
Trip class acc. to IEC 60947-4-1	CLASS	5E, 10E, 20E and 30E adjustable
Phase failure sensitivity		Yes
Overload warning		Yes, from 1.125 x $I_{\rm e}$ for symmetrical loads and from 0.85 x $I_{\rm e}$ for unsymmetrical loads
Reset and recovery		
<ul> <li>Reset options after tripping</li> </ul>		Manual, Automatic and Remote RESET
Recovery time		
- For automatic RESET	min.	<ul> <li>For tripping due to overcurrent: 3 (stored permanently),</li> <li>For tripping by thermistor: Time until the motor temperature has fallen 5 K below the response temperature,</li> <li>For tripping due to a ground fault: no automatic RESET</li> </ul>
- For manual RESET	min.	<ul> <li>For tripping due to overcurrent: 3 (stored permanently),</li> <li>For tripping by thermistor: Time until the motor temperature has fallen 5 K below the response temperature,</li> <li>For tripping due to a ground fault: Immediately</li> </ul>
- For remote RESET	min.	<ul> <li>For tripping due to overcurrent: 3 (stored permanently),</li> <li>For tripping by thermistor: Time until the motor temperature has fallen 5 K below the response temperature,</li> <li>For tripping due to a ground fault: Immediately</li> </ul>
Features		
Display of operating state on device		Yes, with four LEDs: - Green LED "Ready", - Red LED "Ground Fault", - Red LED "Thermistor", - Red LED "Overload"
TEST function		Yes, test of LEDs, electronics, auxiliary contacts and wiring of control circuit by pressing the button TEST/RESET / self-monitoring
RESET button		Yes, with the TEST/RESET button
STOP button		No
Protection and operation of explosion-proof motors		
EC type-examination certificate number according to directive 2014/34/EU (ATEX)		PTB 05 ATEX 3022  II (2) GD see https://support.automation.siemens.com/ WW/view/en/23115758
Ambient temperatures		
Storage/transport	°C	-40 +80
Operation	°C	-25 +60
Temperature compensation	°C	+60
Permissible rated current		
- Temperature inside control cabinet 60 °C	%	100
- Temperature inside control cabinet 70 °C	%	On request
Degree of protection acc. to IEC 60529		IP20
Touch protection acc. to IEC 60529		Finger-safe
Shock resistance with sine acc. to IEC 60068-2-27	g/ms	15/11

3RB22, 3RB23 for high-feature applications

		3RB22, 3RB23 for high-feature applications
Type – Overload relay: evaluation modules		3RB2283-4A.1 3RB2383-4A.1
Size contactor	3	S00 S10/S12
Dimensions of evaluation modules	<b>∠</b> mm	45 x 111 x 95
$(W \times H \times D)$		
General data (continued)		
Electromagnetic compatibility (EMC) – Interference immun	ity	
Conductor-related interference		
- Burst acc. to IEC 61000-4-4 (corresponds to degree of severity 3)	kV	2 (power ports), 1 (signal port)
- Surge acc. to IEC 61000-4-5 (corresponds to degree of severity 3)	kV	2 (line to earth), 1 (line to line)
Electrostatic discharge according to IEC 61000-4-2 (corresponds to degree of severity 3)	kV	8 (air discharge), 6 (contact discharge)
Field-related interference acc. to IEC 61000-4-3 (corresponds to degree of severity 3)	V/m	10
Electromagnetic compatibility (EMC) – Emitted interference	9	Degree of severity A according to EN 55011 (CISPR 11) and EN 55022 (CISPR 22)
Resistance to extreme climates – air humidity	%	100
Installation altitude above sea level	m	Up to 2 000
Mounting position		Any
Type of mounting		
Evaluation modules		Stand-alone installation
Current measuring module	Size	S00 to S3: Stand-alone installation,
		S6 and S10/S12: Stand-alone installation or mounting onto contactors
Type – Overload relay: evaluation modules		3RB2283-4A.1, 3RB2383-4A.1
Size contactor		S00 S10/S12
Auxiliary circuit		
Number of NO contacts		2
Number of NC contacts		2
Number of CO contacts		
		<ul> <li>1 NO for the signal "tripped by overload and/or thermistor",</li> <li>1 NC for disconnecting the contactor,</li> <li>1 NO for the signal "tripped by ground fault",</li> <li>1 NC for disconnecting the contactor</li> <li>or 1)</li> <li>Alternative 2</li> <li>1 NO for the signal "tripped by overload and/or thermistor and/or ground fault",</li> <li>1 NC for disconnecting the contactor,</li> <li>1 NO for overload warning</li> <li>1 NC for disconnecting the contactor</li> </ul>
Rated insulation voltage <i>U</i> <sub>i</sub> (pollution degree 3)	V	300
Rated impulse withstand voltage U <sub>imp</sub>	kV	4
Auxiliary contacts – contact rating	***	·
• NC, NO contact with alternating current AC-14/AC-15, rated operational current $I_{\rm e}$ at $U_{\rm e}$ = 24 V = 120 V = 125 V = 250 V	A A A	6 6 6 3
• NC, NO contacts with DC current DC-13, rated operational current $I_{\rm e}$ at $U_{\rm e}$ - 24 V	A	2
- 60 V	Α	0.55
- 110 V - 125 V	A A	0.3 0.3
- 250 V	Ä	0.2
<ul> <li>Conventional thermal current I<sub>th</sub></li> <li>Contact reliability</li> </ul>	А	5 Yes
(suitability for PLC control; 17 V, 5 mA)		
Short-circuit protection	Δ.	
With fuse, operational class gG     With ministure circuit breaker. Coherenteristic.	A	6
With miniature circuit breaker, C characteristic  Protective separation between auxiliary current paths	A V	1.6 300
Acc. to IEC 60947-1		
CSA, UL, UR rated data		
Auxiliary circuit – switching capacity		B300, R300
The assignment of auxiliary contacts may be influenced by f		

The assignment of auxiliary contacts may be influenced by function expansion modules.

## SIRIUS 3RB2 Electronic Overload Relays

## 3RB22, 3RB23 for high-feature applications

Type – Overload relay: evaluation modules		3RB2283-4A.1, 3RB2383-4A.1
Size contactor		S00 S10/S12
Control circuit		
Rated insulation voltage <i>U</i> <sub>i</sub> (pollution degree 3)	V	300
Rated impulse withstand voltage U <sub>imp</sub>	kV	4
Rated control supply voltage $U_{\rm s}$		
• 50/60 Hz AC	V	24 240
• DC	V	24 240
Operating range		
• 50/60 Hz AC		$0.85 \times U_{\text{s min}} \le U_{\text{s}} \le 1.1 \times U_{\text{s max}}$
• DC		$0.85 \times U_{\text{s min}} \le U_{\text{s}} \le 1.1 \times U_{\text{s max}}$
Rated power		
• 50/60 Hz AC	W	0.5
• DC	W	0.5
Mains buffering time	ms	200
Sensor circuit		
Thermistor motor protection (PTC thermistor sensor)		
Summation cold resistance	kΩ	≤ 1.5
Response value	kΩ	3.4 3.8
Return value	kΩ	1.5 1.65
Ground-fault detection		The information refers to sinusoidal residual currents at 50/60 Hz.
$ullet$ Tripping value $I_{\Delta}{}^{1)}$		
- For 0.3 $ imes I_{ m e}$ < $I_{ m motor}$ < 2.0 $ imes$ $I_{ m e}$		$> 0.3 \times I_{\mathrm{e}}$
- For 2.0 $ imes I_{ m e}$ < $I_{ m motor}$ < 8.0 $ imes$ $I_{ m e}$		$> 0.15 \times I_{motor}$
• Response time t <sub>trip</sub>	ms	500 1 000
Analog output <sup>1)2)</sup>		
Rated values		
Output signal	mA	4 20
Measuring range		0 1.25 × $I_{\rm e}$ 4 mA is equivalent to 0 × $I_{\rm e}$ 16.8 mA is equivalent to 1.0 × $I_{\rm e}$ 20 mA is equivalent to 1.25 × $I_{\rm e}$
• Load, max.	Ω	100
Conductor cross-sections for the auxiliary, contro	ol and	
Connection type		Screw terminals
Terminal screw		M3, Pozidriv size 2
Operating devices	mm	$3.0 \times 0.5$
Prescribed tightening torque	Nm	0.8 1.2
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected	_	
Solid or stranded	mm <sup>2</sup>	$1 \times (0.5 \dots 4)^{3)}, 2 \times (0.5 \dots 2.5)^{3)}$
<ul> <li>Finely stranded without end sleeve</li> </ul>	mm <sup>2</sup>	
• Finely stranded with end sleeve (DIN 46228-1)	mm <sup>2</sup>	$1 \times (0.5 \dots 2.5)^{3)}, 2 \times (0.5 \dots 1.5)^{3)}$
AWG cables, solid or stranded	AWG	2 × (20 14)
Connection type		Spring-type terminals
Operating devices	mm	3.0 x 0.5
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected	_	
Solid or stranded	mm <sup>2</sup>	2 × (0.25 1.5)
Finely stranded without end sleeve	mm <sup>2</sup>	
• Finely stranded with end sleeve (DIN 46228-1)	mm <sup>2</sup>	2 × (0.25 1.5)
AWG cables, solid or stranded	AWG	2 × (24 16)
1) For the 2000 and 2000 averland relays in combination	1.1	3) If the different conductor expenses tions are connected to one classical

<sup>1)</sup> For the 3RB22 and 3RB23 overload relays in combination with a corresponding function expansion module.

Analog input modules, e.g. SM 331, must be configured for 4-wire measuring transducers. In this case the analog input module must not supply current to the analog output of the 3RB22 and 3RB23 relay.

<sup>3)</sup> If two different conductor cross-sections are connected to one clamping point, both cross-sections must be in the range specified.

3RB22, 3RB23 for high-feature applications

### Functions of the 3RB22 and 3RB23 evaluation modules in combination with the 3RB2985 function expansion modules

Evaluation modules	With function expansion module	Basic functions	Inputs A1/A2	T1/T2	Y1/Y2
3RB2283-4AA1 3RB2283-4AC1 3RB2383-4AA1		Inverse-time delayed protection, temperature-dependent protection, electrical remote RESET, overload warning	Power supply 24 240 V AC/DC	Connection PTC sensor	Electrical remote RESET
3RB2383-4AC1	3RB2985-2CA1	Inverse-time delayed protection, temperature-dependent protection, internal ground-fault detection, electrical remote RESET, overload warning	Power supply 24 240 V AC/DC	Connection PTC sensor	Electrical remote RESET
	3RB2985-2CB1	Inverse-time delayed protection, temperature-dependent protection, internal ground-fault detection, electrical remote RESET, ground-fault signal	Power supply 24 240 V AC/DC	Connection PTC sensor	Electrical remote RESET
	3RB2985-2AA0	Inverse-time delayed protection, temperature-dependent protection, electrical remote RESET, overload warning, analog output	Power supply 24 240 V AC/DC	Connection PTC sensor	Electrical remote RESET
	3RB2985-2AA1	Inverse-time delayed protection, temperature-dependent protection, internal ground-fault detection, electrical remote RESET, overload warning, analog output	Power supply 24 240 V AC/DC	Connection PTC sensor	Electrical remote RESET
	3RB2985-2AB1	Inverse-time delayed protection, temperature-dependent protection, internal ground-fault detection, electrical remote RESET, ground-fault signal, analog output	Power supply 24 240 V AC/DC	Connection PTC sensor	Electrical remote RESET

Evaluation modules	With function	Outputs									
	expansion module	I ( <del>-</del> ) / I (+)	95/96 NC	97/98 NO	05/06 NC	07/08 NO					
3RB2283-4AA1 3RB2283-4AC1 3RB2383-4AA1		No	Disconnection of the contactor (inverse-time delayed/temperature-dependent protection)	Signal "tripped"	Overload warning	Overload warning					
3RB2383-4AC1	3RB2985-2CA1	No	Disconnection of the contactor (inverse-time delayed/temperature-dependent protection + ground fault)	Signal "tripped"	Overload warning	Overload warning					
3R£	3RB2985-2CB1	No	Disconnection of the contactor (inverse-time delayed/temperature-dependent protection)	Signal "tripped"	Disconnection of the contactor (ground fault)	Signal "ground-fault tripping"					
	3RB2985-2AA0	Analog signal	Disconnection of the contactor (inverse-time delayed/temperature-dependent protection)	Signal "tripped"	Overload warning	Overload warning					
	3RB2985-2AA1	Analog signal	Disconnection of the contactor (inverse-time delayed/temperature-dependent protection + ground fault)	Signal "tripped"	Overload warning	Overload warning					
	3RB2985-2AB1	Analog signal	Disconnection of the contactor (inverse-time delayed/temperature-dependent protection)	Signal "tripped"	Disconnection of the contactor (ground fault)	Signal "ground-fault tripping"					

## 3RB22, 3RB23 for high-feature applications IE3/IE4 ready

3RB22 and 3RB23 electronic overload relays (evaluation modules) for full motor protection, stand-alone installation, CLASS 5E, 10E, 20E and 30E (adjustable)

Туре	3RB2283-4A.1, 3RB2383-4A.1
Features and technical specifications	
Overload protection, phase failure protection and asymmetry protection	✓
Supplied from an external source	24 240 V AC/DC
Auxiliary contacts	2 NO + 2 NC
Electrical remote RESET integrated	✓
Four LEDs for operating and status displays	✓
TEST function and self-monitoring	✓
Internal ground-fault detection	(with function expansion module)
Screw or spring-type terminals for auxiliary, control and sensor circuits	✓
Input for PTC sensor circuit	✓
Analog output	(with function expansion module)
✓ Available	

## Selection and ordering data

 $\begin{array}{ll} PU \text{ (UNIT, SET, M)} = 1 \\ PS^* & = 1 \text{ unit} \\ PG & = 41G \end{array}$ 





3RB2283-4AA1, 3RB2383-4AA1 3RB2283-4AC1, 3RB2383-4AC1

Size contactor	Version	SD	Screw terminals	⊕ SE	Spring-type terminals	$\stackrel{\circ}{\square}$
		d	Article No.	Price per PU d	Article No.	Price per PU
<b>Evaluation modules</b>						
S00 S12	Monostable	<b>&gt;</b>	3RB2283-4AA1	<b>&gt;</b>	3RB2283-4AC1	
	Bistable	▶	3RB2383-4AA1	<b>&gt;</b>	3RB2383-4AC1	

#### Notes:

Overview of overload relays – matching contactors, see page 7/76.

Current measuring modules and related connecting cables, see page 7/132, general accessories, see page 7/133 onwards.

**IE3/IE4 ready** 3RB22, 3RB23 for high-feature applications

#### Function expansion modules for 3RB22 and 3RB23 overload relays (evaluation modules)

	Size contactor	Version	For overload relays	SD	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
Sizes S00 to S12				d					
31263 300 to 312		For plugging into evaluation module (1 unit)							
	S00 S12	Analog Basic 1 modules <sup>1)</sup> Analog output 4 20 mA DC, with overload warning	3RB22, 3RB23	<b>&gt;</b>	3RB2985-2AA0		1	1 unit	41F
3RB2985-21		Analog Basic 1 GF modules 1/2) Analog output 4 20 mA DC, with internal ground-fault detection and overload warning	3RB22, 3RB23	•	3RB2985-2AA1		1	1 unit	41F
		Analog Basic 2 GF modules <sup>1)2)</sup> Analog output 4 20 mA DC, with internal ground-fault detection and ground-fault signal	3RB22, 3RB23	<b>&gt;</b>	3RB2985-2AB1		1	1 unit	41F
		Basic 1 GF modules <sup>2)</sup> with internal ground-fault detection and overload warning	3RB22, 3RB23	<b>&gt;</b>	3RB2985-2CA1		1	1 unit	41F
		Basic 2 GF modules <sup>2)</sup> with internal ground-fault detection and ground-fault signal	3RB22, 3RB23	<b>&gt;</b>	3RB2985-2CB1		1	1 unit	41F

<sup>1)</sup> The analog signal 4 mA up to 20 mA DC can be used for operating rotary coil instruments or for feeding into analog inputs of programmable logic controllers.

- 2) The following information on ground-fault protection refers to sinusoidal residual currents at 50/60 Hz:
  - With a motor current of between 0.3 and 2 times the current setting  $I_{\rm e}$ , the unit will trip at a ground-fault current equal to 30 % of the current setting.
  - With a motor current of between 2 and 8 times the current setting  $I_{\rm e}$ , the unit will trip at a ground-fault current equal to 15 % of the current setting.
  - The response delay amounts to between 0.5 s and 1 s.

### Note:

Analog input modules, e.g. SM 331, must be configured for 4-wire measuring transducers. In this case the analog input module must not supply current to the analog output of the 3RB22/3RB23 relay.


### SIRIUS 3RB2 Electronic Overload Relays

#### 3RB24 for IO-Link for high-feature applications

#### Overview

#### More information

Home page, see http://www.siemens.com/sirius-overloadrelays Industry Mall. see www.siemens.com/product?3RB2



- Plug-in point for operator panel: enables connection of the 3RA6935-0A operator panel.
- Motor current and trip class setting:
  Setting the device to the motor current and to the required trip class dependent on the start-up conditions is easy with the two rotary switches.
- Connecting terminals (removable terminal block): The generously sized terminals permit connection of two conductors with different cross-sections for the auxiliary, control and sensor circuits. Connection is possible with screw connection and alternatively with spring-type connection.
- (4) Test/RESET button: Enables testing of all important device components and functions, plus resetting of the device after a trip when manual RESET is selected.
- (5) Selector switch for manual/automatic RESET: With this switch you can choose between manual and automatic RESET.
- 6 Red LED "OVERLOAD": A continuous red light signals an active overload trip; a flickering led light signals an imminent trip (overload warning).
- Red LED "THERMISTOR": A continuous red light signals an active thermistor trip.
- (8) Red LED "GND FAULT": A continuous red light signals an active ground-fault trip.
- Green LED "DEVICE/IO-Link: A continuous green light signals that the device is working correctly, a green flickering light signals the communication through IO-Link.

#### SIRIUS 3RB24 evaluation module

The modular, IO-Link powered 3RB24 electronic overload relays (with monostable auxiliary contacts) up to 630 A (up to 820 A possible with a series transformer) have been designed for current-dependent protection of loads with normal and heavy starting against excessive temperature rises due to overload, phase asymmetry or phase failure. It comprises an evaluation unit, a current measuring module and a connecting cable.

The evaluation module 3RB24 also offers an engine starter function: The contactors, which are connected via the auxiliary contacts, can also be actuated for operation via IO-Link. In this way, direct-on-line, reversing and wye-delta starters up to 630 A (or 830 A) can be connected to the controller wirelessly via the IO-Link controller.

Application Manual "SIRIUS Controls with IE3/IE4 Motors", see https://support.industry.siemens.com/cs/ww/en/view/94770820

Manual "SIRIUS 3RB24 Electronic Overload Relay for IO-Link", see https://support.industry.siemens.com/cs/ww/en/view/46165627

Certificates, see https://support.industry.siemens.com/cs/ww/en/ps/16281/cert

An overload, phase asymmetry or phase failure result in an increase of the motor current beyond the set rated motor current.

This current rise is detected by means of the current measuring module (see page 7/132) and electronically evaluated by the evaluation module which is connected to it. The evaluation electronics sends a signal to the auxiliary contacts. The auxiliary contacts then switch off the load by means of a contactor.

The break time depends on the ratio between the tripping current and current setting  $I_{\rm e}$  and is stored in the form of a long-term stable tripping characteristic curve (see Manual). The "tripped" status is signaled by means of a continuously illuminated red "OVERLOAD" LED and also reported as a group fault via IO-Link.

The LED indicates imminent tripping of the relay due to overload, phase asymmetry or phase failure by flickering when the limit current has been violated. This warning can also be reported to the higher-level PLC via IO-Link at the 3RB24 overload relay.

In addition to the described inverse-time delayed protection of loads against excessive temperature rises, the 3RB24 electronic overload relays also allow direct temperature monitoring of the motor windings (full motor protection) by connection with broken-wire interlock of a PTC sensor circuit. With this temperature-dependent protection, the loads can be protected against overheating caused, for example, indirectly by reduced coolant flow and which cannot be detected by means of the current alone. In the event of overheating, the devices switch off the contactor, and thus the load, by means of the auxiliary contacts. The "tripped" status is signaled by means of a continuously illuminated "THERMISTOR" LED and also reported as a group fault via IO-1 ink.

To protect the loads against incomplete ground faults due to damage to the insulation, humidity, condensation, etc., the 3RB24 electronic overload relays offer the possibility of internal ground-fault detection (for details, see Manual, not possible in conjunction with contactor assemblies for star-delta (wye-delta) starting). In the event of a ground fault, the 3RB24 relays trip instantaneously.

The "tripped" status is signaled by means of a flashing red LED "Ground Fault" and reported at the overload relay 3RB24 as a group fault via IO-Link.

The reset after overload, phase asymmetry, phase failure, thermistor or ground-fault tripping is performed manually by key on site, via IO-Link or by electrical remote RESET or automatically after the cooling time (motor model) or for thermistor protection after sufficient cooling. Trips in devices initiated by function monitoring systems (broken wire or short-circuit on the thermistor) can only be reset locally.

A motor current measured by the microprocessor can be output in the form of an analog signal DC 4 mA to 20 mA for operating rotary coil instruments or for feeding into analog inputs of programmable logic controllers.

#### 3RB24 for IO-Link for high-feature applications

The current values can be transmitted to the higher-level controller via IO-Link.

The 3RB24 electronic overload relay for IO-Link is suitable for operation with frequency converters.

The devices are manufactured in accordance with environmental guidelines and contain environmentally friendly and reusable materials. They comply with all important worldwide standards and approvals.

#### Use in hazardous areas

The 3RB24 electronic overload relays for IO-Link with the 3RB29 current measuring module are suitable for the overload protection of motors with the following types of protection:

- 🐼 II (2) G [Ex e] [Ex d] [Ex px]
- 😥 II (2) D [Ex t] [Ex p]

EC type test certificate for Group II, Category (2) G/D exists. It has the number PTB 11 ATEX 3014.

#### Article No. scheme

Product versions		Article number
Electronic overload relays		3RB2 🗆 🗆 🗕 🗆 🗆 🗆
Device type	e. g. 4 = monostable device for high-feature applications, supplied from external source (24 V DC), for three-phase loads	
Size, rated operational current and power	e. g. 8 = irrespective of size and current	
Version of the automatic RESET, electrical remote RESET	e. g. 3 = switchable between manual/auto RESET, with integral electrical remote RESET	•
Trip class (CLASS)	e. g. 4 = CLASS 5E, 10E, 20E, 30E (adjustable)	
Setting range of the overload release	e.g. A = none specified	
Connection methods	e.g. A = screw terminals for auxiliary, control and main circuits	
Installation type	e. g. 1 = stand-alone installation	
Example		3RB2 4 8 3 - 4 A A 1

#### Note:


The Article No. scheme shows an overview of product versions for better understanding of the logic behind the article numbers.

For your orders please use the article numbers quoted in the selection and ordering data.

#### Benefits

The most important features and benefits of the 3RB24 electronic overload relays for IO-Link are listed in the overview table (see "General Data", page 7/71 onwards).

#### Advantages through energy efficiency



Overview of the energy management process

We offer you a unique portfolio for industrial energy management, using an energy management system that helps to optimally define your energy needs. We split up our industrial energy management into three phases – identify, evaluate, and realize – and we support you with the appropriate hardware and software solutions in every process phase.

The innovative products of the SIRIUS industrial controls portfolio can also make a substantial contribution to a plant's energy efficiency (see www.siemens.com/sirius/energysaving).

3RB24 electronic overload relays for IO-Link contribute to energy efficiency throughout the plant as follows:

- Transmission of current values
- Reduced inherent power loss
- Less heating of the control cabinet
- Smaller control cabinet air conditioners can be used

### SIRIUS 3RB2 Electronic Overload Relays

#### 3RB24 for IO-Link for high-feature applications

#### Application

#### Industries

The 3RB24 electronic overload relays are suitable for customers from all industries who want to guarantee optimum current and temperature-dependent protection of their electrical loads (e.g. motors) under normal and heavy starting conditions (CLASS 5E to 30E), minimize project completion times, inventories and energy consumption, and optimize plant availability and maintenance management.

#### Application

The 3RB24 electronic overload relays have been designed for the protection of three-phase asynchronous and single-phase

In addition to protection function, these devices can be used together with contactors as direct or reversing starters (star-delta (wye-delta) start also possible), which are controlled via IO-Link. This makes it possible to directly control drives via IO-Link from a higher-level controller or on site via the optional hand-held device and also, for example, to return current values directly via IO-Link.

If single-phase AC motors are to be protected by the 3RB24 electronic overload relays, the main current paths of the current measuring modules must be series-connected. (Circuit Diagrams see Manual).

#### Ambient conditions

The devices are insensitive to external influences such as shocks, corrosive ambient conditions, ageing and temperature fluctuations

In the temperature range from -25 °C to +60 °C, the 3RB24 electronic overload relays compensate the temperature in accordance with IEC 60947-4-1.

Configuration notes for use of the devices below -25°C or above +60°Č on request.

#### Use of SIRIUS protection devices in conjunction with IE3/IE4 motors

#### Note:

For the use of 3RB24 electronic overload relays in conjunction with highly energy-efficient IE3/IE4 motors, please observe the information on dimensioning and configuring, see Application

For more information, see Preface on page 7.

#### Technical specifications

#### More information

Application Manual "SIRIUS Controls with IE3/IE4 Motors", see

Configuration Manual "Configuring SIRIUS Innovations – Selection Data for Fuseless and Fused Load Feeders", see

https://support.industry.siemens.com/cs/ww/en/view/39714188

Manual "SIRIUS 3RB24 Electronic Overload Relay for IO-Link", see

Technical specifications, see


https://support.industry.siemens.com/cs/ww/en/ps/16281/td

The following technical information is intended to provide an initial overview of the various types of device and functions.

#### Type - Overload relay: evaluation modules

Size contactor

Dimensions of evaluation modules  $(W \times H \times D)$ 



#### 3BB2483-4A.1

S00 ... S10/S12 45 x 111 x 95

#### General data

### Tripping in the event of

Overload, phase failure and phase asymmetry (> 40 % according to NEMA), + ground fault (connectable and disconnectable) and activation of the thermistor motor protection (with closed PTC sensor circuit)

Trip class acc. to IEC 60947-4-1 CLASS 5E, 10E, 20E and 30E adjustable Phase failure sensitivity

min.

Overload warning

Yes, from 1.125 x  $I_{\rm e}$  for symmetrical loads and from 0.85 x  $I_{\rm e}$  for unsymmetrical loads

#### Reset and recovery

- Reset options after tripping
- Recovery time
- For automatic RESET

- For manual RESET

- Manual and automatic RESET, electrical remote RESET or through IO-Link
- For tripping due to overcurrent: 3 (stored permanently), For tripping by thermistor: Time until the motor temperature has fallen 5 K below the response temperature,
  - For tripping due to a ground fault: no automatic RESET
- For tripping due to overcurrent: 3 (stored permanently), min.
  - For tripping by thermistor: Time until the motor temperature has fallen 5 K below the response temperature,
  - For tripping due to a ground fault: Immediately
- For remote RESET min.
- - For tripping due to overcurrent: 3 (stored permanently), - For tripping by thermistor: Time until the motor temperature has fallen 5 K below the response temperature.
  - For tripping due to a ground fault: Immediately

## 3RB24 for IO-Link for high-feature applications

Type – Overload relay: evaluation modules		3RB2483-4A.1
Size contactor		S00 S10/S12
Dimensions of evaluation modules (W x H x D)	mm	45 x 111 x 95
(W × II × B)		
General data (continued)		
Features		
Display of operating state on device		Yes, with four LEDs:
		- Green "DEVICE/IO-Link" LED - Red LED "Ground Fault"
		- Red LED "Thermistor"
		- Red "Overload" LED
TEST function		Yes, test of LEDs, electronics, auxiliary contacts and wiring of control circuit by pressing the button TEST/RESET / self-monitoring
RESET button		Yes, with the TEST/RESET button
STOP button		No
Protection and operation of explosion-proof motors		
EC type-examination certificate number according to directive 2014/34/EU (ATEX)		PTB 11 ATEX 3014  (ii) II (2) G [Ex e] [Ex d] [Ex px]
		(2) G [Ex t] [Ex p]
		see https://support.industry.siemens.com/cs/ww/en/view/60524083
Ambient temperatures		
Storage/transport	°C	-40 +80
Operation	°C	-25 +60
Temperature compensation	°C	+60
Permissible rated current		
<ul> <li>Temperature inside control cabinet 60 °C</li> </ul>	%	100
- Temperature inside control cabinet 70 °C	%	On request
Degree of protection acc. to IEC 60529		IP20
Touch protection acc. to IEC 60529		Finger-safe Finger-safe
Shock resistance with sine acc. to IEC 60068-2-27	g/ms	15/11
Electromagnetic compatibility (EMC) – Interference immunity		
Conductor-related interference		
- Burst acc. to IEC 61000-4-4 (corresponds to degree of severity 3)	kV	2 (power ports), 1 (signal port)
<ul> <li>Surge acc. to IEC 61000-4-5 (corresponds to degree of severity 3)</li> </ul>	kV	2 (line to earth), 1 (line to line)
Electrostatic discharge according to IEC 61000-4-2 (corresponds to degree of severity 3)	kV	8 (air discharge), 6 (contact discharge)
Field-related interference acc. to IEC 61000-4-3 (corresponds to degree of severity 3)	V/m	10
Electromagnetic compatibility (EMC) – Emitted interference		Degree of severity A according to EN 55011 (CISPR 11) and EN 55022 (CISPR 22)
Resistance to extreme climates – air humidity	%	100
Installation altitude above sea level	m	Up to 2 000
Mounting position		Any
Type of mounting		
Evaluation modules		Stand-alone installation
Current measuring module	Size	S00 to S3: Stand-alone installation, S6 and S10/S12: Stand-alone installation or mounting onto contactors

## SIRIUS 3RB2 Electronic Overload Relays

## 3RB24 for IO-Link for high-feature applications

Type – Overload relay: evaluation modules		3RB2483-4A.1
Size contactor		S00 S10/S12
Auxiliary circuit		
Number of auxiliary switches		1 CO contact, 1 NO contact connected in series internally
Auxiliary contacts – assignment		<ul> <li>1 CO contact for selecting the contactor (for reversing starter function), actuated by the control system</li> </ul>
		<ul> <li>1 NO contact for normal switching duty, actuated by the control system (opens automatically when tripping occurs)</li> </ul>
Rated insulation voltage <i>U</i> <sub>i</sub> (pollution degree 3)	V	300
Rated impulse withstand voltage U <sub>imp</sub>	kV	4
Auxiliary contacts – contact rating		
<ul> <li>NC, NO contact with alternating current AC-14/AC-15, rated operational current I<sub>e</sub> at U<sub>e</sub></li> <li>24 V</li> </ul>	А	6
- 120 V	A	6
- 125 V	A	6
- 250 V	А	3
<ul> <li>NC, NO contacts with DC current DC-13, rated operational current I<sub>e</sub> at U<sub>e</sub></li> <li>24 V</li> </ul>	А	2
- 60 V	A	0.55
- 110 V	A	0.3
- 125 V - 250 V	A A	0.3 0.2
$ullet$ Conventional thermal current $I_{ m th}$	Α	5
Contact reliability		Yes
(suitability for PLC control; 17 V, 5 mA)		
Short-circuit protection		
<ul> <li>With fuse, operational class gG</li> </ul>	Α	6
With miniature circuit breaker, C characteristic	Α	1.6
Protective separation between auxiliary current paths Acc. to IEC 60947-1	V	300
CSA, UL, UR rated data		
Auxiliary circuit – switching capacity		B300, R300
Conductor cross-sections of the auxiliary circuit		
Connection type		Screw terminals
Terminal screw		M3, Pozidriv size 2
Operating devices	mm	3.0 x 0.5
Prescribed tightening torque	Nm	0.8 1.2
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected		
Solid or stranded	mm <sup>2</sup>	$1 \times (0.5 \dots 4)^{1)}, 2 \times (0.5 \dots 2.5)^{1)}$
Finely stranded without end sleeve	$\text{mm}^2$	-
• Finely stranded with end sleeve (DIN 46228-1)	$\mathrm{mm}^2$	$1 \times (0.5 \dots 2.5)^{1)}, 2 \times (0.5 \dots 1.5)^{1)}$
AWG cables, solid or stranded	AWG	2 × (20 14)
Connection type		Spring-type terminals     □
Operating devices	mm	3.0 x 0.5
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected		
Solid or stranded	$\rm mm^2$	2 × (0.25 1.5)
• Finely stranded without end sleeve	$\rm mm^2$	-
• Finely stranded with end sleeve (DIN 46228-1)	$\rm mm^2$	2 × (0.25 1.5)
<ul> <li>AWG cables, solid or stranded</li> </ul>	AWG	2 × (24 16)

<sup>1)</sup> If two different conductor cross-sections are connected to one clamping point, both cross-sections must be in the range specified.

## 3RB24 for IO-Link for high-feature applications

		ODD0400 44 4
Type – Overload relay: evaluation modules		3RB2483-4A.1
Size contactor		S00 S10/S12
Control circuit		
Rated insulation voltage <i>U</i> <sub>i</sub> (pollution degree 3)	V	300
Rated impulse withstand voltage $U_{\rm imp}$	kV	4
Rated control supply voltage $U_s^{(1)}$		
• DC	V	24 through IO-Link
Operating range		
• DC		$0.85 \times U_{\text{S min}} \leq U_{\text{S}} \leq 1.1 \times U_{\text{S max}}$
Rated power		
• DC	W	0.5
Mains buffering time	ms	200
Sensor circuit		
Thermistor motor protection (PTC thermistor sensor)		
Summation cold resistance	kΩ	≤ 1.5
Response value	kΩ	3.4 3.8
Return value	kΩ	1.5 1.65
Ground-fault detection		The information refers to sinusoidal residual currents at 50/60 Hz.
$ullet$ Tripping value $I_{\Lambda}$		
- For 0.3 × $I_{ m e}$ < $I_{ m motor}$ < 2.0 × $I_{ m e}$		$> 0.3 \times I_{\scriptscriptstyle  m P}$
- For $2.0 \times I_{\rm e} < I_{\rm motor} < 8.0 \times I_{\rm e}$		$> 0.15 \times I_{\text{motor}}$
$ullet$ Response time $t_{ m trip}$	ms	500 1 000
Analog output <sup>1)</sup>		
Rated values		
Output signal	mA	4 20
Measuring range		0 1.25 $\times$ $I_{\rm e}$ 4 mA is equivalent to 0 $\times$ $I_{\rm e}$ 16.8 mA is equivalent to 1.0 $\times$ $I_{\rm e}$ 20 mA is equivalent to 1.25 $\times$ $I_{\rm e}$
• Load, max.	Ω	100
Conductor cross-sections for the control and sensor circuits as well as the analog output		
Connection type		Screw terminals
Terminal screw		M3, Pozidriv size 2
Operating devices	mm	3.0 × 0.5
Prescribed tightening torque	Nm	0.8 1.2
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected		
• Solid	$\text{mm}^2$	$1 \times (0.5 \dots 4)^{2}$ , $2 \times (0.5 \dots 2.5)^{2}$
Finely stranded without end sleeve	mm <sup>2</sup>	
• Finely stranded with end sleeve (DIN 46228-1)		$1 \times (0.5 \dots 2.5)^{2}, 2 \times (0.5 \dots 1.5)^{2}$
• Stranded	mm <sup>2</sup>	
AWG cables, solid or stranded	AWG	2 × (20 14)
Connection type	7	Spring-type terminals
Operating devices	mm	3.0 × 0.5
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected		
• Solid	$\text{mm}^2$	2 × (0.25 1.5)
Finely stranded without end sleeve	$\rm mm^2$	
• Finely stranded with end sleeve (DIN 46228-1)	$\rm mm^2$	2 × (0.25 1.5)
• Stranded	$\text{mm}^2$	2 × (0.25 1.5)
AWG cables, solid or stranded	AWG	2 × (24 16)
1) Analog input modules, e.g. SM 331, must be configured for 4-wire	2)	If two different conductor cross-sections are connected to one clamping

Analog input modules, e.g. SM 331, must be configured for 4-wire measuring transducers. The analog input module may not supply current to the analog output of the 3RB24 overload relay.

<sup>2)</sup> If two different conductor cross-sections are connected to one clamping point, both cross-sections must be in the range specified.

### SIRIUS 3RB2 Electronic Overload Relays

## 

## 3RB24 electronic overload relays (evaluation modules) for full motor protection, stand-alone installation, CLASS 5E, 10E, 20E and 30E (adjustable)

Peatures and technical specifications Overload protection, phase failure protection and asymmetry protection Supplied from an external source  Direct-on-line or reversing starters (wye-delta starting also possible) controllable through IO-Link Auxiliary contacts  Manual and automatic RESET  Remote RESET  Four LEDs for operating and status displays  TEST function and self-monitoring Internal ground-fault detection  Screw or spring-type terminals for auxiliary, control and sensor circuits Input for PTC sensor circuit Analog output  IO-Link-specific functions	
Supplied from an external source  Direct-on-line or reversing starters (wye-delta starting also possible) controllable through IO-Link  Auxiliary contacts  Manual and automatic RESET  Remote RESET  Four LEDs for operating and status displays  TEST function and self-monitoring  Internal ground-fault detection  Screw or spring-type terminals for auxiliary, control and sensor circuits  Input for PTC sensor circuit  Analog output	
Direct-on-line or reversing starters (wye-delta starting also possible) controllable through IO-Link  Auxiliary contacts  Manual and automatic RESET  Remote RESET  Four LEDs for operating and status displays  TEST function and self-monitoring  Internal ground-fault detection  Screw or spring-type terminals for auxiliary, control and sensor circuits  Input for PTC sensor circuit  Analog output	
Auxiliary contacts  Manual and automatic RESET  Remote RESET  Four LEDs for operating and status displays  TEST function and self-monitoring Internal ground-fault detection  Screw or spring-type terminals for auxiliary, control and sensor circuits Input for PTC sensor circuit  Analog output	
Manual and automatic RESET Remote RESET  Four LEDs for operating and status displays TEST function and self-monitoring Internal ground-fault detection Screw or spring-type terminals for auxiliary, control and sensor circuits Input for PTC sensor circuit Analog output	
Remote RESET  Four LEDs for operating and status displays  FST function and self-monitoring Internal ground-fault detection Screw or spring-type terminals for auxiliary, control and sensor circuits Input for PTC sensor circuit Analog output	
Four LEDs for operating and status displays  TEST function and self-monitoring  Internal ground-fault detection  Screw or spring-type terminals for auxiliary, control and sensor circuits  Input for PTC sensor circuit  Analog output	
TEST function and self-monitoring  Internal ground-fault detection  Screw or spring-type terminals for auxiliary, control and sensor circuits  Input for PTC sensor circuit  Analog output	
Internal ground-fault detection  Screw or spring-type terminals for auxiliary, control and sensor circuits Input for PTC sensor circuit  Analog output	
Screw or spring-type terminals for auxiliary, control and sensor circuits  Input for PTC sensor circuit  Analog output	
Input for PTC sensor circuit  Analog output	
Analog output ✓	
IO-Link-specific functions	
Connection of direct-on-line, reversing and star-delta starters to the controller via IO-Link     ✓	
<ul> <li>On-site controlling of the starter using the hand-held device</li> </ul>	
<ul> <li>◆ Accessing process data (e.g. current values in all three phases) via IO-Link</li> </ul>	
◆ Accessing parameterization and diagnostics data (e.g. tripped signals) via IO-Link	

#### ✓ Available

#### Selection and ordering data

PU (UNIT, SET, M) = 1 PS\* = 1 unit PG = 41G





3RB2483-4AA1

3RB2483-4AC1

Size contactor	Version	SD	Screw terminals	<b></b>	SD	Spring-type terminals	$\stackrel{\circ}{\square}$
_		d	Article No. Pr	ice PU	d	Article No.	Price per PU
Evaluation modules							
S00 S12	Monostable	<b>&gt;</b>	3RB2483-4AA1		2	3RB2483-4AC1	

#### Notes:

- Overview table of overload relays matching contactors, see page 7/76
- Analog input modules, e.g. SM 331, must be configured for 4-wire measuring transducers. The analog input module may not supply current to the analog output of the 3RB24 relay.

Current measuring modules and related connecting cables, see page 7/132, "Accessories", see page 7/133 onwards.

Current measuring modules for 3RB22, 3RB23, 3RB24

#### Overview

#### More information

Home page, see http://www.siemens.com/sirius-overloadrelays Industry Mall, see www.siemens.com/product?3RB2



Application Manual "SIRIUS Controls with IE3/IE4 Motors", see https://support.industry.siemens.com/cs/ww/en/view/94770820 Other Manuals, see

https://support.industry.siemens.com/cs/ww/en/ps/16282/man

The current measuring modules are designed as system components for connecting to evaluation units 3RB22 to 3RB24. Using these evaluation units the motor current is measured and the measured value sent to the evaluation unit for evaluation.

The current measuring modules in sizes up to S3 are equipped with straight-through transformers and can be snap-fitted under the evaluation units. The larger evaluation units are installed directly on the contactor or as stand-alone units.

SIRIUS 3RB2906 current measuring module

### Application

#### Use of SIRIUS protection devices in conjunction with IE3/IE4 motors

### Note:

For the use of current measuring modules for 3RB22, 3RB23, 3RB24 in conjunction with highly energy-efficient IE3/IE4 motors, please read the information on dimensioning and configuration, see Application Manual.

For more information, see Preface on page 7.

## SIRIUS 3RB2 Electronic Overload Relays

## Current measuring modules for 3RB22, 3RB23, 3RB24

#### Technical specifications

#### More information

Manuals, see https://support.industry.siemens.com/cs/ww/en/ps/16282/man

Technical specifications, see https://support.industry.siemens.com/cs/ww/en/ps/16282/td

The following technical information is intended to provide an initial overview of the various types of device and functions.

Type – Overload relays: Current measuring modules			3RB2906		3RB2956	3RB2966			
Size contactor			S00/S0	S2/S3	S6	S10/S12			
Dimensions of current measuring modules (W x H x D)	W	mm	45 x 84 x 45	55 x 94 x 72	120 x 119 x 145	145 x 147 x 148			
Main circuit									
Rated insulation voltage <i>U</i> <sub>i</sub> (pollution degree 3)		V	1 000						
Rated impulse withstand voltage U <sub>imp</sub>		kV	6		8				
Rated operational voltage U <sub>e</sub>		V	1 000						
Type of current									
Direct current			No						
Alternating current			Yes, 50/60 H	z ± 5 %					
Current setting		А	0.3 3; 2.4 25	10 100	20 200	63 630			
Power loss per unit (max.)		W	0.5						
Short-circuit protection									
With fuse without contactor			see "Selectio	n and Orderir	ng Data", page 7/132				
With fuse and contactor			See Configuration Manuals						
			<ul> <li>"Configuring SIRIUS Innovations – Selection Data for Fuseless and Fused Load Feeders"</li> </ul>						
			• "SIRIUS Configuration – Selection Data for Fuseless Load Feeders"						
Degree of protection acc. to IEC 60529									
Screw terminals/busbar connections			IP20		<ul><li>IP20 (front side)</li><li>Terminal IP00 (us for higher degree</li></ul>	e additional terminal covers of protection)			
<ul> <li>Straight-through transformers</li> </ul>			IP20		IP20				
Touch protection acc. to IEC 60529									
Screw terminals/busbar connections			Finger-safe		Finger-safe with terr tact from the front	minal covers for vertical con-			
Straight-through transformers			Finger-safe		Finger-safe				
Protective separation between main and auxiliacc. to IEC 60947-1 (pollution degree 2)	ary current paths								
<ul> <li>For systems with grounded neutral point</li> </ul>		V	690						
For systems with ungrounded neutral point		V	600						

## Current measuring modules for 3RB22, 3RB23, 3RB24

Type – Overload relays: Current measuring modules		3RB	2906		3RB2956	3RB2966
Size contactor		S00/	S0	S2/S3	S6	S10/S12
Dimensions of current measuring modules	mm	45 x	84 x 45	55 x 94 x 72	120 x 119 x 145	145 x 147 x 148
W x H x D)	<del>-    -    -    -    -    -    -    - </del>	_				
Conductor cross-sections of main circuit			Carou t	orminala wit	h box terminal	
Connection type		4	Screwi	emmais wii	ii box teriiiiiai	
Terminal screw	mm				4 mm Allen screw	5 mm Allen screw
Operating devices	mm				4 mm Allen screw	5 mm Allen screw
Prescribed tightening torque	Nm				10 12	20 22
Conductor cross-sections (min./max.), 1 or 2 conductorsections (min./max.)	ors can be connected mm <sup>2</sup>				With box terminal 3RT1955-4G: 2 × (max. 70), 1 × (16 70)	2 × (70 240), Front clamping point only: 1 × (95 300)
Finely stranded without end sleeve	mm²				With box terminal 3RT1956-4G: 2 × (max. 120), 1 × (16 120) With box terminal	Rear clamping point only: 1 × (120 240)  2 × (50 185),
					3RT1955-4G: 2 × (1 × max. 50, 1 × max. 70), 1 × (10 70) With box terminal	Front clamping point only: 1 × (70 240)  Rear clamping point
	2				3RT1956-4G: 2 × (1 × max. 95, 1 × max. 120), 1 × (10 120)	only: 1 × (120 185)
Finely stranded with end sleeve (DIN 46228-1)	mm <sup>2</sup>				With box terminal 3RT1955-4G: 2 × (1 × max. 50, 1 × max. 70), 1 × (10 70)	2 × (50 185), Front clamping point only: 1 × (70 240)
					With box terminal 3RT1956-4G: 2 × (1 × max. 95, 1 × max. 120), 1 × (10 120)	Rear clamping point only: 1 × (120 185)
• AWG cables	AWG				With box terminal 3RT1955-4G: 2 × (max. 1/0), 1 × (6 2/0)	2 × (2/0 500 kcmil), Front clamping point only: 1 × (3/0 600 kcmil)
					With box terminal 3RT1956-4G: 2 × (max. 3/0), 1 × (6 250 kcmil)	Rear clamping point only: 1 × (250 kcmil 500 kcmil)
Ribbon cables (Number x Width x Thickness)	mm				With box terminal 3RT1955-4G: 2 × (6 × 15.5 × 0.8), 1 × (3 × 9 × 0.8 6 × 15.5 × 0.8)	$2 \times (20 \times 24 \times 0.5),$ $1 \times (6 \times 9 \times 0.8$ $20 \times 24 \times 0.5)$
					With box terminal $3RT1956-4G$ : $2 \times (10 \times 15.5 \times 0.8)$ , $1 \times (3 \times 9 \times 0.8 \dots 10 \times 15.5 \times 0.8)$	
Connection type		00	Busbar	connections	S	
Terminal screw					M8 × 25	M10 x 30
Prescribed tightening torque	Nm				10 14	14 24
						0)
Conductor cross-sections (min./max.), 1 or 2 conductor	_				10 001)	
Conductor cross-sections (min./max.), 1 or 2 conductors Solid with cable lug	$\mathrm{mm}^2$				16 95 <sup>1)</sup>	50 240 <sup>2)</sup>
Conductor cross-sections (min./max.), 1 or 2 conductors Solid with cable lug Stranded with cable lug	mm² mm²				25 120 <sup>1)</sup>	70 240 <sup>2)</sup>
Conductor cross-sections (min./max.), 1 or 2 conductors Solid with cable lug  Stranded with cable lug  AWG cables, solid or stranded, with cable lug	mm² mm² AWG	  			25 120 <sup>1)</sup> 4 250 kcmil	70 240 <sup>2)</sup> 2/0 500 kcmil
Conductor cross-sections (min./max.), 1 or 2 conductors Solid with cable lug Stranded with cable lug	mm² mm²		Straigh	t-through tra	25 120 <sup>1)</sup> 4 250 kcmil 17	70 240 <sup>2)</sup>
Conductor cross-sections (min./max.), 1 or 2 conductors Solid with cable lug  Stranded with cable lug  AWG cables, solid or stranded, with cable lug  With connecting bars (max. width)	mm² mm² AWG			t-through tra	25 120 <sup>1)</sup> 4 250 kcmil 17	70 240 <sup>2)</sup> 2/0 500 kcmil

When connecting cable lugs according to DIN 46235 with conductor cross-sections of 95 mm<sup>2</sup> and more, the 3RT1956-4EA1 terminal cover must be used to ensure phase clearance, see page 7/133.

When connecting cable lugs according to DIN 46234 for conductor cross-sections from 240 mm², as well as DIN 46235 for cable cross-sections from 185 mm², the 3RT1956-4EA1 terminal cover must be used to ensure phase clearance, see page 7/133.

### SIRIUS 3RB2 Electronic Overload Relays

Current measuring modules for 3RB22, 3RB23, 3RB24 IE3/IE4 ready

#### Selection and ordering data

#### Current measuring modules (essential accessories)







3RB2906-2JG1







3RB2966-2WH2

Size contactor	Current setting value of the inverse-time delayed overload release	Short-circuit protection with fuse, type of coordination "2", operational class gG <sup>1)</sup>	For overload relays	SD		Price er PU	PU (UNIT, SET, M)	PS*	PG
	А	Α		d					
Sizes S00/S0									
Devices with straight-t for stand-alone installa									
S00/S0	0.3 3	20	3RB22 to	<b>&gt;</b>	3RB2906-2BG1		1	1 unit	41G
	2.4 25	63	3RB24	<b>&gt;</b>	3RB2906-2DG1		1	1 unit	41G
Sizes S2/S3									
Devices with straight-t for stand-alone installa									
S2/S3	10 100	315	3RB22 to 3RB24	<b>&gt;</b>	3RB2906-2JG1		1	1 unit	41G
Size S6									
Devices with busbar co for mounting onto con		ne installation							
S6	20 200	315	3RB22 to 3RB24	•	3RB2956-2TH2		1	1 unit	41G
Devices with straight-t for mounting onto con		ne installation							
For mounting onto \$6 contactors with box terminals	20 200	315	3RB22 to 3RB24	<b>&gt;</b>	3RB2956-2TG2		1	1 unit	41G
Sizes S10/S12 <sup>2)</sup>									
Devices with busbar co		ne installation							
S10/S12 and size 14 (3TF68/3TF69) <sup>2)</sup>	63 630	800	3RB22 to 3RB24	•	3RB2966-2WH2		1	1 unit	41G

<sup>1)</sup> Maximum protection by fuse only for overload relays, type of coordination "2". For fuse values in connection with contactors, See Configuration Manuals

- See Configuration Manuals
   "Configuring SIRIUS Innovations Selection Data for Fuseless and Fused
   "Look Fuseless"
- "SIRIUS Configuration Selection Data for Fuseless Load Feeders".

## Note:

The connecting cable between the current measuring module and the evaluation module is not included in the scope of supply; please order separately (see "Accessories").

## Accessories

		Size contactor	Version	For overload relays	SD		Price er PU	PU (UNIT, SET, M)	PS*	PG
					d					
	Connecting cab	les (essent	ial accessories)							
			For connection between evaluation module and current measuring module							
		S00 S3	<ul> <li>Length 0.1 m (only for mounting of the evaluation module directly onto the current measuring module)</li> </ul>	3RB22 to 3RB24	•	3RB2987-2B		1	1 unit	41F
	3RB2987-2.	S00 S12	• Length 0.5 m	3RB22 to 3RB24	<b>&gt;</b>	3RB2987-2D		1	1 unit	41F

Additional general accessories, see page 7/133.

<sup>2)</sup> For 3TF68/3TF69 contactors, direct mounting is not possible.

Accessories for 3RB22, 3RB23, 3RB24

#### Overview

#### More information

Home page, see http://www.siemens.com/sirius-overloadrelays Industry Mall, see www.siemens.com/product?3RB2

Manuals, see https://support.industry.siemens.com/cs/ww/en/ps/16283/man

The following optional accessories are available for the 3RB22 to 3RB24 electronic overload relays:

- Operator panel for the evaluation modules 3RB24
- Sealable cover for the evaluation modules 3RB22 to 3RB24
- Terminal covers for the 3RB29 current measuring modules size S6 and S10/S12
- Box terminal blocks for the 3RB29 current measuring modules size S6 and S10/S12
- Push-in lugs for screw fixing for 3RB22 to 3RB24 evaluation modules and 3RB2906 current measuring modules

#### Selection and ordering data

#### Accessories for 3RB24 overload relays

Accessories for She	324 Overload Telays								
	Version		For overload relays	SD	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
			,	d			. ,		
Operator panels for	evaluation modules								
A STATE OF THE PARTY OF THE PAR	Operator panels (set)		3RB24	10	3RA6935-0A		1	1 unit	42F
3RA6935-0A	One set comprises:  • 1 x operator panel  • 1 x 3RA6936-0A enabling modul  1 x 3RA6936-0B interface cover  • 1 x fixing terminal	le							
	Note: The connecting cable between the evaluation module and the operator panel is not included in the scope of supply; please order separately.  Connecting cables Length 2.5 m (round), for connecting the evaluation module to the operator panel								
			3RB24	•	3UF7933-0BA00-0		1	1 unit	42J
	Enabling modules (replacement	)	3RB24	10	3RA6936-0A		1	1 unit	42F
	Interface covers		3RB24	10	3RA6936-0B		1	5 units	42F
General accessories	5								
	Vencies	Size	Ган	SD	Article No.	Deino	PU	PS*	PG
	Version	Size	For overload relays		Article No.	Price per PU	(UNIT, SET, M)	P5*	PG
Osalabla assum fam				d					
Sealable covers for e			00000	Ţ.	0000010			40 ''	
e and a second	For covering the setting knobs		3RB22 to 3RB24	•	3RB2984-2		1	10 units	41F
3RB2984-2									
Terminal covers for	current measuring modules								
Brothadford	Covers for cable lugs and busbar connections								
	Length 100 mm	S6	3RB2956	<b>&gt;</b>	3RT1956-4EA1		1	1 unit	41B
SIEMENS	• Length 120 mm	S10/S12	3RB2966	<b>&gt;</b>	3RT1966-4EA1		1	1 unit	41B
	Covers for box terminals								
0DT4050 4544	<ul> <li>Length 25 mm</li> </ul>	S6	3RB2956	<b>&gt;</b>	3RT1956-4EA2		1	1 unit	41B
3RT1956-4EA1	Length 30 mm	S10/S12	3RB2966	<b>&gt;</b>	3RT1966-4EA2		1	1 unit	41B
SIEMENS	Covers for screw terminals between contactor and overload	S6	3RB2956	<b>&gt;</b>	3RT1956-4EA3		1	1 unit	41B
3RT1956-4EA2	relay, without box terminals (1 unit required per combination)	S10/S12	3RB2966	•	3RT1966-4EA3		1	1 unit	41B
Box terminal blocks	for current measuring module	es							
	For round and ribbon cables								
D. Committee	• Up to 70 mm <sup>2</sup>	S6 <sup>1)</sup>	3RB2956	<b>&gt;</b>	3RT1955-4G		1	1 unit	41B
	• Up to 120 mm <sup>2</sup>	S6	3RB2956	<b>&gt;</b>	3RT1956-4G		1	1 unit	41B
	• Up to 240 mm <sup>2</sup>	S10/S12	3RB2966	•	3RT1966-4G		1	1 unit	41B
3RT1954G									

<sup>1)</sup> In the scope of supply for 3RT1054-1 contactors (55 kW).

## SIRIUS 3RB2 Electronic Overload Relays

## Accessories for 3RB22, 3RB23, 3RB24

	Version		Size	For overload relays	SD	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
					d					
Push-in lugs for e										
3RP1903	For screw fixing the	evaluation modules		3RB22 to 3RB24	5	3RP1903		1	10 units	41H
3RB1900-0B	For screw fixing the modules (2 units rec		S00 S3	3RB2906	2	3RB1900-0B		100	10 units	41F
	Version	Size	Color	For overload relays	SD	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
					d					
Tools for opening	spring-type term	inals				-				
						Spring-type terminals	$\stackrel{\infty}{\boxplus}$			
3RA2908-1A	Screwdrivers For all SIRIUS devices with spring- type terminals	Length, approx. 200 mm, 3.0 mm x 0.5 mm	Titanium gray/ black, partially insulated	Main and auxiliary circuit connection: 3RB2	2	3RA2908-1A		1	1 unit	41B
Blank labels										
	Unit labeling plates <sup>1)</sup>	20 mm x 7 mm	Pastel turquoise	3RB2	20	3RT1900-1SB20		100	340 units	41B
	For SIRIUS devices	20 mm x 7 mm	Titanium gray	3RB2	20	3RT2900-1SB20		100	340 units	41B
-01429b	Adhesive inscription	19 mm x 6 mm	Pastel turquoise	3RU2	15	3RT1900-1SB60		100	3 060 units	41B
<b>_______</b>	labels <sup>1)</sup> For SIRIUS devices	19 mm x 6 mm	Zinc yellow	3RU2	15	3RT1900-1SD60		100	3 060 units	41B
3RT2900-1SB20										

PC labeling system for individual inscription of unit labeling plates available from: murrplastik Systemtechnik GmbH (see page 16/20).