



Quick Start Instructions

To power up the YLCDRX63NE, take the male barrel jack connector from the AC/DC Power Adapter and insert it into the female barrel jack (J101) on the bottom side of the YLCDRX63NE.

Now at the top right corner of the bottom side of the YLCDRX63NEcombo, there's a switch (S201) which controls the power to the YLCDRX63NE. Ensure that this switch is in the ON position as shown by pushing the switch gently away from the connector labeled RS485/CAN that's below it.

The YDBENETPMOD/YLCDRX63N combo is now ready to power up. Plug the AC/DC Power Adapter into an outlet, then wait a moment and the two ABOUT and HOME screens should appear in sequence (See photos on Back).

You have now successfully powered up your YDBENETPMOD/YLCDRX63N combo.



For further instructions on how to use the Demo programs and develop your own projects, please proceed to <http://am.renesas.com/dlcd+comm>.

X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for [Display Development Tools](#) category:

Click to view products by [Renesas](#) manufacturer:

Other Similar products are found below :

[KIT 60121-3](#) [S5U13U11P00C100](#) [MAX14521EEVKIT](#) [KIT 60145-3](#) [S5U13748P00C100](#) [DFR0413](#) [3248](#) [DLPLCR90EVM](#)
[MAX20069EVKIT#](#) [KIT95000-3](#) [LCD-16396](#) [PIM370](#) [1109](#) [MCIMX-LVDS1](#) [MIKROE-2449](#) [MIKROE-2453](#) [131](#) [DEV-13628](#) [1590](#)
[MIKROE-2269](#) [1601](#) [1770](#) [1947](#) [1983](#) [1987](#) [2050](#) [2218](#) [2219](#) [2260](#) [2345](#) [2418](#) [2423](#) [2454](#) [2455](#) [2478](#) [2674](#) [SK-220RD-PI](#) [FIT0477](#) [333](#)
[1774](#) [334](#) [TE-M321-SDK](#) [DFR0428](#) [cs-epapersk-03](#) [338](#) [DEV-14442](#) [FIT0478](#) [cs-paperino-01](#) [OM-E-OLE](#) [ALTHSMCMIPILCD](#)